

[Manuals.plus](#) /
› [SANODESK](#) /
› SANODESK Standing Desk Height Adjustable Electric Stand up Desk 40x24 Inches Sit Stand Home Office with Splice Board, White Frame/White Top User Manual

SANODESK 40x24 White Frame+ White Top

SANODESK Standing Desk User Manual

Model: 40x24 White Frame+ White Top

INTRODUCTION

Thank you for choosing the SANODESK Electric Height Adjustable Standing Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new ergonomic workspace. Designed for comfort and stability, this desk allows you to effortlessly switch between sitting and standing positions, promoting a healthier work routine.



Image: The SANODESK 40x24 inch electric standing desk, featuring a white frame and white top, set up with a computer monitor, keyboard, mouse, and headphones, highlighting its modern design and functionality.

SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during operation.
- Do not overload the desk. The maximum load capacity is 154 lbs (70 kg).
- Avoid placing liquids directly on the control panel or near electrical components.
- Do not attempt to disassemble or repair the motor or control system yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Verify that all items are present before beginning assembly:

- Desktop (Splice Board)

- Desk Frame Components (Legs, Crossbar)
- Control Panel and Motor
- Power Adapter and Cable
- Assembly Tools
- Instruction Manual

SETUP GUIDE

The SANODESK standing desk is designed for easy assembly. It is recommended to have two people for certain steps, though one person can complete the assembly.

Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components on a clean, flat surface. Refer to the included parts list to ensure everything is present.
2. **Assemble the Frame:** Attach the desk legs to the crossbar using the provided screws and tools. Ensure all connections are secure.
3. **Attach the Desktop:** Carefully place the desktop onto the assembled frame. Align the pre-drilled holes in the desktop with the frame. Secure the desktop to the frame using the appropriate screws.
4. **Install Control Panel:** Mount the control panel to the underside of the desktop in the designated location. Connect the motor and power cables to the control panel as per the wiring diagram in the detailed installation manual.
5. **Connect Power:** Plug the power adapter into the control panel and then into a wall outlet.

| Desk Dimensions



Image: A visual representation of the desk dimensions, indicating a width of 40 inches and a depth of 24 inches, providing clarity for space planning.

For a visual guide, please refer to the official product video:

Your browser does not support the video tag.

Video: An official SANODESK video demonstrating the assembly process and key features of the standing desk, including its height adjustment mechanism and stability.

Control Panel Functions:

| Multifunctional Control Panel




Image: A detailed view of the desk's control panel, showing the LED display for current height, up/down arrows for manual adjustment, and four memory preset buttons for saving preferred heights.

- **LED Display:** Shows the current height of the desk in inches.
- **Up/Down Buttons (▲ / ▼):** Press and hold to manually adjust the desk height. Release to stop.

- **Memory Presets (1, 2, 3, 4):** The desk can save up to 4 custom heights.

Setting Memory Presets:

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the 'M' or 'Set' button (if available, otherwise refer to specific button on panel). The display may flash.
3. Within 3 seconds, press the desired number button (1, 2, 3, or 4) to save the current height to that preset.

Using Memory Presets:

Simply press the corresponding number button (1, 2, 3, or 4) to automatically move the desk to the saved height.

Wide Lifting Range

28.9"-46.5"



Image: The desk demonstrating its wide height adjustment range, from a minimum of 28.9 inches suitable for sitting to a maximum of 46.5 inches for comfortable standing.

MAINTENANCE

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight.
- **Cable Management:** Keep cables tidy to prevent entanglement during height adjustments.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Overload; Motor error.	Check power connections. Reduce weight on desk. Unplug for 30 seconds and plug back in to reset.
Desk moves unevenly.	Uneven load; Loose connections.	Distribute weight evenly. Check and tighten all assembly screws.
Noise during operation.	Normal motor sound; Loose components.	A slight motor sound is normal. Check for any loose parts and tighten them.

SPECIFICATIONS

- **Product Dimensions:** 24"D x 40"W x 29"H
- **Height Range:** 28.9 inches - 46.5 inches
- **Maximum Load Capacity:** 154 lbs
- **Lifting Mechanism:** Electric (Dual Motors)
- **Top Material Type:** Wood
- **Base Material:** Alloy Steel
- **Color:** White Frame + White Top
- **Control Panel:** Multifunctional with LED display and 4 memory presets



load capacity of

154 lbs

| Reliable & smooth lifting

Smooth lifting, with a maximum

Image: A demonstration of the desk's robust construction, showing a person sitting on the desktop to highlight its 154 lbs load capacity and stable, smooth lifting capabilities.

WARRANTY AND SUPPORT

SANODESK products come with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official SANODESK website. If you encounter any issues or require assistance, please contact SANODESK customer support through the following channels:

- **Online Support:** Visit the [SANODESK Store on Amazon](#) for FAQs and contact options.
- **Email Support:** Refer to your product documentation for the dedicated support email address.

© 2025 SANODESK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D82X9NG1>

More documents and user manuals: <https://manuals.plus/>