

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CAPHAUS](#) /

› [CAPHAUS 94.5-Inch Large Indoor Outdoor Dog Kennel with Removable Roof User Manual](#)

## CAPHAUS PHHDO-BH9601

# CAPHAUS 94.5-Inch Large Indoor Outdoor Dog Kennel with Removable Roof User Manual

Model: PHHDO-BH9601

## 1. INTRODUCTION

Thank you for choosing the CAPHAUS 94.5-Inch Large Indoor Outdoor Dog Kennel. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your new pet enclosure. Please read all instructions carefully before use and retain this manual for future reference.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure all parts are securely fastened before allowing pets inside the kennel.
- Regularly inspect the kennel for any signs of damage, loose parts, or wear. Replace damaged components immediately.
- Do not allow children to climb on or play inside the kennel without adult supervision.
- Position the kennel on a flat, stable surface to prevent tipping.
- Ensure adequate ventilation when using the kennel indoors.
- The roof provides protection from sun and rain; however, do not leave pets unattended in extreme weather conditions.
- This kennel is designed for pets. Do not use it for purposes other than its intended use.

## 3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Metal Panels (12 pieces, including 1 door panel)
- Waterproof and Anti-UV Roof Cover

- Ground Stakes (24 pieces)
- Lock Mechanism Components (lock plates, screws, nuts)
- Assembly Hardware (bolts, nuts, washers)
- Wrench (for tightening nuts)

If any parts are missing or damaged, please contact customer support.

## 4. ASSEMBLY AND SETUP

Follow these steps to assemble your CAPHAUS dog kennel. It is recommended to have two people for easier assembly.

### 4.1 Panel Assembly

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the metal panels using the provided bolts, nuts, and washers. Ensure the panels are oriented correctly to form the desired enclosure shape.
3. Attach the door panel in the desired location, ensuring it opens and closes smoothly.

# COMPARISON

## 1 OUR KENNEL



**#Strong**  
**20MM Heavy Duty Steel**



**#Firm**  
**2.8MM Wire Mesh**



**#Durable**  
**5 Top Support Pipe**



**#Secure**  
**U-Shape Nails**



## OTHER KENNEL



**15MM Metal Tube**



**2.2MM Wire**



**2 Top Support Pipe**



**J-Shape Nails**



Image 1: Illustration of connecting the metal panels to form the kennel structure.

## 4.2 Roof Installation

1. Once the main frame is assembled, place the roof support pipes onto the top of the kennel frame.
2. Drape the waterproof and anti-UV roof cover over the support pipes.
3. Secure the roof cover to the frame using the elastic rubber fasteners, ensuring it is taut and covers the entire top area.


**OUR KENNEL**

**#Strong 20MM  
Heavy Duty Steel**

**#Firm 2.8MM  
Wire Mesh**

**#Durable 5 Top  
Support Pipe**

**#Secure  
U-Shape Nails**
**OTHER KENNEL**

**15MM  
Metal Tube**

**2.2MM  
Wire**
**VS**

**2 Top  
Support Pipe**

**J-Shape  
Nails**

Image 2: The grey canopy roof providing protection from sun and rain.

### 4.3 Door Lock Assembly

Assemble the door lock mechanism as shown in the video and detailed steps below:

Your browser does not support the video tag.

Video 1: Detailed instructions for assembling the heavy-duty dog kennel door lock.

1. Attach one lock plate to the door panel using the provided screws.
2. Insert the lock mechanism into the attached lock plate.
3. Attach the second lock plate to the frame, aligning it with the lock mechanism.
4. Secure all components with the nuts, tightening them with the provided wrench.



**VERSATILE USAGE  
THROUGH VARIOUS  
CONFIGURATION**

**FENCE**



**CAGE**



Image 3: A close-up view of the secure door lock mechanism.

#### 4.4 Ground Anchoring

For outdoor use, secure the kennel to the ground using the 24 ground stakes to prevent movement or tipping.

### 5. OPERATING INSTRUCTIONS

#### 5.1 Opening and Closing the Door

- To open: Disengage the lock mechanism and pull the door outwards.
- To close: Push the door shut and engage the lock mechanism to secure it.

#### 5.2 Removable Roof

The roof cover can be easily removed or reattached depending on weather conditions or if the kennel is used indoors.

### 5.3 Versatile Configuration

The modular design allows for various configurations. Panels can be rearranged to create different shapes or sizes to suit your pet's needs or available space.



Image 4: The kennel panels can be configured into various shapes, such as a fence or a cage.

### 6. MAINTENANCE

- **Cleaning:** Regularly clean the metal panels and roof cover with mild soap and water. Rinse thoroughly and allow to air dry. Avoid harsh chemicals that could damage the materials or harm your pet.
- **Inspection:** Periodically check all bolts, nuts, and fasteners to ensure they are tight. Inspect the metal frame for rust or damage, and the roof cover for tears or excessive wear.
- **Storage:** If storing the kennel for an extended period, disassemble it, clean all parts, and store them in a dry place to prevent rust and prolong product life.

## 7. TROUBLESHOOTING

- **Kennel is unstable:** Ensure all bolts are tightened. Verify the kennel is on a flat surface. For outdoor use, ensure all ground stakes are fully inserted into the ground.
- **Door not closing/locking properly:** Check for any obstructions. Ensure the lock plates are correctly aligned and securely fastened.
- **Roof cover not staying in place:** Ensure all elastic rubber fasteners are properly attached and the cover is taut.
- **Rust appearing on metal parts:** While the frame is rustproof steel, prolonged exposure to moisture or damage to the coating can lead to rust. Clean affected areas and apply a rust-inhibiting paint if necessary.

## 8. SPECIFICATIONS

<b>Brand</b>	CAPHAUS
<b>Model Number</b>	PHHDO-BH9601
<b>Product Dimensions (L x W x H)</b>	94.5 x 47.2 x 71.7 inches (240 x 120 x 182 cm)
<b>Material</b>	Rustproof Steel (Frame), Waterproof and Anti-UV Fabric (Roof Cover)
<b>Mesh Size</b>	4.1" L x 1.8" W
<b>Door Dimensions (H x W)</b>	49" H x 17.5" W
<b>Number of Panels</b>	12
<b>Specific Uses</b>	Indoor, Outdoor
<b>Special Features</b>	Durable, Lockable, Removable Cover

## 9. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your product at the time of purchase. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact CAPHAUS customer support through the retailer where the product was purchased or visit the official CAPHAUS website for contact details.