

## CUBOT A10

# CUBOT A10 Smartphone User Manual

Model: A10

## 1. INTRODUCTION

---

This manual provides essential information for setting up, operating, and maintaining your CUBOT A10 smartphone. Please read it carefully to ensure optimal performance and longevity of your device.

## 2. WHAT'S IN THE BOX

---

Your CUBOT A10 package includes the following items:

- A10 Smartphone x 1
- Type-C Cable x 1
- Charger x 1
- User Manual x 1
- Protective Case x 1
- SIM Eject Pin x 1



Figure 2.1: Package Contents of the CUBOT A10 Smartphone.

## 3. SETUP GUIDE

### 3.1. Inserting SIM and TF Card

The CUBOT A10 supports either two 4G SIM cards or one SIM card along with a 1TB TF card for expanded storage. Use the provided SIM eject pin to open the SIM tray located on the side of the device. Carefully place your SIM card(s) and/or TF card into the designated slots, ensuring correct orientation. Close the tray securely.



Figure 3.1: SIM and TF Card Insertion.

### 3.2. Initial Power On and Charging

To power on your CUBOT A10, press and hold the power button until the CUBOT logo appears. For first-time use or if the battery is depleted, connect the device to the charger using the provided Type-C cable. The phone features a large 5100mAh battery, providing extended usage time.

# GroBes 5100mAh-Akku



Figure 3.2: Charging the CUBOT A10.

## 4. OPERATING YOUR DEVICE

### 4.1. Android 14 System Overview

The CUBOT A10 runs on the latest Android 14 operating system, offering enhanced personalization options, improved privacy controls, and a smooth user experience. You can customize your desktop with app groupings, widgets, and intelligent floating windows. Privacy features allow you to manage data access and advertising preferences.

# Android 14 System

Sanfte neue Erfahrung, führend in smartem Leben




Figure 4.1: Android 14 User Interface.

## 4.2. Display Features

The device features a 6.56-inch HD+ display with a resolution of 720\*1612 pixels and a 90Hz refresh rate, providing a clear and responsive visual experience. The display supports 10-point touch for precise interaction.

# Display 6.56 Zoll 90Hz

Größerer Bildschirm, maximieren Sie Ihre Produktivität und Kreativität.



# 90Hz



**720\*1612**  
Auflösung



**10 Touch**  
Punkte



**20:9**  
Seitenverhältnis

Figure 4.2: CUBOT A10 Display Specifications.

### 4.3. Camera Functions

The CUBOT A10 is equipped with a 48MP main camera and a 16MP front camera. It offers various shooting modes including Panorama, Portrait, Pro, Night Mode, and Time-lapse photography, allowing for versatile photo capture.



Figure 4.3: CUBOT A10 Camera Features.

#### 4.4. Performance and Storage

The smartphone comes with 12GB RAM (4GB physical + 8GB extended) and 128GB internal storage, expandable up to 1TB via a TF card. This configuration supports smooth multitasking and ample space for applications, games, photos, and videos.

# 12GB RAM + 128GB ROM




Figure 4.4: RAM and ROM Configuration.

## 4.5. Additional Features

The CUBOT A10 includes features such as Face ID for secure unlocking, GPS+GLONASS+Galileo+BEIDOU navigation for accurate positioning, and OTG (On-The-Go) functionality, allowing the phone to act as a power bank or connect to USB devices.

## 5. MAINTENANCE

### 5.1. Battery Care

To maximize battery life, avoid exposing the device to extreme temperatures. Charge the battery regularly and avoid fully discharging it frequently. The 5100mAh battery is designed for long-lasting performance.

### 5.2. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Updates are typically found in the device's settings under 'System' or 'About Phone'.

## 5.3. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your smartphone. Avoid using harsh chemicals or abrasive materials that could damage the finish or screen. For stubborn smudges, a slightly damp cloth can be used, followed by a dry one.

## 6. TROUBLESHOOTING

### 6.1. Common Issues and Solutions

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Apps crashing or freezing:** Close background applications. If the issue persists, restart the device. Consider clearing the app's cache or reinstalling the app.
- **Poor network signal:** Check your SIM card insertion. Move to an area with better network coverage. Restart the device.
- **Battery draining quickly:** Reduce screen brightness, disable unnecessary features like GPS or Bluetooth when not in use, and close background apps.
- **Storage full:** Delete unnecessary files, photos, or videos. Move media to a TF card if installed. Uninstall unused applications.

## 7. SPECIFICATIONS

Feature	Detail
Brand	CUBOT
Model Name	A10
Operating System	Android 14
RAM Size	12 GB (4+8GB extended)
Storage Capacity	128 GB (expandable up to 1TB with TF card)
Display Size	6.56 inches
Display Resolution	720*1612
Refresh Rate	90 Hz
Main Camera	48 MP
Battery Capacity	5100 mAh
CPU Model	Octa Core Processor
Connectivity	Dual 4G SIM, WLAN 2.4G, Bluetooth 5.2, OTG, GPS, Face ID

## 8. PRODUCT VIDEOS

### 8.1. CUBOT A10 Product Overview

Your browser does not support the video tag.

This video provides a comprehensive overview of the CUBOT A10 smartphone's features and design.

## 8.2. CUBOT A10 Unboxing Video

Your browser does not support the video tag.

Watch this video to see the unboxing experience and initial setup of the CUBOT A10 smartphone.

## 9. WARRANTY AND SUPPORT

---

CUBOT offers a 2-year repair protection for customers who purchase their products. For any issues or inquiries, please contact customer service. 24-hour customer service is available to assist you with problem resolution.

© 2024 CUBOT. All rights reserved.