

[Manuals.plus](#) /

› [HOUROM](#) /

› Instruction Manual for HOUROM White 7-Drawer Dresser

HOUROM HRMDSR005WH

HOUROM White 7-Drawer Dresser Instruction Manual

Model: HRMDSR005WH

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep these instructions for future reference.

- **Anti-Tipping Device:** This dresser is equipped with an anti-tipping device to enhance stability and prevent accidental tipping. It is crucial to install this device securely to a wall as instructed to maximize the safety of your family, especially children.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the top surface (150 lbs) or individual drawers (40 lbs). Overloading can compromise stability and cause damage.
- **Children Safety:** Never allow children to climb on or play with the dresser. Keep heavy items in lower drawers to reduce the risk of tipping.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface. Uneven surfaces can affect stability.



Figure 1: Anti-Toppling Device. This image illustrates the importance of installing the anti-toppling device. It shows a close-up of the device and diagrams comparing a dresser with and without the device, highlighting the risk of tipping if not secured.

2. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present. Each component is labeled for easy identification.

Component Type	Description
Panels	Top panel, side panels, back panel, drawer panels (front, back, sides, bottom)
Drawers	Seven (7) complete drawer sets
Hardware	Screws, dowels, cams, drawer slides, metal handles, anti-tipping kit
Tools	Assembly tools (e.g., Allen wrench) may be included or required (screwdriver not included)

If any parts are missing or damaged, please contact HOUROM customer support immediately for assistance.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this dresser. Follow the detailed, step-by-step instructions provided in the included assembly manual. Each sheet part is labeled with a number to simplify the process.

1. **Unpack:** Carefully unpack all components from the shipping packaging. The packaging includes thicker foam board for product protection.
2. **Identify Parts:** Lay out all labeled parts and hardware. Refer to the parts list in your assembly manual to ensure everything is accounted for.
3. **Assemble Frame:** Begin by assembling the main frame of the dresser according to the numbered steps. Ensure all connections are secure.
4. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and to the drawer sides as indicated in the instructions.
5. **Assemble Drawers:** Construct each of the seven drawers. Attach the metal handles to the drawer fronts.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots on the dresser frame.
7. **Attach Anti-Tipping Device:** Securely attach the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.




Figure 2: Product Dimensions and Capacities. This diagram provides key measurements for the dresser (15.7"D x 47.2"W x 31.5"H) and its drawers, along with their respective weight limits, aiding in proper placement and usage planning.

4. USAGE AND OPERATION

The HOUROM 7-Drawer Dresser is designed for organized storage in various rooms. Its smooth-gliding drawers and ample space make it highly functional.

- **Drawer Functionality:** The metal handles allow for smooth opening and closing of the drawers. Avoid forcing drawers if they feel stuck; check for obstructions.
- **Storage Capacity:** Utilize the seven deep drawers to store clothing, linens, accessories, or other household items. The wide design provides significant storage volume.
- **Versatile Placement:** This dresser is suitable for bedrooms, living rooms, hallways, or entryways, enhancing the aesthetic and providing practical storage.



Figure 3: Ample Storage Space. This image highlights the spaciousness of the dresser's drawers, demonstrating its capacity for organizing various items.

5. MAINTENANCE

Proper care will ensure the longevity and appearance of your HOUROM dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** The tabletop features a waterproof design. In case of spills, wipe them immediately with a dry cloth to prevent potential damage or staining.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.



Figure 4: Waterproof Tabletop. This image highlights the waterproof quality of the dresser's top surface, indicating ease of cleaning for minor spills.

6. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions. For persistent problems, please contact customer support.

Problem	Possible Cause	Solution
Dresser wobbles/unstable	Uneven floor; loose fasteners; anti-tipping device not installed	Ensure dresser is on a level surface. Tighten all assembly fasteners. Install the anti-tipping device securely to a wall.
Drawers do not slide smoothly	Drawer slides misaligned; obstruction in drawer; overloaded drawer	Check that drawer slides are correctly installed and aligned. Remove any items obstructing the drawer. Reduce the weight in the drawer.
Missing or damaged parts upon delivery	Shipping error or damage	Do not proceed with assembly. Contact HOUROM customer support immediately with your order details.

7. SPECIFICATIONS

Feature	Detail
Brand	HOUROM
Model Name	HRMDSR005WH
Product Dimensions	15.7"D x 47.2"W x 31.5"H
Color	White
Furniture Finish	White
Mounting Type	Floor Mount
Room Type	Bedroom, Living Room, Nursery
Special Feature	7 Drawer Dresser

Feature	Detail
Item Weight	85.8 Pounds
Assembly Required	Yes
Number of Pieces	1
UPC	763271468022

8. WARRANTY AND SUPPORT

HOUROM stands behind the quality of its products. Your dresser comes with a limited warranty.

- **Warranty:** This product is covered by a Limited Warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions.
- **Returns:** Enjoy a 30-day easy return policy. For details, please refer to your purchase platform's return guidelines.
- **Customer Support:** If you have any questions, concerns, or require assistance with assembly or product issues, please contact HOUROM customer support. We are committed to providing a satisfactory solution as soon as possible.
- **Contact Information:** Refer to your purchase receipt or the HOUROM brand store on Amazon for the most current customer service contact details.

© 2025 HOUROM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D83L67QC>

More documents and user manuals: <https://manuals.plus/>