



Manuals.plus /

› WINGBO /

› WINGBO 48 Inch Flush Mount DC Ceiling Fan Instruction Manual (Model SYCF4802)

WINGBO SYCF4802

WINGBO 48 Inch Flush Mount DC Ceiling Fan Instruction Manual

Model: SYCF4802

Welcome to your new WINGBO 48 Inch Flush Mount DC Ceiling Fan. This manual provides detailed instructions for safe installation, operation, and maintenance of your fan. Please read thoroughly before beginning installation or use.

IMPORTANT SAFETY INSTRUCTIONS

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not bend blade holders during installation, balancing, or cleaning.
- Keep hands clear of rotating fan blades.

SETUP AND INSTALLATION GUIDE

Follow these steps for proper installation of your WINGBO ceiling fan.

Step 1: Install Fan Mounting Bracket

Secure the fan mounting bracket to the ceiling outlet box. Ensure it is firmly attached and can support the fan's weight.




Image: A person using a screwdriver to secure the fan mounting bracket to the ceiling. This is the first step in the installation process.

Step 2: Hang the Motor and Connect Wires

Carefully hang the fan motor assembly onto the mounting bracket. Connect the electrical wires according to the color coding: Yellow (receiver) to Yellow (fan), Red (receiver) to Red (fan), Grey (receiver) to Grey (fan), Black (receiver) to Hot (ceiling), and White (receiver) to Neutral (ceiling). Ensure all connections are secure with wire nuts.

Your browser does not support the video tag.

Video: This video demonstrates the step-by-step installation process of the WINGBO Flush Mount Wood Ceiling Fan, including hanging the motor and connecting the electrical wires. It shows detailed views of each connection.

Step 3: Attach the Canopy

Slide the canopy up and secure it to cover the wiring and mounting bracket.

Dimension



Mounting options



FLUSH MOUNT



Ideal for room
Up to 12' x 14'

Image: A person attaching the gray canopy to the ceiling fan motor, covering the internal wiring and mounting bracket.

Step 4: Attach Blades

Secure each of the four carved wood blades to the motor housing using the provided screws. Ensure they are tightly fastened.



Premium Quality Blades

The fan blades are made of a high-quality solid natural wood that makes them highly durable and efficient

Image: A close-up of a person attaching one of the carved wood blades to the fan motor using a screwdriver.

Step 5: Install the Bottom Cover

Install the decorative bottom cover to complete the fan assembly.



Image: A person installing the circular bottom cover onto the center of the fan motor, beneath the blades.

OPERATING YOUR CEILING FAN

Your WINGBO ceiling fan is controlled by the included handheld remote.

Remote Control Functions



Image: A diagram showing the remote control with labels for Fan Control (6 speeds), Follow/Reverse, and Nature Mode buttons.

- **Fan Control:** Adjust fan speed from 1 (lowest) to 6 (highest).
- **Follow/Reverse:** Changes the direction of blade rotation for summer or winter mode.
- **Nature Mode:** Simulates natural breezes by varying fan speed.

Summer and Winter Modes

The fan features a reversible motor for year-round comfort.



Image: A visual representation of the fan's reversible function, showing downward airflow for summer and upward airflow for winter.

- **Summer Mode (Forward Direction):** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter Mode (Reverse Direction):** Blades rotate clockwise, drawing cool air upwards to circulate warm air trapped near the ceiling.

Timer Function

Set a timer for the fan to automatically turn off after a specified duration (1, 2, 4, or 8 hours).



SET A TIMER

Set a timer (1-8 hours) to turn off the fan automatically




Image: A remote control displaying timer options (1H, 2H, 4H, 8H) for automatic fan shutdown.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft brush or lint-free cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or water.
- **Blade Inspection:** Periodically check blade attachments for tightness. Loose blades can cause noise and wobble.
- **Motor Lubrication:** The DC motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Fan does not start	Loose wire connections, no power, remote not paired.	Check circuit breaker. Ensure all wire connections are secure. Pair the remote control with the fan.
Fan makes noise	Loose screws, unbalanced blades, motor issue.	Tighten all screws on the motor housing and blade attachments. Check for any obstructions. Ensure blades are balanced. If noise persists, contact customer support.
Remote control not working	Dead batteries, remote not paired, interference.	Replace remote batteries. Re-pair the remote with the fan. Ensure no strong signal interference is present.
Fan wobbles	Loose blades, uneven blade weight, improper mounting.	Ensure all blade screws are tight. Use the included balancing kit to balance the blades if necessary. Verify the mounting bracket is securely installed.

PRODUCT SPECIFICATIONS

- **Model Name:** 48 Inch Flush Mount (SYCF4802)
- **Brand:** WINGBO
- **Color:** Black and Walnut
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** DC
- **Product Dimensions:** 48"D x 48"W x 11"H
- **Number of Blades:** 4
- **Blade Length:** 48 Inches
- **Speed Settings:** 6 RPM
- **Switch Type:** Remote Control
- **Motor Type:** DC motor
- **Installation Type:** Flush Mount
- **Noise Level:** 45 Decibels
- **Wattage:** 45 watts
- **Indoor/Outdoor Usage:** Indoor, Outdoor (Covered)
- **Recommended Room Size:** Up to 12' x 14'
- **Certification:** ETL Listed

WARRANTY AND CUSTOMER SUPPORT

For warranty information or technical assistance, please refer to the warranty card included in your product packaging or contact WINGBO customer support directly. Keep your purchase receipt for warranty claims. You can also visit the official WINGBO store for more information: [WINGBO Store on Amazon](#)

