

[Manuals.plus](#) /

> [GWY](#) /

> Air Fryer Rubber Feet for Cuisinart 6QT AIR-200 Air Fryer Oven, 4 PCS Silicone Tabs Air Fryer Rubber Bumper Replacement Parts Tabs
Tips Accessories

GWY AIR-200

GWY Air Fryer Rubber Feet User Manual

Model: Compatible with Cuisinart AIR-200 6QT Air Fryer Oven

1. PRODUCT OVERVIEW

The GWY Air Fryer Rubber Feet are designed as replacement accessories for your air fryer grill pans. Made from high-quality, food-grade silicone, these non-slip and scratch-resistant tabs protect the inner coating of your air fryer from damage caused by metal-on-metal contact. They are an essential component for maintaining the longevity and performance of your air fryer's cooking surface.



Image 1.1: Overview of the GWY Air Fryer Rubber Feet alongside a compatible air fryer grill pan, demonstrating their intended use.

2. KEY FEATURES

- **Food-Grade Silicone:** Manufactured from high-quality, non-toxic, and odorless silicone, meeting FDA standards for safe cooking.
- **High Temperature Resistant:** Capable of withstanding temperatures up to 480°F (250°C), ensuring durability during air frying.
- **Anti-Scratch Protection:** Prevents direct contact between the metal grill pan and the air fryer basket, safeguarding the non-stick coating from scratches and wear.
- **Non-Slip Design:** Provides stability for the grill pan within the air fryer.
- **Easy to Install and Remove:** Designed for simple insertion and removal, facilitating cleaning and replacement.

- **Durable and Elastic:** Sturdy construction ensures long-term usage without tearing.




Image 2.1: Visual representation of the key features, including high temperature resistance, non-toxic material, sturdiness, and ease of cleaning.

3. COMPATIBILITY AND PACKAGE CONTENTS

3.1 Compatibility

These rubber feet are specifically designed for compatibility with the **Cuisinart AIR-200 6QT Air Fryer Oven** grill pan. They may also fit other air fryer grill pans with similar dimensions and tab slot designs. Please verify the dimensions of your original rubber tips before purchasing to ensure proper fit.

3.2 Package Contents

Each package includes:

- 4 x GWY Air Fryer Rubber Bumper Replacement Parts

PRODUCT DIMENSIONS

Compatible with
Cuisinart 6-Qt Basket Stainless Steel Air Fryer




Image 3.1: Illustration of the product dimensions (1.1 inches by 0.7 inches) and confirmation of a 4-piece pack.

4. INSTALLATION

Installing the GWY Air Fryer Rubber Feet is a straightforward process:

1. Ensure your air fryer grill pan is clean and cool before installation.
2. Locate the small holes or slots on the underside of your air fryer grill pan where the original rubber tips were or where new ones are intended to be placed.
3. Align the stem of the GWY rubber foot with the corresponding hole on the grill pan.
4. Gently but firmly push the rubber foot into the hole until it is securely seated. You may need to apply slight pressure to ensure it clicks into place.
5. Repeat for all four corners or designated slots on your grill pan.



Image 4.1: A visual guide demonstrating the simple process of inserting the rubber feet into the grill pan's designated slots.

5. OPERATING AND USAGE

Once installed, the GWY Air Fryer Rubber Feet function automatically to protect your appliance. They serve two primary purposes:

- **Coating Protection:** When the grill pan is placed into or removed from the air fryer basket, the silicone feet act as a buffer, preventing the metal surfaces from rubbing against each other. This significantly reduces the risk of scratches and damage to the air fryer's non-stick coating.
- **Stability:** The non-slip nature of the silicone helps to keep the grill pan stable within the air fryer basket during cooking and handling.

PROTECTING THE AIR FRYER COATING

SILICONE PIECES



Effectively protecting the inner coating of the air fryer from scratching

VS

NO SILICONE PIECES



Friction between the pan and the air fryer caused damage to the air fryer coating

Image 5.1: A comparative image illustrating how the silicone feet protect the air fryer coating, contrasting it with potential damage without them.



Image 5.2: The air fryer grill plate with installed silicone feet, shown in a typical usage scenario with food.

6. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your GWY Air Fryer Rubber Feet:

- **Cleaning:** The silicone feet are easy to clean. They can be washed by hand with warm soapy water or placed in the dishwasher. Ensure they are completely dry before re-installing.
- **Regular Inspection:** Periodically inspect the rubber feet for any signs of wear, tear, or damage. While durable, silicone can degrade over time with repeated exposure to high temperatures and cleaning cycles.
- **Replacement Recommendation:** For optimal performance and continued protection of your air fryer's coating, it is recommended to replace these protective plate rack feet every 6 months, or sooner if visible wear is observed.

7. IMPORTANT NOTES AND SAFETY WARNINGS

- **Size Verification:** Always measure the size of your original air fryer rubber tips or the slots on your grill pan before

ordering to ensure these replacement parts will fit correctly.

- **Choking Hazard:** These small parts should be kept away from children to avoid the risk of accidental swallowing.
- **Manual Measurement:** Please note that the size is measured manually, and there may be a slight deviation of 1-3mm.
- **Temperature Resistance:** While resistant to high temperatures, avoid direct exposure to open flames or extreme heat sources beyond the specified operating temperature.



Image 7.1: Visual representation highlighting the high temperature resistance of the silicone feet, up to 430°F/221°C.

8. SPECIFICATIONS

Material	Food-Grade Silicone
Color	Black

Size (L x W x H)	1.1 x 0.7 x 0.3 inches (approximately)
Temperature Resistance	Up to 480°F (250°C)
Package Quantity	4 Pieces
Compatible Model	Cuisinart AIR-200 6QT Air Fryer Oven (and others with matching dimensions)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question