

[manuals.plus](#) /

› [Xgody](#) /

› [Xgody S200 Flip Phone User Manual](#)

Xgody S200

Xgody S200 Flip Phone User Manual

Model: S200

1. INTRODUCTION

Welcome to the user manual for your Xgody S200 Flip Phone. This device is designed for ease of use, featuring large buttons, a clear 2.4-inch display, and essential functions tailored for straightforward communication. Please read this manual carefully to understand how to operate your phone safely and effectively.

The Xgody S200 supports dual SIM cards and offers expandable storage via an SD card. It includes a 1300mAh battery and a Type-C charging port for convenience.



Image 1.1: The Xgody S200 flip phone is designed for easy communication, connecting users with family and friends.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Xgody S200 Flip Phone
- Battery (pre-installed or separate)
- USB Type-C Charging Cable
- Phone Case
- Screen Protector
- User Manual (this document)

If any items are missing or damaged, please contact customer support.

3. DEVICE OVERVIEW

The Xgody S200 features a classic flip design with a clear display and large, easy-to-press buttons.



Image 3.1: Front and back view of the Xgody S200 flip phone, highlighting its design and large keypad.

Key Features:

- **Large Buttons:** For easy dialing and navigation.
- **2.4-inch Color Display:** Clear and easy to read.
- **Dual SIM Support:** Manage two phone numbers simultaneously.
- **SD Card Expansion:** For additional storage.
- **1300mAh Battery:** Long standby and talk time.
- **Type-C Charging Port:** Modern and convenient charging.

- **SOS Emergency Button:** For quick access to emergency contacts.
- **Flashlight:** Built-in for convenience.
- **FM Radio & Bluetooth:** For entertainment and connectivity.



Image 3.2: Visual representation of key features including dual SIM, speed dial, foldable design, and 2.4-inch HD display.

4. SETUP

4.1. Inserting SIM Card(s) and SD Card

1. Power off the phone and open the back cover.
2. If the battery is installed, remove it carefully.
3. Locate the SIM card slot(s) and the SD card slot.
4. Insert your SIM card(s) into the designated slots with the gold contacts facing down. The phone supports two SIM cards.
5. If desired, insert a microSD card into the SD card slot for additional storage.

6. Reinsert the battery and close the back cover.

4.2. Battery Installation and Charging

The Xgody S200 comes with a 1300mAh battery. For optimal performance, fully charge the phone before first use.

1. Connect the USB Type-C charging cable to the charging port on the phone.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator will appear on the screen. A full charge typically takes a few hours.



Image 4.1: The phone's 1300mAh battery and external ports, including the Type-C charging port, 3.5mm headphone port, and flashlight.

4.3. Powering On/Off

- **To Power On:** Press and hold the **Power/End Call** button until the screen lights up.
- **To Power Off:** Press and hold the **Power/End Call** button until the power off options appear, then select "Power Off".

5. OPERATING INSTRUCTIONS

5.1. Making and Receiving Calls

- **To Make a Call:**

1. Enter the phone number using the keypad.
2. Press the **Call/Send** button to initiate the call.

- **To Receive a Call:**

1. When the phone rings, press the **Call/Send** button to answer.
2. To end a call, press the **Power/End Call** button.

- **Adjusting Volume:** Use the dedicated volume buttons on the side of the phone during a call.




Image 5.1: The Xgody S200 offers loud and clear audio for conversations, making it easier for users to hear.

5.2. Sending and Receiving SMS Messages

- **To Send an SMS:**

1. Navigate to the "Messages" menu.
2. Select "New Message" or "Write Message".
3. Enter the recipient's number and type your message.
4. Press the "Send" option.

- **To Read an SMS:**

1. When a new message arrives, a notification will appear.
2. Navigate to the "Messages" menu and select "Inbox" to view your messages.

5.3. SOS Emergency Calls

The SOS feature allows you to quickly contact pre-set emergency numbers in critical situations.

1. **Setting SOS Numbers:**

- Go to "Settings" > "SOS Settings".
- Add up to 5 emergency contact numbers.

2. **Activating SOS:**

- In an emergency, press and hold the dedicated **SOS button** (usually on the back or side of the phone) for a few seconds.
- The phone will automatically dial the pre-set emergency numbers in sequence until one is answered. It will also send an emergency SMS to these contacts.

SOS Emergency Calls

Support 5 Family Numbers
--Guarantee The Safety of The Elderly




Image 5.2: The SOS emergency call function allows users to quickly contact up to five pre-set family members or emergency services.

5.4. Flashlight

The phone includes a built-in flashlight for convenience.

- **To Turn On/Off:** Press and hold the dedicated **Flashlight button** (often a side button or a specific key on the keypad) for 3 seconds.



Press for 3 seconds to turn on the light immediately



Image 5.3: Activating the flashlight by pressing a button for 3 seconds, providing illumination in dark environments.

5.5. FM Radio

Enjoy listening to FM radio stations without needing an internet connection.

- Navigate to the "FM Radio" application from the main menu.
- You may need to connect wired headphones (not included) as they often act as an antenna.
- Use the navigation keys to scan for stations or tune manually.

5.6. Bluetooth

Connect your phone to Bluetooth headsets or other compatible devices.

- Go to "Settings" > "Bluetooth".
- Turn Bluetooth "On".
- Search for available devices and select the device you wish to pair with.
- Follow the on-screen prompts to complete the pairing process.

5.7. Dual SIM Management

If you have two SIM cards installed, you can manage them through the phone's settings.

- Go to "Settings" > "Dual SIM Settings" or "Network Settings".
- Here you can choose which SIM card to use for calls, messages, or data (if applicable).

6. MAINTENANCE

6.1. Cleaning Your Phone

- Use a soft, lint-free cloth to wipe the screen and body of the phone.
- Avoid using harsh chemicals, cleaning sprays, or abrasive materials.
- Keep the charging port and speaker grilles free from dust and debris.

6.2. Battery Care

- Avoid exposing the battery to extreme temperatures (hot or cold).
- Do not puncture, disassemble, or modify the battery.
- If the battery appears swollen or damaged, discontinue use and replace it with an authorized Xgody battery.
- For long-term storage, charge the battery to about 50% and store the phone in a cool, dry place.

6.3. Storage and Handling

- Store the phone in a dry place away from direct sunlight and moisture.
- Avoid dropping the phone or subjecting it to strong impacts. The flip design offers some screen protection.
- Keep the phone away from magnetic fields.

7. TROUBLESHOOTING

If you encounter issues with your Xgody S200, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone does not power on.	Low battery; faulty battery; software issue.	Charge the phone for at least 30 minutes. Ensure the battery is correctly installed. If problem persists, contact support.
Cannot make or receive calls.	No SIM card; SIM card not properly inserted; no network signal; SIM card not activated.	Ensure SIM card is inserted correctly. Check network signal strength. Contact your service provider to verify SIM activation.
Poor call quality/low volume.	Weak network signal; speaker/microphone obstruction; volume settings.	Move to an area with better signal. Clean speaker/microphone openings. Adjust call volume using side buttons.
Battery drains quickly.	Excessive usage; background apps; old battery.	Reduce screen brightness. Close unnecessary applications. If battery is old, consider replacement.
Flashlight not working.	Not activated correctly; software glitch.	Ensure you press and hold the flashlight button for 3 seconds. Restart the phone.

For issues not listed here, please refer to the official Xgody support website or contact customer service.

8. SPECIFICATIONS

Feature	Detail
Model	Xgody S200
Operating System	Nucleus OS
Display	2.4 Inches, 480 x 800 Resolution
Network Technology	2G GSM (Unlocked for All Carriers)
SIM Card Support	Dual SIM
Connectivity	Bluetooth
Battery Capacity	1300mAh
Talk Time	Up to 6 Hours
Standby Time	Up to 200 Hours
Charging Port	Type-C
Special Features	Large Buttons, SOS Function, Flashlight, FM Radio
Dimensions	19.5 x 10.1 x 5.6 cm (Package)
Item Weight	280 g
Color	Gold

9. WARRANTY AND SUPPORT

The Xgody S200 Flip Phone comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or warranty claims, please contact Xgody customer service through their official website or the contact information provided with your purchase. Keep your purchase receipt as proof of purchase.

Xgody Official Website: www.xgody.com (This is a placeholder link, please verify the actual official website for Xgody support.)

 X31 Mobile Phone User Manual	<p><u>XGODY X31 Mobile Phone User Manual</u></p> <p>User manual for the XGODY X31 mobile phone, covering product overview, getting started, settings, and troubleshooting.</p>
 X60 Mobile Phone User Manual	<p><u>X60 Mobile Phone User Manual - Getting Started and Troubleshooting</u></p> <p>Comprehensive user manual for the X60 Mobile Phone, covering setup, basic operations, troubleshooting common issues, and FCC compliance information. Learn how to install SIM cards, power on/off, manage battery, take screenshots, and resolve connectivity or performance problems.</p>
 X32 Mobile Phone User Manual	<p><u>XGODY X32 Mobile Phone User Manual</u></p> <p>Comprehensive user guide for the XGODY X32 smartphone, covering product overview, setup, settings, and troubleshooting. Available in English, German, Spanish, French, and Italian.</p>
 <p>Manufacturer: SHENZHEN XGODY CO., LTD. Production Site: No. 100, Shuangqiao Industrial Park, Shuangqiao, Shenzhen, China Address: 100, Shuangqiao Industrial Park, Shuangqiao, Shenzhen, China Zip Code: 518057 Country: China Country Website: www.xgody.com</p>   	<p><u>XGODY X36 Mobile Phone User Manual</u></p> <p>Comprehensive user manual for the XGODY X36 mobile phone, covering setup, features, and troubleshooting. Includes manufacturer details and support links.</p>
 ANDROID TABLET QUICK START GUIDE Model: N01	<p><u>XGODY N01 Android Tablet Quick Start Guide</u></p> <p>Get started with your XGODY N01 Android Tablet. This guide provides essential setup, operational, and connectivity information for users.</p>



[XGODY Tablet User Manual - Setup, Features, and Troubleshooting Guide](#)

Comprehensive user guide for the XGODY Tablet, covering setup, basic operations, connectivity, app management, troubleshooting, and technical specifications. Learn how to maximize your XGODY tablet experience.


Documents - Xgody – S200



EU Declaration of Conformity for XGODY Cell Phones

This EU Declaration of Conformity certifies that XGODY cell phone models X17, X18, S21, S22, S23, Mate 60, Mate 70, A54, X31, S200, and Y13 Pro comply with the RED Directive 2014/53/EU and relevant harmonized standards for safety and performance.

lang:en score:20 filesize: 938.33 K page_count: 1 document date: 2024-07-04



Elenco di Compatibilità Periferiche TIM I love games

Scopri l'elenco completo dei dispositivi e periferiche compatibili con i servizi TIM I love games, inclusi smartphone, tablet e altri modelli di Acer, Alcatel, e molti altri marchi. lang:it score:9 filesize: 5.79 M page_count: 415 document date: 2017-07-28