

[Manuals.plus](#) /

> [BESNOOW](#) /

> BESNOOW I53 Wireless Bluetooth Earbuds User Manual

## BESNOOW I53

# BESNOOW I53 Wireless Bluetooth Earbuds User Manual

Model: I53 | Brand: BESNOOW

## INTRODUCTION

This manual provides instructions for the BESNOOW I53 Wireless Bluetooth Earbuds. These earbuds feature Bluetooth 5.3 connectivity, up to 40 hours of playback with the charging case, ENC noise cancelling, and IP7 waterproofing. Please read this manual thoroughly before using the product to ensure proper operation and maintenance.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- 2 x Bluetooth Earbuds
- 1 x Charging Case
- 1 x Instruction Manual
- Eartips (S/M/L)
- 1 x USB-C Charging Cable



Image: Contents of the BESNOOW I53 Earbuds package, including earbuds, charging case, USB-C cable, and different sized eartips.

## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED display on the charging case will indicate the battery level. A full charge is indicated by "100".



Image: The BESNOOW I53 earbuds resting in their charging case, which features an LED display showing the current battery percentage.

## 2. Pairing with a Device

The earbuds support automatic pairing with the last connected device. For initial pairing:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "I53" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the earbuds will automatically pair with this device when removed from the case.



Image: A smartphone screen displaying Bluetooth settings, with the "I53" earbuds shown as connected, illustrating the pairing process.

### **3. Wearing the Earbuds**

For optimal sound quality and comfort, choose the correct eartip size and adjust the earbuds properly.

1. Select the eartips (S, M, L) that provide the best seal and comfort for your ears.
2. Insert the earbud into your ear canal.
3. Gently twist and adjust the earbud until it feels secure and comfortable, following the natural contour of your ear.

# Wear Them All Day Without Worries



Ergonomic

Comfortable earbud design for a perfect fit

Image: A visual guide demonstrating the ergonomic design of the earbuds and how to achieve a comfortable and secure fit in the ear.

## OPERATING INSTRUCTIONS

### Touch Controls

The BESNOOW I53 earbuds feature smart touch controls for managing music playback, calls, and voice assistant activation.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Song		Double Tap
Previous Song	Double Tap	
Volume Up		Long Press (1s)

Action	Left Earbud	Right Earbud
Volume Down	Long Press (1s)	
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant (Siri)	Triple Tap	Triple Tap
Power On	Long Press (5s)	Long Press (5s)




Image: A visual representation of the touch control gestures and their corresponding functions for the BESNOOW I53 earbuds.

## MAINTENANCE

### Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove any earwax or debris from the eartips and speaker mesh using a small, soft brush or cotton swab.
- Do not use abrasive cleaners, alcohol, or chemical sprays.

### Water Resistance (IP7)

The earbuds are rated IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for use during workouts, in light rain, or against accidental splashes.

- Do not intentionally submerge the earbuds for extended periods or in depths greater than 1 meter.
- The charging case is not waterproof. Keep it dry.
- Ensure earbuds are completely dry before placing them back into the charging case to prevent damage.

# IP7 Waterproof & Dustproof

Protects against dust and perspiration and meets the needs of many life situations



Light Rain



Accident Splashes



Sweat



Image: The earbuds and charging case shown with water droplets, illustrating their IP7 waterproof and dustproof capabilities, suitable for various life situations.

## TROUBLESHOOTING

Problem	Solution
<b>Earbuds not pairing</b>	<ul style="list-style-type: none"><li>◦ Ensure earbuds are charged.</li><li>◦ Turn off and on Bluetooth on your device.</li><li>◦ Forget "I53" from your device's Bluetooth list and re-pair.</li><li>◦ Place earbuds back in the case, close, then reopen to reset pairing mode.</li></ul>

Problem	Solution
<b>No sound from one earbud</b>	<ul style="list-style-type: none"> <li>◦ Ensure both earbuds are charged.</li> <li>◦ Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise re-pair).</li> <li>◦ Clean the speaker mesh for any blockages.</li> </ul>
<b>Low volume</b>	<ul style="list-style-type: none"> <li>◦ Increase volume on both your device and the earbuds (using touch controls).</li> <li>◦ Ensure eartips provide a good seal in your ear.</li> <li>◦ Clean the speaker mesh.</li> </ul>
<b>Charging issues</b>	<ul style="list-style-type: none"> <li>◦ Ensure the USB-C cable is properly connected to both the case and power source.</li> <li>◦ Try a different USB-C cable or power adapter.</li> <li>◦ Clean the charging contacts on both the earbuds and inside the case.</li> </ul>

## SPECIFICATIONS

Feature	Detail
<b>Model Number</b>	I53
<b>Connectivity Technology</b>	Wireless (Bluetooth)
<b>Bluetooth Version</b>	5.3
<b>Audio Driver Type</b>	13mm Vibrating Diaphragm Speaker Driver
<b>Noise Control Features</b>	ENC Noise Cancellation
<b>Battery Life (Earbuds)</b>	Up to 8 hours per charge
<b>Total Battery Life (with Charging Case)</b>	Up to 40 hours
<b>Charging Port</b>	USB-C
<b>Water Resistance Rating</b>	IP7 Waterproof
<b>Control Method</b>	Touch
<b>Item Weight</b>	3.52 ounces (approx. 0.1 kg)
<b>Compatible Devices</b>	Smartphones (iOS, Android), Tablets, Laptops, Smart TVs, Cars

# All-Day Companionship Long Battery Life Of 40 Hours

Enjoy exceptional sound all day with up to 8 hours of continuous listening time and a total battery life of up to 40 hours when using the charging case

**8 Hrs**  
Playtime

**40 Hrs**  
Charging Case

**1.5 Hrs**  
Quickly Charged



Image: The BESNOOW I53 earbuds and charging case, emphasizing the long battery life of up to 40 hours with the case and 8 hours per earbud charge.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official BESNOOW website. Keep your proof of purchase for warranty claims.

**Online Support:** For frequently asked questions and further assistance, please visit the BESNOOW brand store on Amazon: [BESNOOW Store](#).

## PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: An official overview of the BESNOOW I53 Wireless Bluetooth Earbuds, showcasing key features and design.



© 2024 BESNOOW. All rights reserved.