

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RoyalCraft](#) /

› [RoyalCraft TV Stand for 65+ Inch TV: Farmhouse Entertainment Center, Light Grey \(Model ZTS013\) - Instruction Manual](#)

RoyalCraft ZTS013

RoyalCraft Farmhouse TV Stand

MODEL: ZTS013 - LIGHT GREY

INTRODUCTION

Thank you for choosing the RoyalCraft Farmhouse TV Stand, Model ZTS013. This entertainment center is designed to accommodate TVs 65 inches and larger, offering a blend of rustic charm and practical storage solutions. Featuring sliding barn doors and adjustable shelves, it provides versatile organization for your living space. Constructed from high-grade engineered wood, this stand is built for durability and stability. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.



Image: The RoyalCraft TV Stand (Model ZTS013) in a living room setting, demonstrating its capacity to hold a large television and integrate with home decor.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all hardware is securely tightened before use.
- Do not overload shelves or the top surface. The desktop has a weight capacity of 300 lbs.
- Use the included anti-tipping hardware to secure the TV stand to a wall, especially if children are present.
- Keep small parts and packaging materials away from children.
- Place the TV stand on a level, stable surface.

PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included assembly instructions for a detailed diagram and identification of each component.

- Top Panel

- Bottom Panel
- Side Panels (Left & Right)
- Back Panels
- Fixed Shelves
- Adjustable Shelves
- Sliding Barn Doors
- Door Handles
- Sliding Rail Hardware (Track, Rollers, Stops)
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Anti-Tipping Hardware

SETUP (ASSEMBLY INSTRUCTIONS)

Assembly is required for this TV stand. It is recommended to have two people for assembly. Please follow the step-by-step instructions provided in the packaging. A general overview of the process is as follows:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided diagrams.
2. **Assemble the Base:** Attach the side panels to the bottom panel using the specified hardware.
3. **Install Fixed Shelves and Dividers:** Secure any fixed shelves and vertical dividers according to the instructions.
4. **Attach Back Panels:** Fasten the back panels to the assembled frame.
5. **Install Top Panel:** Secure the top panel to complete the main structure.
6. **Assemble Sliding Doors:** Attach handles to the barn doors.
7. **Install Sliding Rail System:** Mount the sliding rail track above the main storage compartments. Attach the rollers to the top of the barn doors.
8. **Hang Doors:** Carefully hang the barn doors onto the sliding rail system. Adjust door stops as needed.
9. **Insert Adjustable Shelves:** Place adjustable shelves into the desired positions using the shelf pins.
10. **Secure Anti-Tipping Hardware:** Attach the anti-tipping hardware to the back of the TV stand and to a wall stud to prevent accidental tipping.

Video: An overview of the RoyalCraft Farmhouse TV Stand, demonstrating its features including the adjustable partition and sliding barn doors.

OPERATING INSTRUCTIONS

- **Sliding Barn Doors:** The barn doors slide smoothly along the top rail. You can position them to cover any of the storage compartments, allowing you to customize the display and hidden storage areas.
- **Adjustable Shelves:** The interior shelves are adjustable. To change their height, remove the shelf pins, reposition the shelf to the desired level, and reinsert the pins securely. Ensure the shelf is level before placing items on it.
- **Cable Management:** The back panel includes cutouts for cable management, allowing you to route

wires neatly from your electronic devices.

Ultra - Practical TV Cabinets



Sliding doors are space - saving. They don't need extra space to open like hinged doors, perfect for small areas like bedroom in apartment or compact office partitions. They can also flexibly choose the display area and storage area.

VS

5 open and large layers can be placed large Bluetooth speaker, game consoles, storage boxes, etc



Image: Detailed view of the TV stand's sliding doors and interior shelving, illustrating its versatile storage options.

MAINTENANCE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish. The surface is waterproof and easy to keep clean.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Sliding Mechanism:** Keep the sliding rail and rollers free of dust and debris to ensure smooth operation of the barn doors.
- **Environmental Conditions:** Avoid placing the TV stand in direct sunlight or near heat sources to prevent warping or discoloration.

Green Material, Sustainable Style

Formaldehyde Emission

P2 < P1 < E1 < E2



Wood Grain Finish

Natural wood aesthetics,
water resistant, sratch-resistant

P2 Graded Laminated Particleboard&MDF

Durable, warp-resistant,
improved solidity for years of
long-lasting use

Wood Grain Finish

Natural wood aesthetics,
water resistant,
sratch-resistant

Image: Cross-section view detailing the construction materials, including P2 Graded Laminated Particleboard & MDF with a water-resistant wood grain finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
TV Stand is wobbly	Loose hardware; Uneven floor	Check and tighten all screws. Adjust floor levelers if present, or place shims under the base.
Sliding doors stick or do not move smoothly	Debris in track; Loose rollers; Misaligned track	Clean the sliding track. Check that rollers are securely attached to the doors. Ensure the track is level and properly installed.
Shelves are not level	Shelf pins not inserted correctly; Damaged shelf pins	Ensure shelf pins are fully inserted into corresponding holes. Replace any bent or broken pins.

SPECIFICATIONS

Feature	Detail
Brand	RoyalCraft
Model Name	ZTS013
Color	Light Grey
Product Dimensions	16"D x 58"W x 34"H
Material	Engineered Wood (CARB P2 certified MDF)
Weight Limit (Desktop)	300 lbs
Special Features	Adjustable Shelf, Ample Storage, Anti-Tipping, Rust Resistant (metal parts), Sliding Barn Door
Mounting Type	Floor Mount
Number of Shelves	9 (total compartments, including open and behind doors)
Assembly Required	Yes
Item Weight	95.7 Pounds

Product Dimension



Image: Product dimensions and weight capacity for the RoyalCraft TV Stand.

WARRANTY

RoyalCraft products are designed for quality and durability. For specific warranty information regarding your TV stand, please refer to the warranty card included in your product packaging or contact RoyalCraft customer support directly. General policies often include coverage for manufacturing defects.

SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your RoyalCraft TV Stand, please do not hesitate to contact our professional support team. We are committed to ensuring your satisfaction.

Email: support@royalcraft.store

Our team is available to provide 24-hour after-sales service.