

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WANBO](#) /

› [WANBO DALI 1 Projector User Manual - 350 ANSI Lumen, 720p HD](#)

WANBO DALI 1

WANBO DALI 1 Projector User Manual

Model: DALI 1 (S9913100)

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your WANBO DALI 1 Projector. Please read this manual thoroughly before using the device and retain it for future reference. The WANBO DALI 1 is a portable projector designed for home cinema, gaming, and presentations, offering 720p HD resolution and 350 ANSI lumens brightness.

SAFETY INFORMATION

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Keep the projector away from water, moisture, and flammable materials.
- Use only the power adapter supplied with the device.
- Do not attempt to disassemble or repair the projector yourself. Contact qualified service personnel.
- Keep out of reach of children.

PRODUCT OVERVIEW

Familiarize yourself with the components of your WANBO DALI 1 Projector.



Figure 1: Front view of the WANBO DALI 1 Projector, showing the lens and front ventilation grille.



Figure 2: Rear view of the WANBO DALI 1 Projector, displaying the power input, USB port, HDMI port, and audio jack.

Package Contents:

- WANBO DALI 1 Projector
- Power Adapter
- Remote Control (requires 2 AAA batteries, included)
- User Manual (this document)

SETUP

1. Placement

Place the projector on a stable, flat surface. Ensure there is adequate space around the projector for ventilation. For optimal viewing, position the projector perpendicular to the projection surface. The projector features automatic obstacle avoidance and auto-focus for easier setup.

2. Power Connection

1. Connect the power adapter to the projector's power input port (refer to Figure 2).
2. Plug the power adapter into a suitable electrical outlet.

3. Initial Power On

Press the power button on the projector or the remote control to turn on the device. The projector will perform an automatic focus adjustment and obstacle avoidance scan upon startup.

4. Remote Control Setup

Insert the two AAA batteries (included) into the remote control, observing the correct polarity.

OPERATING

1. Navigation

The WANBO DALI 1 runs on Android 9.0. Use the remote control to navigate the on-screen interface. The directional buttons, OK button, and Back button are primary for navigation.

2. Connecting Devices

- **HDMI:** Connect an HDMI cable from your source device (e.g., laptop, game console) to the HDMI port on the projector (refer to Figure 2). Select the HDMI input from the projector's source menu.
- **USB:** Insert a USB drive into the USB port (refer to Figure 2) to play media files directly. Navigate to the file manager application on the projector to access content.
- **Bluetooth:** Pair Bluetooth audio devices (e.g., speakers, headphones) through the projector's Bluetooth settings menu.
- **Wi-Fi:** Connect the projector to your wireless network via the Wi-Fi settings. This enables access to online streaming apps and content.

3. Picture and Sound Settings

Access the settings menu to adjust picture parameters such as brightness, contrast, color, and aspect ratio. Sound settings allow for volume control and audio output selection.

4. App Installation

Utilize the pre-installed app store or other compatible methods to download and install additional applications for streaming, gaming, or productivity.

MAINTENANCE

1. Cleaning the Lens

Gently wipe the projector lens with a soft, lint-free cloth specifically designed for optical surfaces. Do not use abrasive cleaners or excessive force.

2. Cleaning the Casing

Wipe the exterior casing with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry wipe. Avoid using harsh chemicals.

3. Ventilation

Ensure the ventilation grilles are free from dust and obstructions. Periodically clean them with a soft brush or compressed air to maintain optimal airflow and prevent overheating.

4. Storage

When not in use for extended periods, store the projector in a cool, dry place, protected from dust and direct sunlight. It is recommended to use the original packaging or a protective case.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable disconnected, power outlet issue	Check power cable connection, try a different outlet.
No image	Input source not selected, cable issue, lens cap on	Select correct input source, check HDMI/USB cable, remove lens cap.
Blurry image	Out of focus, incorrect projection distance	Allow auto-focus to adjust, manually adjust focus if available, reposition projector.
No sound	Volume too low, incorrect audio output, external device muted	Increase volume, check audio output settings, unmute source device.
Remote control not working	Batteries low/dead, obstruction, not paired	Replace batteries, ensure clear line of sight, re-pair remote if necessary.

SPECIFICATIONS

Feature	Detail
Brand	WANBO
Model Name	Wanbo Dali 1 Projector
Model Number	S9913100
Resolution	1280 x 720 Pixels (HD 720p)

Feature	Detail
Brightness	350 ANSI Lumen
Contrast Ratio	1500:1
Aspect Ratio	16:9
Operating System	Android 9.0
Connectivity	Wi-Fi, Bluetooth, HDMI, USB
Special Features	Automatic Obstacle Avoidance, Auto-Focus, Portable, Lightweight
Dimensions	24 x 21 x 18 cm
Weight	1.7 Kilograms
Power Source	AC Power Adapter
Included Components	Projector, Power Adapter, Remote Control, User Manual

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official WANBO website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact WANBO customer service through their official channels.

Related Documents - DALI 1

	<p>Wanbo X5 Projector User Manual - Setup and Operation Guide Comprehensive user manual for the Wanbo X5 projector, covering setup, operation, maintenance, and safety precautions. Learn how to connect devices, adjust settings, and care for your projector.</p>
	<p>Wanbo T4 Projector: User Manual, Safety, and Setup Guide Comprehensive guide for the Wanbo T4 Projector, covering safety precautions, installation, operation, mobile screen mirroring, maintenance, technical specifications, and FCC compliance.</p>
	<p>Wanbo X5 Projector User Manual Comprehensive user manual for the Wanbo X5 projector, covering setup, operation, maintenance, safety, and connectivity features. Includes multi-language support.</p>

	<p><u>Wanbo Projector User Manual and Product Information</u></p> <p>Comprehensive guide for the Wanbo Projector, covering packing list, remote control functions, product specifications, usage instructions, troubleshooting, and warranty information. Includes details on product considerations, hazardous substance content, and FCC compliance.</p>
	<p><u>Wanbo X2 Max Projector User Manual: Setup, Features, and Safety Guide</u></p> <p>Comprehensive user manual for the Wanbo X2 Max projector. Learn about setup, operation, safety precautions, specifications, and troubleshooting. Get the most out of your Wanbo X2 Max.</p>
	<p><u>Wanbo Projector Mozart 1 Introduction Manual</u></p> <p>This introduction manual provides essential information for the Wanbo Projector Mozart 1, covering setup, safety guidelines, features, technical specifications, and connectivity options.</p>