

[Manuals.plus](#) /

› [Savoy House](#) /

› Savoy House 22-FD-445-89 Diana Fandelier Instruction Manual

Savoy House 22-FD-445-89

Savoy House 22-FD-445-89 Diana Fandelier Instruction Manual

Mid-Century Modern Chandelier Ceiling Fan with Remote and Light

[Overview](#) [Safety Information](#) [Package Contents](#) [Specifications](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Savoy House 22-FD-445-89 Diana Fandelier is a 24-inch mid-century modern chandelier ceiling fan designed for indoor use. It features a matte black finish with black blades and includes a remote control for convenient operation of both the fan and light functions. This unit requires four E26 base bulbs (not included) and is dimmable when using compatible dimmable bulbs.



Figure 1.1: Front view of the Savoy House Diana Fandelier in matte black.

Key Features:

- **Finish:** Matte Black with Black Blades
- **Dimensions:** 24 inches (W) x 11 inches (H) x 24 inches (L)
- **Bulbs:** Requires 4 x E26 Base Bulbs (max 8W each, not included). LED bulbs recommended for energy efficiency.
- **Control:** Remote Control included for fan and light operation.
- **Motor:** DC Motor for efficient and quiet performance.
- **Mounting:** Semi-flush mount installation. Includes 4-inch and 18-inch rods.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions.

- Read all instructions carefully before beginning installation.
- Consult a qualified electrician if you are unsure about wiring or installation procedures.
- Ensure the electrical supply is disconnected at the main circuit breaker before installation or servicing.

- All wiring must be in accordance with national and local electrical codes.
- The mounting structure must be capable of supporting the weight of the fan (approximately 20.7 lbs).
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of the fan blades during operation.
- This product is for indoor use only and is not water resistant.

3. PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before proceeding with installation.

- Fandelier Unit (with integrated fan and light fixture)
- Rods (1 x 4-inch, 1 x 18-inch)
- Remote Control
- Mounting Hardware (screws, wire nuts, etc. - specific items may vary)
- Instruction Manual (this document)

Note: E26 base bulbs are not included and must be purchased separately.

4. PRODUCT SPECIFICATIONS




Figure 4.1: EnergyGuide label for the Diana Fandelier.

Feature	Detail
Brand	Savoy House
Model Number	22-FD-445-89

Feature	Detail
Color	Matte Black
Material	Acrylic, Acrylonitrile Butadiene Styrene, Metal
Style	Mid-Century Modern
Dimensions (L x W x H)	24" x 24" x 11"
Item Weight	20.7 Pounds
Power Source	AC
Voltage	120 Volts (AC)
Light Source	LED (when using LED bulbs)
Number of Light Sources	4
Bulb Base	E26 Medium
Max Wattage per Bulb	8 watts
Brightness	3200 lumen (with recommended bulbs)
Control Method	Remote Control
Installation Type	Semi Flush Mount
Indoor/Outdoor Usage	Indoor Only
Required Assembly	Yes

5. SETUP AND INSTALLATION

Professional installation is recommended for ceiling fans. Ensure you have all necessary tools and safety equipment before beginning.

5.1 Pre-Installation Steps

- Turn Off Power:** Locate the circuit breaker for the room where you are installing the fan and turn off the power. Verify power is off using a voltage tester.
- Prepare Mounting Location:** Ensure the existing electrical box is securely mounted and rated for ceiling fan support. If not, install a fan-rated support box.
- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.

5.2 Mounting the Fan

- Attach Mounting Bracket:** Secure the mounting bracket to the electrical box using the screws provided.
- Assemble Downrod:** Choose the desired downrod (4-inch or 18-inch) and feed the electrical wires from the fan motor through it. Secure the downrod to the fan motor assembly.
- Hang Fan Assembly:** Carefully lift the fan assembly and hang it from the mounting bracket. This will

free your hands for wiring.

5.3 Wiring

7. **Connect Wires:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the detailed manual (not provided here). Typically, this involves connecting live, neutral, and ground wires using wire nuts.
8. **Secure Wiring:** Tuck all wires neatly into the electrical box.

5.4 Final Assembly

9. **Attach Canopy:** Slide the canopy up and secure it to the mounting bracket, covering the wiring.
10. **Install Light Kit:** Connect the light kit wiring to the fan's light kit wires. Secure the light kit to the fan housing.
11. **Install Bulbs:** Screw four E26 base bulbs (max 8W each) into the light sockets.
12. **Attach Shade:** Secure the acrylic shade to the light kit.



Figure 5.1: Angled view of the assembled Diana Fandelier.



Figure 5.2: Bottom view of the Diana Fandelier, highlighting the light and fan components.

Once installation is complete, restore power at the circuit breaker.

6. OPERATING INSTRUCTIONS

The Diana Fandelier is operated using the included remote control.

6.1 Remote Control Functions

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed Control:** Use the speed buttons (typically 1-6 or +/-) to adjust the fan speed.

- **Light ON/OFF:** Press the light button to turn the light on or off.
- **Light Dimming:** If using dimmable bulbs, press and hold the light button to cycle through brightness levels. Release when the desired brightness is reached.
- **Reverse Function:** Some remote controls include a reverse button to change the direction of the fan blades for seasonal use (downward airflow for cooling, upward for heat circulation). Refer to your specific remote's diagram.
- **Timer Function:** If available, use the timer buttons to set the fan to turn off automatically after a set period.

6.2 Initial Operation

1. Ensure batteries are correctly installed in the remote control.
2. Point the remote control towards the fan.
3. Press the desired function button (e.g., Fan ON, Light ON).

7. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your fandelier.

7.1 Cleaning

- **WARNING:** Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the exterior surfaces of the fan and light fixture.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- Periodically wipe the fan blades to prevent dust buildup, which can affect performance.

7.2 Bulb Replacement

- **WARNING:** Ensure power is off and bulbs are cool before attempting to replace them.
- Unscrew the old E26 base bulb.
- Screw in a new E26 base bulb (maximum 8W).
- Replace the shade securely.

8. TROUBLESHOOTING

If you encounter issues with your Diana Fandelier, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on	No power supply Loose wiring Remote control issues	Check circuit breaker. Ensure all wiring connections are secure. Replace remote batteries. Re-pair remote if necessary (refer to detailed remote manual).

Problem	Possible Cause	Solution
Light does not turn on	No power supply Bulb faulty or loose Loose wiring Remote control issues	Check circuit breaker. Ensure bulbs are screwed in tightly and are not burnt out. Verify wiring connections. Replace remote batteries.
Fan makes excessive noise	Loose screws Unbalanced blades Motor issue	Check and tighten all screws on the fan housing and blades. Ensure blades are properly balanced (balancing kit may be required). If noise persists, contact customer support.
Remote control not working	Dead batteries Out of range Not paired	Replace batteries. Ensure you are within effective range of the fan. Follow instructions to pair the remote with the fan.

If these solutions do not resolve the issue, please contact customer support.

9. WARRANTY AND SUPPORT

9.1 Manufacturer's Warranty

The Savoy House 22-FD-445-89 Diana Fandelier comes with a **1-year manufacturer's warranty from the date of purchase**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, misuse, abuse, or natural disasters.

9.2 Customer Support

For technical assistance, warranty claims, or replacement parts, please contact Savoy House customer service. Please have your model number (22-FD-445-89) and proof of purchase available when contacting support.

Savoy House Customer Service:

Website: www.savoyhouse.com (for contact information)

(Specific phone number or email not provided in product data, please refer to the official website or original packaging for direct contact details.)