

[Manuals.plus](#) /

> [Travelpro](#) /

> Travelpro VersaPack+ Large Checked Luggage 417246901 User Manual

## Travelpro 417246901

# Travelpro VersaPack+ Large Checked Luggage User Manual

Model: 417246901

## INTRODUCTION

This manual provides comprehensive instructions for the Travelpro VersaPack+ Lightweight Softside Expandable Checked Luggage. Designed for durability and organization, this luggage features advanced components to enhance your travel experience. Please read these instructions carefully to ensure proper use and maintenance of your product.

The VersaPack+ Large Check-in Expandable Spinner is engineered to meet checked luggage size restrictions for most airlines. It offers ultimate packing versatility with features that maximize capacity and keep contents organized and secured. Key features include two removable large packing cubes, built-in interior pockets, a removable laundry bag, and a built-in wet pocket for separating items.





Image: Front view of the Travelpro VersaPack+ Large Checked Luggage in black, showcasing its overall design and dimensions.

---

## **SETUP**

### **Unpacking**

Remove all packaging materials and protective coverings from the luggage. Inspect the luggage for any signs of damage incurred during shipping. If any damage is found, contact customer support immediately.

### **TSA Lock Initial Setup**

Your Travelpro VersaPack+ luggage is equipped with a built-in TSA-compliant combination lock. The default combination is **0-0-0**.

1. Open the lock by sliding the release button (usually located next to the dials) or pulling the zipper pulls out of the lock mechanism.
2. With the lock open and set to 0-0-0, locate the small reset button (often a small hole that requires a pen or pointed object to press).
3. Press and hold the reset button.
4. While holding the reset button, set your desired 3-digit combination by rotating the dials.
5. Release the reset button. Your new combination is now set. Test the new combination to ensure it works correctly before securing your luggage.
6. To lock, align your chosen combination, then insert the zipper pulls into the lock mechanism. Scramble the dials to secure.





Image: Detailed view of the built-in TSA-compliant lock and YKK zippers on the luggage.

---

## OPERATING INSTRUCTIONS

### Packing and Organization

The VersaPack+ is designed for maximum organization. Utilize the included accessories and compartments:

- **Packing Cubes:** Two large packing cubes are provided to compress and organize your clothing and other items. Place folded garments neatly inside the cubes and zip them closed.
- **Laundry Bag:** Use the removable laundry bag to separate damp or soiled clothing from clean items.
- **Water-Resistant Compartment:** A built-in wet pocket is ideal for toiletries or items that might leak, protecting other contents.
- **Lid Pocket & Hold-Down Straps:** The full-length lid pocket is suitable for smaller items or documents. Use the adjustable hold-down straps to secure packed items and prevent shifting during transit.



Image: The interior of the luggage showing the two large packing cubes, mesh lid pocket, and adjustable hold-down straps.



Image: Close-up of the included packing cubes, laundry bag, and the adjustable hold-down straps.

## Expanding Luggage Capacity

For additional packing space, your luggage features a tapered 2-inch expansion. Locate the expansion zipper around the perimeter of the main compartment and unzip it to increase the volume. This design helps maintain a low center of gravity even when expanded, reducing the risk of tipping.



LIMITED LIFETIME  
COVERAGE PLUS TRUSTED  
COMPANION PROMISE



TAPERED EXPANSION  
DESIGN KEEPS THE  
CENTER OF GRAVITY LOW



Image: Side view illustrating the tapered expansion design of the luggage.

### **Mobility: PrecisionGlide® System**

The PrecisionGlide® System ensures smooth and effortless movement. It consists of:

- **PowerScope Handle:** Extend the airline-grade PowerScope handle to one of its four height stops for comfortable maneuvering. The Contour Grip provides a secure and ergonomic hold.
- **MagnaTrac® Spinner Wheels:** The eight ultra-durable, 360° MagnaTrac® self-aligning spinner wheels allow for precise control and smooth rolling in any direction.

**PRECISIONGLIDE® SYSTEM**  
DELIVERS PRECISE CONTROL  
AND EFFORTLESS ROLL



**COMFORTABLE  
CONTOUR GRIP**



**AIRLINE-GRADE  
POWERSCOPE  
EXTENSION HANDLE**



**360° MAGNATRAC®  
SELF-ALIGNING  
SPINNER WHEELS**



Image: Detailed view of the PowerScope handle with Contour Grip and the MagnaTrac® spinner wheels.

## MAINTENANCE

### Cleaning Instructions

- **Exterior Fabric:** The high-density ballistic nylon fabric with DuraGuard® coating is stain-resistant. For general cleaning, wipe with a damp cloth and mild soap. For tougher stains, use a soft brush and a gentle fabric cleaner. Rinse thoroughly and air dry away from direct sunlight.
- **Interior Lining:** The ECOFAB™ interior lining with H2O guard can be wiped clean with a damp cloth.
- **Wheels:** Periodically check the spinner wheels for debris (hair, lint, etc.). Remove any obstructions to ensure

smooth rolling.

- **Handles:** Wipe the telescopic handle and carry handles with a damp cloth as needed.



Image: Close-up showing the texture of the high-density ballistic nylon fabric with DuraGuard® coating.

## Zipper Maintenance

The luggage features durable YKK® zippers. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax. A YKK® zipper repair kit is included with your luggage for minor repairs, ensuring long-term reliability.

## TROUBLESHOOTING

### Common Issues and Solutions

- **Stuck Telescopic Handle:** Ensure no items are obstructing the handle mechanism inside the lining. Press the release button firmly and try extending/retracting the handle. If it remains stuck, avoid forcing it to prevent damage.
- **Wheels Not Rolling Smoothly:** Check for hair, lint, or other debris wrapped around the wheel axles. Carefully remove any obstructions. If a wheel is damaged, refer to the warranty information for repair options.
- **Zipper Malfunction:** If a zipper pull detaches or the teeth misalign, use the included YKK® zipper repair kit. For more significant issues, contact customer support.
- **TSA Lock Combination Forgotten:** If you forget your combination, unfortunately, there is no universal reset code. You may need to try combinations or contact Travelpro customer support for assistance, which may involve a locksmith or authorized service center.

## SPECIFICATIONS

Below are the key specifications for the Travelpro VersaPack+ Large Checked Luggage (Model 417246901):

Feature	Detail
Overall Dimensions (includes wheels & handles)	30.75"L x 18"W x 13.25"H
Case Dimensions	27.75"L x 17"W x 12.75"H
Item Weight	10.9 Pounds
Capacity	130 Liters
Wheel Type	Spinner (8 wheels)
Lock Type	Combination Lock (TSA Compliant)
Material Type	High-density Ballistic Nylon with DuraGuard® coating
Lining Material	ECOFAB™ (100% post-consumer recycled plastic bottles) with H2O guard
Expansion	Tapered 2-inch expansion
Handle Type	Telescopic Extendable PowerScope Handle with Contour Grip
Water Resistance Level	Water Resistant
Model Number	417246901
UPC	051243133345





Image: Visual representation of the luggage with key dimensions highlighted.

# WARRANTY AND SUPPORT

## Limited Lifetime Coverage

Your Travelpro VersaPack+ luggage is covered by a Limited Lifetime Coverage, which covers defects in materials and workmanship for the duration of the product's ownership by the original purchaser or gift recipient. This includes coverage for wheels, zippers, and handles (carrying & extension). Repairs are at Travelpro's discretion.

## 3-Year Trusted Companion Promise

An enhanced warranty, the 3-Year Trusted Companion Promise, is valid for the first three years of ownership for the original purchaser or gift recipient. This promise covers:

- Shipping costs if the product needs to be sent to a Travelpro repair facility.
- The cost of repair for damage caused by airlines or other common carriers.

This additional coverage activates upon product registration. It is valid when purchased new and registered within 120 days of the delivery date or gift receipt.

## Customer Support

For warranty claims, service, or any product-related inquiries, please refer to the official Travelpro website or contact their customer service department. Keep your proof of purchase (e.g., Amazon receipt) as it may be required for warranty validation.

**VERSAPAC+  
COLLECTION**

**LIMITED LIFETIME COVERAGE**  
Duration\* covers defects in materials and workmanship for:

- Wheels ✓
- Zippers ✓
- Handles (Carrying & Extension) ✓
- Repair or replace (at Travelpro's discretion) ✓

**NEW TRUSTED COMPANION PROMISE\*\***  
< A WORRY-FREE ENHANCEMENT >\*\*\*

- Valid for **first (3) years** of limited coverage ✓
- Covers shipping cost** - If product needs to be shipped to one of Travelpro' repair facilities ✓
- Covers the **cost of repair for damage** caused by an airline or other common carrier ✓

\*For the period the product is owned by the original purchaser or gift recipient  
\*\*New Trusted Companion Promise activates upon product registration.  
\*\*\*Additional coverage, if registered within 120 days of delivery date or gift receipt

Image: Overview of the VersaPack+ Limited Lifetime Coverage and 3-Year Trusted Companion Promise.