

[Manuals.plus](#) /

› [PIIKAGO](#) /

› PIIKAGO Kids Play Tent with Mat - Instruction Manual

## PIIKAGO B0D86SZSYR

# PIIKAGO Kids Play Tent with Mat - Instruction Manual

Model: B0D86SZSYR

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your PIIKAGO Kids Play Tent with Mat. Designed to offer a safe and engaging space for children aged 3-8, this playhouse is suitable for both indoor and outdoor use. Please read all instructions carefully before assembly and use to ensure proper setup and safety.



Image: The PIKAGO Kids Play Tent with Mat, fully assembled and decorated, providing a comfortable play area.

## SAFETY INFORMATION

---

**WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.**

- Always supervise children during play.
- Ensure all poles are securely connected to prevent collapse.
- Keep away from open flames and heat sources.
- Do not use in strong winds or severe weather conditions outdoors.
- Regularly inspect the tent for any damage or wear.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- 1 x Play Tent Fabric Cover
- Set of Poles (various lengths, typically labeled)
- Set of Connectors

- 1 x Padded Mat
- 1 x Set of Star Lights
- 1 x Set of Decorative Flags
- 1 x Carry Bag

## COZY KIDS ROOM DECOR

Creates an enchanting atmosphere



Star Lights



Colorful Flags



Carry Bag



Image: Included accessories: star lights, colorful flags, and a convenient carry bag.

### SETUP INSTRUCTIONS

---

Assembly is designed to be straightforward and requires no tools. Follow these steps:

1. **Unpack Components:** Carefully remove all items from the carry bag and lay them out on a clean, flat surface. Identify the tent fabric, poles, and connectors.
2. **Assemble the Frame Base:** Connect the shortest poles using the appropriate connectors to form the rectangular base of the tent. Ensure each pole is firmly inserted into the connectors.
3. **Construct Vertical Supports:** Attach the longer poles to the base connectors, extending upwards to form the vertical structure.
4. **Form the Roof Structure:** Use the remaining poles and connectors to create the triangular roof frame. Pay close attention to the angles and ensure all connections are tight.

5. **Attach Fabric Cover:** Drape the tent fabric cover over the assembled pole frame. The cover is designed to fit snugly. Ensure the fabric is correctly oriented, with window and door openings aligned.
6. **Secure Fabric:** Zip up any closures or secure ties on the fabric cover to fully enclose the frame.
7. **Insert Mat:** Place the padded mat inside the tent for a comfortable floor.
8. **Add Decorations:** Hang the star lights and decorative flags as desired to enhance the tent's appearance. The star lights typically require AA batteries (not included).

**Important Note:** Press firmly and ensure **EVERY** pole is tightly connected to its corresponding connector. If there are gaps, the fabric cover may not fit properly over the tent structure.



Image: Illustration of connecting the base poles for the tent frame.



Image: Illustration of attaching vertical support poles to the tent base.



Image: Illustration of assembling the roof structure of the play tent.



Image: Illustration of placing the fabric cover onto the completed tent frame.

The PIIKAGO Kids Play Tent is designed for imaginative play, reading, and relaxation. Here are some tips for optimal use:

- **Indoor Use:** Position the tent on a flat, stable surface in a playroom, bedroom, or living area.
- **Outdoor Use:** The tent can be used outdoors in calm weather. Avoid placing it on uneven ground or in areas prone to strong winds. Always bring the tent indoors during inclement weather to prevent damage.
- **Ventilation:** The tent features breathable windows and a gauze curtain design to ensure air circulation.
- **Curtain Management:** The gauze curtains can be tied back for an open entrance or left down for a more enclosed space.
- **Star Lights:** Install 2 AA batteries (not included) into the battery pack of the star lights. Turn them on to create a cozy, enchanting atmosphere.



Image: Detailed view of the tent's features, including breathable windows and tie-back curtains.

## MAINTENANCE

To ensure the longevity and cleanliness of your play tent:

- **Cleaning the Fabric:** The tent fabric is made of premium polyester and is suitable for easy deep cleaning. Spot clean with a damp cloth and mild soap. For more thorough cleaning, the fabric cover can be gently hand washed in cold water and air-dried. Do not bleach or tumble dry.
- **Cleaning the Mat:** The padded mat can be wiped clean with a damp cloth.
- **Pole Care:** Wipe poles with a dry cloth if they become dirty. Ensure they are completely dry before storing to prevent rust.
- **Storage:** When not in use, disassemble the tent and store all components in the provided carry bag in a cool, dry place.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Tent fabric does not fit over the frame.	Poles are not fully connected, creating gaps in the frame.	Disassemble and reassemble the frame, ensuring all poles are pressed firmly and tightly connected into the connectors.
Star lights are not working.	Batteries are dead or incorrectly installed.	Check battery orientation and replace with fresh AA batteries.
Tent feels unstable.	Loose pole connections or uneven ground.	Verify all pole connections are secure. Move the tent to a flat, level surface.

## SPECIFICATIONS

---

- **Product Dimensions:** 57.08" L x 35.43" W x 47.24" H (145 x 90 x 120 cm)
- **Item Weight:** 6 pounds (2.72 kg)
- **Recommended Age:** 36 months - 10 years
- **Material:** Premium Polyester Fabric, Reinforced PVC Poles
- **Capacity:** Accommodates 3-4 children

# SPACIOUS & LARGE KIDS TENT

Accommodate up to 3-4 kids 



**NOTICE:** Please make sure there is no gap between two connecting poles, otherwise the cloth cover will not fit over the structure.

Image: Dimensional overview of the play tent, highlighting its spacious design.

## WARRANTY AND SUPPORT

PIIKAGO is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential warranty claims.

For product support, questions, or concerns, please contact PIIKAGO customer service through the retailer where the product was purchased or visit the official PIIKAGO brand store online.

[Visit the PIIKAGO Store](#)