

[Manuals.plus](#) /

› [Kepwam](#) /

› Kepwam Self Heating Coffee Mug T1-16oz Instruction Manual

Kepwam T1-16oz

Kepwam Self Heating Coffee Mug T1-16oz Instruction Manual

Model: T1-16oz

INTRODUCTION

This manual provides comprehensive instructions for the Kepwam Self Heating Coffee Mug T1-16oz. Please read this manual carefully before using your mug to ensure safe and efficient operation. Keep this manual for future reference.



Image: The Kepwam T1-16oz Self Heating Coffee Mug, black in color, filled with coffee and placed on its charging coaster. A transparent, spill-proof lid is shown beside it.

SAFETY INSTRUCTIONS

- **Hand Wash Only:** The mug is designed for hand washing. Do not immerse the base of the mug in water.
- **No Dishwasher or Microwave:** Do not place the mug in a dishwasher or microwave. This can damage internal wiring, impair heating functions, and pose safety risks such as melting or electrical hazards, reducing the product's lifespan.
- **Proper Charging:** Use only the provided rechargeable coaster and charging cable.
- **Avoid Overfilling:** Do not overfill the mug. The capacity is 16 oz (14 oz with the lid on).
- **Hot Surfaces:** The mug's exterior may become warm during operation. Handle with care.
- **Children and Pets:** Keep out of reach of children and pets when in use or charging.

SMART MUG FOR DRINKS

Milk



Coffee



Tea



Beverage



Image: Visual safety instructions explicitly prohibiting the use of the mug in a microwave or dishwasher to prevent damage and ensure user safety.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Kepwam Self Heating Coffee Mug (T1-16oz)
- Rechargeable Coaster
- Dedicated Charging Cable
- Spill-Proof Lid

WHY DID YOU CHOOSE US?



VS



Kepwam

Keep Warm Time 7 Hours



Battery Capacity 4000mAH



Smart Touch Button



14 oz & 16 oz



Other



Keep Warm Time 2 Hours



Battery Capacity 2500mAH



Mechanical Switch Button



One Size

Image: An illustration detailing the contents of the product package, including the mug, charging coaster, charging cable, and lid.

SETUP

1. **Initial Charge:** Before first use, fully charge the mug. Place the mug onto the rechargeable coaster, and connect the charging cable to the coaster and a power source. The LED indicators on the mug will show charging status.
2. **App Download (Optional):** For enhanced control and customization, download the Kepwam app from your device's app store. Follow the in-app instructions to pair your mug.



Image: A detailed view of the charging coaster, highlighting its design for stable and efficient charging.

OPERATING INSTRUCTIONS

Manual Control

- **Power On/Off:** Long press the power button located at the base of the mug to turn it on or off. The mug will vibrate slightly to confirm the action.
- **Set Temperature:** With the mug powered on, single-click the power button to cycle through the three temperature settings:
 - **Warm:** 113°F (45°C)
 - **Hot:** 131°F (55°C)
 - **Piping:** 149°F (65°C)

The LED indicators on the mug's base will illuminate to show the selected temperature level.



Image: A close-up of the power button on the mug's base, indicating its function.



Image: The LED indicators on the mug's base, showing the different temperature settings.

Kepwam

SELF HEATING COFFEE MUG

Charge the mug

1

Connect consistent docking coaster charge the mug, meanwhile activate APP control function



Touch the control button to select:

2

- Warm 113 degrees
- Hot 131 degrees
- Piping 149 degrees



Enjoy your favorite hot beverage

3

Perfect temperature...
right to the last sip



Image: A visual guide illustrating the simple three-step process for operating the self-heating coffee mug.

App Control (Optional)

The Kepwam app provides additional features:

- **Real-time Temperature Display:** Monitor your beverage's current temperature.
- **Remote Temperature Adjustment:** Change temperature settings from your smartphone.
- **Customization:** Adjust other settings and customize the mug's appearance within the app.



Image: A user demonstrating manual control by pressing the power button on the mug.



Image: A user interacting with the Kepwam mobile application to adjust the mug's temperature settings.

Using the Spill-Proof Lid

The included sliding lid helps retain heat and prevent spills. Place the lid securely on top of the mug to maximize heat retention, especially when not on the charging coaster.



Image: A detailed view of the spill-proof lid, featuring its sliding opening mechanism.

MAINTENANCE

- **Cleaning:** Hand wash the mug with mild soap and water. Do not submerge the mug's base in water. Wipe the exterior with a damp cloth. Ensure the charging contacts on the mug and coaster are clean and dry before charging.
- **Storage:** Store the mug and coaster in a dry place when not in use.
- **Battery Care:** For optimal battery longevity, avoid completely draining the battery frequently. Charge the mug regularly.



Image: A visual representation of hand washing the mug, emphasizing its waterproof design for cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mug not heating or turning on.	Low battery; mug not properly placed on coaster; power button not pressed correctly.	Ensure mug is fully charged. Place mug firmly on the coaster. Long press the power button until vibration is felt.
Temperature not consistent.	Lid not used; mug not on charging coaster for extended warmth; incorrect temperature setting.	Use the spill-proof lid. For all-day warmth, keep the mug on the charging coaster. Verify the desired temperature setting.
App not connecting to mug.	Bluetooth disabled; mug not in pairing mode; app issues.	Ensure Bluetooth is enabled on your device. Restart the app and mug. Refer to the app's help section for pairing instructions.
Mug turns off unexpectedly.	Accidental press of the sensitive power button; low battery.	Be mindful of where you grip the mug to avoid accidental button presses. Ensure the mug is adequately charged.

SPECIFICATIONS

- **Model:** T1-16oz
- **Capacity:** 16 ounces (14 ounces with lid on)
- **Temperature Settings:**
 - Warm: 113°F (45°C)
 - Hot: 131°F (55°C)
 - Piping: 149°F (65°C)
- **Battery Life:** Up to 180+ minutes (3+ hours) on a full charge without coaster; indefinite with coaster.
- **Control:** Manual touch button, Kepwam mobile app.
- **Material:** Ceramic coating, stainless steel interior.
- **Power Source:** Rechargeable Lithium Polymer battery.

- **Item Weight:** Approximately 1.85 pounds (0.84 kg).
- **Package Dimensions:** 6.89 x 6.57 x 4.84 inches.

TECHNOLOGY-ENABLED, EACH BITE IS JUST THE RIGHT



Temperature Range

Choose from three modes:
Warm (113°F), Hot (131°F),
and Piping (149°F)



Smart LED

Indicate the temperature
and working condition of
the beverage



Built-In Battery

Enjoy up to 7 hours
of heat — when used
with the lid on

Image: An overview of key specifications including temperature range, LED indicators, and battery life.

ESTIMATED USE TIME AT VARIOUS CONDITION OF KEPWAM

Usage Tip: For best results, charge thermal cup before each use.

Estimated Use Time at Various Settings of Kepwam				
Temp:Setting	OFF COASTER		ON COASTER	
	With lid	Without lid	With lid	Without lid
Warm 113°F/45°C	7h	4h	Indefinite	Indefinite
Hot 131°F/55°C	4.5h	2.5h	Indefinite	Indefinite
Piping 149°F/65°C	3.5h	2h	Indefinite	Indefinite

*Data based on 14 oz mug, coffee brewed at 113°F-149°F(average brew temperature),
mug start temperature of 113°F, fully charged battery.



Image: A table illustrating the estimated battery life and heat retention under different usage conditions (with/without lid, on/off coaster).

WARRANTY AND SUPPORT

Kepwam products are designed for quality and reliability. For warranty information, please refer to the documentation included with your purchase or visit the official Kepwam website. For technical support, troubleshooting assistance, or any product-related inquiries, please contact Kepwam customer service through the contact information provided on the official website or your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D86W35TZ>

More documents and user manuals: <https://manuals.plus/>