

manuals.plus /

› [little dove](#) /

› [Little Dove Kids Play Tent with Mat and Star Lights \(Model: Play Tent001\) - Instruction Manual](#)

little dove Play Tent001

Little Dove Kids Play Tent with Mat and Star Lights

Model: Play Tent001 - Instruction Manual

1. IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.

- Always supervise children during play.
- Keep all packaging materials away from children to prevent suffocation.
- Ensure all poles are securely connected to prevent collapse.
- Do not use near open flames or heat sources.
- This tent is for play purposes only and is not intended for camping or protection from severe weather.

2. PACKAGE CONTENTS

Please verify that all components are present before assembly:

- 1 x Play Tent Fabric Body
- 1 x Set of Poles and Connectors for Tent Structure
- 1 x Star Lights String (battery-operated)
- 1 x Non-Slip Play Mat
- 1 x Tassel Garland

All-in-One Accessories

No need for extra decorations



Figure 2.1: Included accessories: Star Lights, Tassel Garland, and Non-Slip Mat.

3. ASSEMBLY INSTRUCTIONS

The Little Dove Play Tent is designed for quick and easy assembly without the need for additional tools.

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Assemble Frame:** Connect the poles using the provided connectors. Ensure each pole is **tightly connected** to form a stable frame. This is crucial for the fabric cover to fit correctly.
3. **Drape Fabric Cover:** Carefully drape the tent fabric body over the assembled pole frame. Align the corners and edges of the fabric with the frame.
4. **Secure Mat:** Place the non-slip play mat inside the tent. The mat features ties that can be secured to the tent poles at the base to prevent it from shifting.
5. **Add Decorations:** Hang the star lights and tassel garland around the tent as desired. The star lights are battery-

operated; insert batteries (not included) and use the switch to turn them on/off.



Figure 3.1: Fully assembled Little Dove Kids Play Tent.

4. OPERATING INSTRUCTIONS

The Little Dove Play Tent offers a versatile space for children's activities.

- **Door and Windows:** The tent features one main door and three windows, each equipped with curtains. These can be opened or closed to adjust light and privacy.
- **Star Lights:** The included star lights provide a gentle illumination. To operate, ensure batteries are installed in the battery pack and use the ON/OFF switch.
- **Play Mat:** The non-slip mat provides a comfortable surface for play, reading, or napping.

Skin-friendly Mat

Soft and comfortable for children's delicate skin

50% more filling



1. Soft fabric

2. Thick cotton

3. Machine washable



Figure 4.1: Skin-friendly mat details.

5. MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Little Dove Play Tent:

- **Cleaning the Fabric:** The tent fabric is machine washable. Use a gentle cycle with cold water and mild detergent. Do not bleach. Air dry or tumble dry on low heat.
- **Cleaning Poles:** Wipe poles and connectors with a damp cloth as needed.
- **Star Lights:** Remove batteries if the lights will not be used for an extended period. Wipe with a dry cloth. Do not immerse in water.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place away from direct sunlight.

6. TROUBLESHOOTING

- **Tent Cover Does Not Fit:** Ensure all poles are fully and tightly connected into their respective connectors. A loose connection can alter the frame's dimensions, preventing the cover from fitting properly.
- **Star Lights Not Working:** Check if batteries are correctly inserted and are not depleted. Ensure the ON/OFF switch is in the 'ON' position.
- **Tent Instability:** Verify that all poles are securely joined and the tent is placed on a flat, stable surface.

7. SPECIFICATIONS

Product Dimensions	47 x 52 x 40 inches (Length x Height x Width)
Item Weight	3.8 pounds
Model Number	Play Tent001
Recommended Age	3 years and up
Material	Premium Polyester Fabric

Perfect Size

Spacious for kids to play inside while not occupying too much room in your indoor space



Figure 7.1: Play Tent dimensions.







8. WARRANTY AND SUPPORT

Little Dove products are designed for quality and durability. We offer:

- **Superior Warranty Coverage:** Details available upon product registration or by contacting customer service.
- **30-Day Satisfaction Guarantee:** If you are not completely satisfied with your purchase, please contact us within 30 days for assistance.
- **Always-On Assistance:** For any questions, concerns, or support needs, please visit the Little Dove store on Amazon or contact our customer service team directly.

For further assistance, please visit the official Little Dove store: [Little Dove Store](#)

Related Documents - Play Tent001

	<p>Costzon Kids Play Tent Assembly Instructions</p> <p>Step-by-step assembly guide for the Costzon Kids Play Tent, including a list of accessories and general safety warnings.</p>																				
	<p>Kids Tent User Manual: Assembly and Care Guide</p> <p>Comprehensive user manual for the Kids Tent, providing step-by-step assembly instructions, parts list, dimensions, and care guidelines for this playhouse.</p>																				
	<p>Light Up Play Tent Blue Assembly and Care Instructions</p> <p>Detailed assembly, usage, and care instructions for the Light Up Play Tent Blue (Key Code: 43073832). Includes parts list, step-by-step assembly, folding guide, important safety warnings, and care tips.</p>																				
	<p>IKEA HÖVLIG Children's Tent Assembly Instructions</p> <p>Step-by-step assembly guide for the IKEA HÖVLIG children's tent, including safety warnings and care instructions.</p>																				
	<p>BusyWood Model 21 75x38 Slats Playhouse Assembly Instructions</p> <p>Comprehensive assembly guide for the BusyWood Model 21 75x38 Slats Playhouse, including safety information, a detailed parts list, and step-by-step instructions for building a durable wooden playhouse for children.</p>																				
 <table><tr><td colspan="2">besrey</td></tr><tr><td>型号</td><td>BR-WJZ06</td></tr><tr><td>物料名称</td><td>骑马钉帐篷</td></tr><tr><td>材质</td><td>128G微麻纸正反面印刷</td></tr><tr><td>印刷</td><td>4C30网</td></tr><tr><td>尺寸</td><td>148*210MM</td></tr><tr><td>公差</td><td>±1mm</td></tr><tr><td>版本号</td><td>6.0</td></tr><tr><td>设计师</td><td>黄泽华</td></tr><tr><td>日期</td><td>20250630</td></tr></table>	besrey		型号	BR-WJZ06	物料名称	骑马钉帐篷	材质	128G微麻纸正反面印刷	印刷	4C30网	尺寸	148*210MM	公差	±1mm	版本号	6.0	设计师	黄泽华	日期	20250630	<p>Besrey BR-WJZ06 Kids House Tent User Manual - Assembly and Care Guide</p> <p>Comprehensive user manual for the Besrey BR-WJZ06 Kids House Tent. Includes detailed assembly instructions, parts list, safety warnings, and care tips for this indoor/outdoor play tent.</p>
besrey																					
型号	BR-WJZ06																				
物料名称	骑马钉帐篷																				
材质	128G微麻纸正反面印刷																				
印刷	4C30网																				
尺寸	148*210MM																				
公差	±1mm																				
版本号	6.0																				
设计师	黄泽华																				
日期	20250630																				

