

Bestier L103114N

Bestier Gaming TV Stand with LED Light

Model: L103114N

[Introduction](#)

[Safety Information](#)

[Assembly](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bestier Gaming TV Stand with LED Light, Model L103114N. Please read all instructions carefully before assembly and use to ensure proper function and safety.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety guidelines may result in injury or product damage.

- Do not exceed the maximum weight limit of the TV stand. Exceeding the weight limit may cause damage or injury.
- Ensure the stand is properly leveled and stable on uneven surfaces using the adjustable feet.
- Follow all assembly instructions carefully and use only the provided hardware.
- Do not look directly at the LED lights for extended periods.
- Avoid leaving LED lights on for excessively long durations to prolong their lifespan.
- Keep small parts and packaging materials away from children.

3. ASSEMBLY INSTRUCTIONS

Your Bestier Gaming TV Stand is designed for straightforward assembly. All necessary accessories and an

illustrated instruction manual are included in the packaging. We recommend having a second person assist with certain steps for easier and safer assembly.

3.1. Unpacking and Preparation

- Carefully unpack all components and hardware. Verify that all parts listed in the included parts list are present.
- Lay out all parts on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
- Tools required: Typically a Phillips head screwdriver (not always included).

3.2. Step-by-Step Assembly

Refer to the detailed step-by-step diagrams in the included instruction manual for specific assembly sequences. General steps include:

1. Attach the metal frame components using the provided screws and fasteners.
2. Secure the particleboard panels to the frame.
3. Install the adjustable metal net shelves. These shelves can be positioned to suit your storage needs.
4. Attach the adjustable feet to the bottom of the stand. Adjust them to ensure the stand is level on your floor.
5. Install the LED light strip according to the separate LED light instructions.

Product Size





Image: Product dimensions and weight capacity. The stand measures 53 inches in length, 13.8 inches in width, and 21.5 inches in height. The top surface supports up to 100 lbs on each end, and the shelves support 30 lbs or 50 lbs depending on placement.

Adjustable Shelf

Flexible configurations for varied storage needs



Option 1



Option 2



Option 3

Image: Adjustable shelf configurations. The middle mesh shelf can be adjusted left or right to create varied storage layouts, allowing for flexible organization of media devices.

3.3. Cable Management

The TV stand features four cable holes on the back panel to help organize and route cables for your media devices, keeping your setup tidy and clutter-free.

Multi-Functional TV Stand



Versatile Storage Space



Cable Management Holes



Adjustable Feet



Image: Multi-functional features. This image highlights versatile storage space, integrated cable management holes, and adjustable feet for stability on uneven floors.

4. OPERATING INSTRUCTIONS

4.1. LED Light Operation

The integrated LED lights are controlled by a remote control. Follow the instructions provided with the LED light kit for pairing and operation.

- **Power On/Off:** Use the designated button on the remote to turn the lights on or off.
- **Color Selection:** Choose from 7 main colors using the color buttons on the remote.
- **Dynamic Modes:** Select from 22 dynamic modes to create various lighting effects.
- **Brightness Adjustment:** Adjust the brightness levels to your preference.



Image: LED light features and remote control. This image illustrates the 7 main colors, 22 dynamic modes, and RGB capabilities controlled by the included remote.

5. MAINTENANCE

5.1. Cleaning

- Wipe the surfaces of the TV stand with a dry, soft cloth.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.

5.2. General Care

- Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- Ensure the adjustable feet are correctly set to maintain stability.
- Avoid placing hot items directly on the surface without protective coasters.

6. TROUBLESHOOTING

6.1. Stability Issues

- Problem:** The TV stand wobbles or is unstable.
Solution: Check that all assembly screws are tightened. Adjust the leveling feet on the bottom of the stand to compensate for uneven floor surfaces.

6.2. LED Lights Not Functioning

- Problem:** LED lights do not turn on or respond to the remote.
Solution: Ensure the power adapter for the LED lights is securely plugged into a working outlet. Check the connection between the LED strip and the controller. Replace the remote control battery if necessary. Refer to the separate LED light manual for specific troubleshooting steps.

6.3. Missing or Damaged Parts

- Problem:** Parts are missing or damaged upon arrival.
Solution: Contact Bestier customer service immediately for assistance. Provide your model number and a description of the issue.

7. SPECIFICATIONS

Feature	Detail
Model Number	L103114N
Dimensions (L x W x H)	134.6 x 35 x 54.8 cm (53"L x 13.8"W x 21.5"H)
Material	P2 Grade Particleboard, Metal Frame
Color	Black
Item Weight	36.6 Pounds (approx. 16.6 kg)
Weight Capacity	Up to 240 Pounds (total)
Number of Shelves	3 (including 1 adjustable metal net shelf)
Special Features	Adjustable Shelf, LED Lights (7 colors, 22 dynamic modes), Cable Management Holes, Adjustable Feet
TV Size Compatibility	Up to 60 Inch TVs

8. CUSTOMER SUPPORT

Bestier is committed to providing excellent customer service. If you encounter any product issues, have questions regarding assembly, or require assistance with your TV stand, please do not hesitate to contact us.

- Contact Method:** Refer to the contact information provided in your product packaging or on the Bestier official website.
- Response Time:** Our professional customer service team aims to reply to all inquiries within 24 hours.

Please have your model number (L103114N) and purchase details ready when contacting support to expedite the process.

© 2024 Bestier. All rights reserved.