

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VGR](#) /

› [VGR V-938 Body Hair Trimmer for Men - User Manual](#)

VGR V-938

VGR V-938 Body Hair Trimmer User Manual

Model: V-938 | Brand: VGR

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your VGR V-938 Body Hair Trimmer. Please read all instructions carefully before use and retain this manual for future reference.

The VGR V-938 is designed for efficient and comfortable body hair trimming, featuring ceramic anti-cut blades, a powerful motor, and a waterproof design for versatile grooming.

SETUP AND FIRST USE

Unboxing and Package Contents

Carefully unpack all items from the box. Ensure all components are present:

- Trimmer unit
- USB Charging Cable
- 4 Guide Combs (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
- Blade Protection Cap
- Blade Oil
- Cleaning Brush
- Instructions Manual (this document)



Image: The VGR V-938 Body Hair Trimmer with its complete set of accessories, including the trimmer unit, charging dock, USB cable, four guide combs, blade oil, and cleaning brush.

Charging the Trimmer

Before first use, fully charge the trimmer. The device is powered by a built-in Lithium Ion battery.

1. Connect the USB charging cable to the charging dock.
2. Place the trimmer securely onto the charging dock.
3. Connect the USB cable to a compatible USB power adapter (not included) or a USB port.
4. The LED display on the trimmer will indicate charging status. A full charge takes approximately 2 hours and provides up to 90 minutes of work time.



ARC CUTTER HEAD
Prevent skin damage from
blade teeth during cutting

2 Hours

Charge Time

90 Mins

Work Time



Image: Close-up of the VGR V-938 Trimmer's charging port with a USB cable connected, indicating a 2-hour charge time for 90 minutes of work time.



Image: The VGR V-938 Trimmer standing upright on its wireless charging dock, with water droplets visible on its surface, highlighting its waterproof feature.

Attaching Guide Combs

The trimmer comes with four guide combs that allow for six different trimming lengths (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm). To attach a comb:

- Ensure the trimmer is turned off.
- Align the desired guide comb with the trimmer blade.
- Gently push the comb onto the blade until it clicks into place.
- To remove, gently pull the comb away from the blade.




Image: A set of four grey guide combs, varying in size, designed to be attached to the trimmer for different hair lengths.

OPERATING INSTRUCTIONS

Powering On/Off and Travel Lock

- To turn the trimmer **ON**, press the power button once.
- To turn the trimmer **OFF**, press the power button once.
- To activate the **Travel Lock**, press and hold the ON/OFF button for 3 seconds. The travel lock icon will appear on the LED display.
- To deactivate the **Travel Lock**, press and hold the ON/OFF button for 3 seconds again.



 **ON/OFF BUTTON**

Easy to operate, convenient and practice.

 **LOW NOISE**

It's quieter than most products on the market.

 **LONGER WORK TIME**

Rechargeable Li-ion battery 5V 600mAh.

 **LED DISPLAY**

The LED display show the power left status and add oil timely.

Image: The VGR V-938 Trimmer displaying its ON/OFF button, LED screen, and features such as low noise and longer work time.

Trimming Techniques

The VGR V-938 features ceramic anti-cut blades designed for smooth and safe trimming across various body areas.

- Ensure your skin is clean and dry before trimming.
- For best results, trim against the direction of hair growth.
- Use the appropriate guide comb for your desired hair length.
- Apply light pressure and move the trimmer slowly and steadily.
- The built-in LED spotlight provides illumination for precise trimming in hard-to-see areas.



Image: A detailed view of the VGR V-938 Trimmer's arc cutter head, designed to prevent skin damage during use.

LED Display Indicators

The LED display provides important information about the trimmer's status:

- **Battery Level:** Shows the remaining power percentage.
- **Oil Reminder:** An icon will illuminate to indicate when the blades require oiling.
- **Travel Lock:** An icon indicates when the travel lock feature is active.

MAINTENANCE AND CARE

Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene. The VGR V-938 is waterproof (IPX7 rated) for easy cleaning.

1. Turn off the trimmer and remove any attached guide comb.
2. Use the provided cleaning brush to remove loose hairs from the blade and trimmer body.
3. Rinse the blade head and the trimmer body under running water. Do not submerge the entire unit for extended periods.
4. Allow the trimmer to air dry completely before storing or recharging.




Image: The VGR V-938 Trimmer covered in water droplets, demonstrating its waterproof capability for easy cleaning.

Oiling the Blades

To maintain blade sharpness and smooth operation, oil the blades regularly, especially when the oil reminder icon appears on the LED display.

1. Ensure the trimmer is clean and dry.
2. Apply 1-2 drops of the provided blade oil evenly across the top of the blades.
3. Turn on the trimmer for a few seconds to allow the oil to distribute.
4. Wipe off any excess oil with a soft cloth.

TROUBLESHOOTING GUIDE

If you encounter issues with your VGR V-938 Trimmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted. Travel lock is active.	Charge the trimmer fully. Deactivate travel lock by holding the power button for 3 seconds.
Blades are pulling hair or not cutting effectively.	Blades are dirty or clogged. Blades need oiling. Blades are dull.	Clean the blades thoroughly with the brush and rinse. Apply blade oil as per maintenance instructions. If issues persist after cleaning and oiling, contact customer support.
Trimmer is not charging.	Charging cable or dock is not properly connected. Power source issue.	Ensure the USB cable is securely connected to the dock and power source, and the trimmer is correctly seated on the dock. Try a different USB power adapter or port.
Unusual noise during operation.	Blades are not properly oiled or are obstructed.	Clean and oil the blades. Ensure no hair or debris is lodged in the blade mechanism.

If the problem persists after attempting these solutions, please contact VGR customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	V-938
Brand	VGR
Blade Material	Ceramic
Power Source	Battery Powered (Lithium Ion)
Charge Time	Approx. 2 hours
Work Time	Approx. 90 minutes
Waterproof Rating	Yes (IPX7)
Guide Combs	4 combs providing 6 lengths (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
Special Features	Portable, Rechargeable, Waterproof, LED Spotlight, Travel Lock, LED Display
Dimensions (LxWxH)	20 x 9.7 x 6.6 cm
Item Weight	490 g

Feature	Detail
Manufacturer	Ningbo VGR Electric Appliance Co., Ltd., Yiwu Gemei Electric Appliance Co. Ltd




Image: Visual representations of the trimmer's key internal components: a Lithium Battery and a Powerful Motor.

WARRANTY AND SUPPORT

Warranty Information

The VGR V-938 Body Hair Trimmer comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its stated performance standards under normal use.

Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or warranty claims, please contact VGR customer service. Our team aims to respond within 24 hours to provide a satisfactory resolution.

You can visit the official VGR store on Amazon for more information and contact options: [VGR Official Store](#)