

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Donner](#) /
- › [Donner 38" Carbon X Wood Acoustic Guitar RISING-G1 User Manual](#)

Donner RISING-G1

Donner 38" Carbon X Wood Acoustic Guitar RISING-G1 User Manual

Model: RISING-G1

1. INTRODUCTION

The Donner RISING-G1 is a 38-inch acoustic guitar designed for both beginner and intermediate players. It features a unique blend of a carbon fiber top and a mahogany body, offering a balance of durability, stable tone, and rich resonance. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your RISING-G1 guitar.




Figure 1: Donner RISING-G1 Carbon X Wood Acoustic Guitar (Brown Satin finish)

2. PRODUCT FEATURES

- **Carbon Fiber Top & Mahogany Body:** This guitar combines a 3K pure carbon fiber fabric top with a mahogany back, sides, and neck. This construction provides a warm, natural tone with enhanced durability and stability across various environmental conditions.
- **Stable Performance:** The carbon fiber soundboard ensures stable performance, resisting changes due to humidity

or temperature fluctuations.

- **Ergonomic Design:** Featuring a self-developed 38-inch body and carbon fiber bracing design, the RISING-G1 optimizes sound transmission and resonance while maintaining portability and comfortable playability.
- **Comfortable Fretboard:** The high-density HPL fretboard and anti-oxidation rounded frets offer a smooth, rust-free playing experience.
- **Complete Kit:** The guitar comes with essential accessories including a quality case, strap, strings, and picks, making it ready for immediate use.




Figure 2: Key features of the Donner RISING-G1 guitar.

3. SETUP

3.1 Unboxing and Initial Inspection

Carefully remove the guitar from its packaging. Inspect the instrument for any visible damage that may have occurred during shipping. Ensure all included accessories (case, strap, strings, picks) are present.

Your browser does not support the video tag.

Video 1: Unboxing the Donner Carbon Fiber Wood Acoustic Guitar. This video demonstrates the careful unboxing process and highlights the guitar's initial appearance and included accessories.

3.2 String Installation and Tuning

The guitar comes with steel strings (Phosphor Bronze). If new strings are needed, carefully replace them one by one to maintain neck tension. Tune the guitar to standard EADGB_e tuning using a reliable tuner. New strings may require several tunings before they stabilize.

CRAFTED EVERY DETAIL




Figure 3: Tuning the guitar using a clip-on tuner.

3.3 Adjusting the Truss Rod (Advanced Users Only)

The truss rod, located inside the neck, controls the neck's relief. If you experience excessive fret buzz or high action, a minor adjustment may be needed. This should ideally be performed by an experienced technician or luthier. Use the included Allen wrench for adjustments. Turn clockwise to reduce relief (straighten neck) and counter-clockwise to increase relief (add bow). Make small adjustments (quarter turns) and allow the neck to settle before re-evaluating.

4. OPERATING THE GUITAR

4.1 Playing Position

Hold the guitar comfortably, either seated or standing with the strap. The ergonomic 38-inch body is designed for ease of play. Ensure your fretting hand can comfortably reach all frets and your strumming/picking hand is positioned over the strings for optimal sound.

Your browser does not support the video tag.

Video 2: Overview of the Donner Carbon Fiber X Wood Acoustic Guitar. This video showcases the guitar's design and sound in various playing scenarios.

4.2 Fretboard and Frets

The HPL fretboard with anti-oxidation rounded frets is designed for smooth playability. Practice fretting notes cleanly and consistently. The smooth edges prevent discomfort during extended playing sessions.




Figure 4: Detailed view of the high-density HPL fretboard and anti-oxidation rounded frets.

5. MAINTENANCE

5.1 Cleaning

- Wipe down the guitar body, neck, and strings with a soft, dry cloth after each use to remove sweat and oils.
- For deeper cleaning, use a guitar-specific cleaning solution on the body. Avoid harsh chemicals.
- Clean the fretboard periodically with a lemon oil or fretboard conditioner to prevent drying and cracking.

5.2 String Care

Replace strings regularly, typically every 1-3 months depending on usage, to maintain optimal tone and playability. Phosphor Bronze strings are recommended for this model.


5.3 Storage

Store the guitar in its included gig bag when not in use to protect it from dust, scratches, and minor impacts. Avoid extreme temperatures and humidity, as these can affect the wood components. The carbon fiber top provides enhanced stability against environmental changes.

CARBON X WOOD ACOUSTIC GUITAR


1 Easy Maintenance

More durable and stable



2 Well-Balanced Tone

A stronger tonal grain and more prominent mid-high frequencies



3 Comfortable Woody Sound



4 Better Resonance



■ RISING-G1 ■ WOODEN
■ CARBON FIBER FULL




Figure 5: The Donner RISING-G1 guitar stored in its protective gig bag.

6. TROUBLESHOOTING

- **Fret Buzz:** Check string action. If too low, a truss rod adjustment or saddle adjustment may be needed. Ensure frets are level.
- **Poor Intonation:** If notes are out of tune higher up the neck, check the saddle for proper placement and height. Professional setup may be required.

- **Dull Sound:** Old or dirty strings can cause a dull sound. Replace strings regularly. Ensure the guitar is clean.
- **Tuning Instability:** New strings take time to stretch. Ensure tuning pegs are tight. Extreme temperature changes can affect tuning, though the carbon fiber top minimizes this.

7. SPECIFICATIONS

Feature	Detail
Model Number	RISING-G1
Item Weight	3.53 pounds
Package Dimensions	40.1 x 16.25 x 6 inches
Top Material	Carbon Fiber (3K Pure Carbon Fiber Fabric)
Back Material	Mahogany Wood
Body Material	Mahogany
Neck Material Type	Mahogany
Fretboard Material	HPL (High-Pressure Laminate)
Number of Strings	6
String Material	Phosphor Bronze
Guitar Bridge System	Fixed
Hand Orientation	Right
Color	Brown (Satin finish for this model)

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official Donner website or contact Donner customer service.

Donner Official Website: [Visit the Donner Store on Amazon](#)

