

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MANSCAPED](#) /

› [MANSCAPED® The Dome Shaver™ PRO Head Shaver - Instruction Manual](#)

MANSCAPED 30-00130

MANSCAPED® The Dome Shaver™ PRO Head Shaver - Instruction Manual

Model: 30-00130

PRODUCT OVERVIEW

The MANSCAPED® The Dome Shaver™ PRO is designed for head shaving, featuring advanced technology for a comfortable and close shave. This device is engineered to provide a smooth and efficient grooming experience for bald men.

Key Features

- **Five Rotary Blade Design with SkinSafe® & FlexAdjust Technology:** Ensures a close shave while minimizing irritation.
- **Waterproof (IPX7 rated):** Allows for wet or dry shaving and easy cleaning under running water.
- **USB-C & Wireless Charging Compatible:** Offers versatile and convenient charging options.
- **Travel Lock:** Prevents accidental activation during transport.
- **Magnetic Blade Pad:** Facilitates easy detachment for cleaning and maintenance.
- **Ergonomic Handheld Design:** Provides comfortable handling and navigation across head contours.

Head Shaver



Magnetic Blade

Hair chamber can be detached to empty clippings and clean blades easily.



FlexAdjust Technology

Contours seamlessly to your head for an effortless, close shave.



.10 mm Close

Stainless-steel rotary blade heads float over bumps and curves.



Travel Lock Button

Press and hold the lock button for 3 seconds to engage / disengage.



Figure 1: Key features of The Dome Shaver PRO, highlighting its magnetic blade, FlexAdjust technology, close shave capability, and travel lock.

SETUP

Charging the Device

The Dome Shaver PRO features a long-lasting rechargeable battery. It is compatible with both USB-C and wireless charging for your convenience.

Use the provided USB-C cable to charge the device. Ensure the shaver is fully charged before its first use to maximize battery life and performance.

The device includes a battery life indicator, allowing you to monitor the remaining usage time and plan your charging sessions effectively.

Video 1: Official MANSCAPED tutorial demonstrating the usage and cleaning of The Dome Shaver PLUS, which includes charging instructions.

OPERATING INSTRUCTIONS

How to Use The Dome Shaver PRO

1. Hold The Dome Shaver PRO by the handle or palm the blade pad with your hand. The ergonomic design allows for comfortable navigation across different head curvatures.
2. Gently glide the shaver across your head, making both straight and circular movements for an effective and smooth shave.
3. The five stainless-steel SkinSafe rotary blade heads float over bumps and curves, providing a 0.10 mm close shave. FlexAdjust technology ensures each blade stays in close contact with the scalp.

**Note: SkinSafe Technology does not guarantee cut protection.*



Palm it.

The ergonomic design and curved blade pad allow you to easily navigate any head shape.



Figure 2: Demonstrating the ergonomic palm grip for comfortable and easy head shaving.

Travel Lock Feature


For secure portability while traveling, The Dome Shaver PRO includes a travel lock feature. To engage or disengage the travel lock, press and hold the power button for 3 seconds. This prevents accidental activation of the device during transport, ensuring safety and preserving battery life.

MAINTENANCE

Cleaning the Shaver

1. The magnetic blade pad and hair chamber can be easily detached from the shaver body. This design allows for convenient emptying of hair clippings.
2. After detaching, rinse the blade pad and hair chamber thoroughly under running water to remove any remaining hair and debris.
3. The entire device is waterproof (IPX7 rated), allowing for safe rinsing under water. Ensure the device is powered off before cleaning.

**IPX7 rated to protect against immersion in up to one meter of fresh water for up to 30 minutes.*



Waterproof.

Shave how you want—it's waterproof.*

*IPX7 rated to protect against immersion in up to one meter of fresh water for up to 30 minutes.

Figure 3: The magnetic blade pad detaches easily for hassle-free cleaning.



Figure 4: The shaver is waterproof, allowing for convenient rinsing under water.

Video 2: Official MANSAPED tutorial demonstrating the cleaning process for The Dome Shaver PLUS, including detaching and rinsing components.

SPECIFICATIONS

Feature	Detail
Package Dimensions	10.28 x 8.62 x 4.53 inches; 12 ounces
Item Model Number	30-00130
Batteries	1 Lithium Ion batteries required. (included)
Date First Available	July 5, 2024

Manufacturer	MANSCAPED
ASIN	B0D886GXP7
Brand	MANSCAPED
Recommended Uses For Product	Scalp
Special Feature	SkinSafe® & FlexAdjust Technology
Power Source	Battery Powered
Model Name	The Dome Shaver™ PRO

WARRANTY AND SUPPORT

For warranty information and customer support regarding your MANSCAPED® The Dome Shaver™ PRO, please refer to the official MANSCAPED website or contact their customer service directly. Detailed contact information can typically be found in the product packaging or on the manufacturer's website.

**Note: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a personal grooming device and not a dietary supplement.*