

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ANTELA](#) /

› [ANTELA C23 Indoor Security Camera \(4-Pack\) User Manual](#)

## ANTELA C23

# ANTELA C23 Indoor Security Camera (4-Pack) User Manual

Model: C23

## 1. INTRODUCTION

Thank you for choosing the ANTELA C23 Indoor Security Camera system. This manual provides detailed instructions for the setup, operation, and maintenance of your 4-pack camera system. The ANTELA C23 offers 1080P Full HD video, dual-band 2.4GHz/5GHz Wi-Fi connectivity, 355° pan and 90° tilt functionality, two-way audio, enhanced night vision, and intelligent motion detection. It is also compatible with Alexa and Google Home for convenient smart home integration.

## 2. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, please contact customer support.

- 4 x ANTELA C23 Indoor Security Cameras
- 4 x Power Adapters
- 4 x USB Cables
- 4 x Wall Mount Brackets
- 4 x Screw Packs (for mounting)
- 1 x User Manual (this document)

## 3. PRODUCT OVERVIEW

The ANTELA C23 camera is designed for indoor surveillance, offering a comprehensive set of features to monitor your home or office.

- **1080P Full HD Video:** Provides clear and detailed live view and recordings.
- **Dual-Band Wi-Fi:** Supports both 2.4GHz and 5GHz Wi-Fi networks for flexible connectivity.
- **Pan & Tilt:** Offers a 355° horizontal and 90° vertical rotation for wide coverage.
- **Two-Way Audio:** Built-in microphone and speaker allow for real-time communication.
- **Enhanced Night Vision:** Infrared (IR) LEDs provide clear vision up to 9 meters in low-light conditions.

- **Motion Detection:** Sends real-time notifications upon detecting movement.
- **Storage Options:** Supports Cloud storage and local storage via Micro SD card (up to 128GB).
- **Smart Home Integration:** Compatible with Amazon Alexa and Google Home.

## 1080P Full HD security camera



Image: Comparison showing the superior clarity of 1080P Full HD video compared to 720P, highlighting the ANTELA C23 camera's high-resolution capability.

## 4. SETUP

### 4.1 Powering On

1. Connect the USB cable to the camera's power port.
2. Plug the power adapter into a standard electrical outlet.
3. The camera will power on, and its indicator light will begin to flash, indicating it is ready for setup.

### 4.2 App Installation

Download the official companion app (e.g., "YI IoT" as mentioned in some reviews, or refer to the packaging for the exact app name) from your smartphone's app store (App Store for iOS or Google Play Store for Android).

1. Search for the app name.
2. Download and install the app.
3. Register for a new account or log in if you already have one.

### 4.3 Connecting to Wi-Fi

The ANTELA C23 supports both 2.4GHz and 5GHz Wi-Fi networks. Ensure your smartphone is connected to the same Wi-Fi network you intend to connect the camera to.



Image: A smartphone displaying the camera's live feed, illustrating its compatibility with both 2.4GHz and 5GHz Wi-Fi networks for enhanced connectivity options.

1. Open the app and tap "Add Device" or the "+" icon.
2. Select your camera model from the list.
3. Follow the on-screen instructions to connect the camera to your Wi-Fi network. This usually involves scanning a QR code generated by the app with the camera lens or entering Wi-Fi credentials.
4. Wait for the camera to connect. A voice prompt or indicator light change will confirm successful connection.

### 4.4 Mounting the Camera

The camera can be placed on a flat surface or mounted to a wall or ceiling using the provided bracket.

1. Choose a suitable location with good Wi-Fi signal and a clear view.
2. If wall-mounting, use the bracket as a template to mark drill holes.
3. Drill holes, insert wall anchors (if necessary), and secure the bracket with screws.
4. Attach the camera to the bracket, ensuring it is firmly in place.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Live View and Pan/Tilt Control

Once connected, open the app and select your camera to view the live feed.

- **Live Feed:** Tap on the camera thumbnail to access the real-time video stream.
- **Pan/Tilt:** Use the directional controls within the app to remotely rotate the camera horizontally (355°) and vertically (90°) to adjust the viewing angle.

### 5.2 Two-Way Audio

The two-way audio feature allows you to listen and speak through the camera.

# Two-Way Audio

With a built-in microphone and speaker  
achieve the voice intercom

I'm playing with the dog!

What are you doing, honey?

works with alexa

works with Hey Google



*Image: A child interacting with the camera, demonstrating the two-way audio function which allows for speaking and listening through the device. The image also shows "Works with Alexa" and "Works with Hey Google" logos.*

- **Listen:** Tap the speaker icon in the app to hear audio from the camera's surroundings.
- **Speak:** Tap and hold the microphone icon to speak through the camera's built-in speaker. Release to stop speaking.

## 5.3 Motion Detection and Notifications

The camera can detect movement and send alerts to your smartphone.

# Improved motion detection

Receive real-time notification when moving objects are detected



*Image: A smartphone displaying a real-time motion detection notification, with children playing in the background, illustrating the camera's ability to alert users to detected movement.*

- **Enable/Disable:** Access the camera settings in the app to turn motion detection on or off.
- **Sensitivity:** Adjust the motion detection sensitivity to minimize false alarms.
- **Alerts:** Ensure app notifications are enabled on your smartphone to receive real-time alerts.

## 5.4 Night Vision

The camera automatically switches to night vision mode in low-light conditions.

# IR Distance 9M, Enhanced Night Vision



*Image: A clear, black-and-white image of a bedroom at night, demonstrating the camera's enhanced infrared night vision capability with an effective range of 9 meters.*

- **Automatic Activation:** Infrared LEDs provide clear black-and-white video in the dark.
- **Range:** Effective night vision range is up to 9 meters.

## 5.5 Video Recording and Storage

The camera supports continuous recording or event-based recording, stored either locally or in the cloud.

# Video recording and playback

Support cloud and micro SD card storage



*Image: A diagram illustrating the camera's video recording and playback options, including support for cloud storage and a Micro SD card slot for local storage up to 128GB.*

- **Micro SD Card:** Insert a Micro SD card (up to 128GB, not included) into the camera's slot for local storage. Format the card via the app if prompted.
- **Cloud Storage:** The app may offer optional cloud storage plans for secure off-site backup of your recordings. Refer to the app for subscription details.
- **Playback:** Access recorded videos through the app's playback feature, typically found in the camera's timeline or event list.

## 5.6 Smart Home Integration

Integrate your ANTELA C23 camera with Amazon Alexa or Google Home for voice control and smart routines.

- **Alexa/Google Home Setup:** Follow the instructions in your Alexa or Google Home app to enable the camera's skill/service and link your account.
- **Voice Commands:** Use voice commands to view the camera feed on compatible smart displays (e.g., "Alexa, show me the living room camera").

## 6. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid harsh chemicals or abrasive materials.
- **Firmware Updates:** Regularly check the app for firmware updates. Keeping your camera's firmware up-to-date ensures optimal performance and security.
- **Storage Management:** If using a Micro SD card, periodically review and delete old recordings to free up space, or ensure loop recording is enabled if desired.

## 7. TROUBLESHOOTING

---

### Camera fails to connect to Wi-Fi:

- Ensure your Wi-Fi network is 2.4GHz or 5GHz and stable.
- Verify the Wi-Fi password is correct.
- Move the camera closer to the router during setup.
- Reset the camera (refer to the app or camera for reset button location) and try again.

### No motion detection alerts:

- Check if motion detection is enabled in the app settings.
- Adjust the sensitivity level.
- Ensure app notifications are enabled on your smartphone.
- Verify the camera has a stable internet connection.

### Poor video quality:

- Ensure the camera lens is clean.
- Check your internet connection speed. A weak signal can affect streaming quality.
- Adjust video quality settings in the app if available.

### Two-way audio not working:

- Ensure microphone and speaker permissions are granted to the app on your smartphone.
- Check the volume settings in the app and on your phone.
- Verify the camera's internet connection is stable.

## 8. SPECIFICATIONS

---

Feature	Specification
Model Number	C23
Video Resolution	1080P Full HD
Wireless Connectivity	Wi-Fi (2.4GHz/5GHz)
Pan Angle	355 Degrees
Tilt Angle	90 Degrees
Night Vision	Infrared (IR), up to 9 meters

Feature	Specification
Two-Way Audio	Yes
Motion Detection	Yes
Storage Options	Cloud Storage, Micro SD Card (Max 128GB)
Power Input	5 Volts, 6 Watts
Mounting Type	Wall Mount Bracket
Material	Metal
Dimensions (L x W x H)	8.5 x 18 x 14 cm
Weight	Approx. 1.4 kg (for 4-pack)
Compatible Devices	Smartphone, Amazon Alexa, Google Home
Indoor/Outdoor Use	Indoor

## 9. WARRANTY AND SUPPORT

Your ANTELA C23 camera system comes with a standard return policy. For specific warranty details, please refer to the product packaging or contact the seller directly.

For technical support, troubleshooting assistance, or any questions regarding your product, please contact ANTELA customer service through the retailer's platform or the contact information provided in the product packaging.

**Online Resources:** For additional support and FAQs, visit the ANTELA brand store on Amazon:[ANTELA Brand Store](#)