

## ECONTROLLY SENUO-8IN1-AR-REM1U

# Replacement Remote Commander User Manual

Model: SENUO-8IN1-AR-REM1U

## INTRODUCTION

This user manual provides instructions for the ECONTROLLY Replacement Remote Commander, designed for use with various Fujitsu Air Conditioner models. This remote offers a direct replacement solution, requiring no complex programming or pairing for compatible units. It supports temperature display in both Celsius and Fahrenheit.

## PACKAGE CONTENTS

- 1 x Infrared Remote Commander

## SETUP

### Battery Installation

The remote commander requires **two (2) 1.5V AAA alkaline batteries** (not included). To install the batteries:

1. Locate the battery compartment on the back of the remote.
2. Slide the battery cover downwards to open it.
3. Insert the two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with compatible Fujitsu Air Conditioner models. No programming or pairing is required for initial operation.





Image: Rear view of the remote control with the battery cover removed, revealing the battery slots for two AAA batteries.

## OPERATING INSTRUCTIONS

This remote commander features a primary set of buttons for common functions and a hidden panel for advanced controls.

Primary Controls





Image: Front view of the remote control, displaying the screen and primary buttons for basic operation.

- **Display Screen:** Shows current settings such as temperature, mode, and fan speed.
- **MIN. HEAT:** Activates the minimum heat function.
- **TEMP. (Up/Down Arrows):** Adjusts the desired temperature.
- **POWERFUL:** Activates the powerful mode for rapid cooling or heating.
- **Power Button (Orange):** Turns the air conditioner ON or OFF.

### Advanced Controls (Under Sliding Cover)

Slide the lower front panel downwards to reveal additional control buttons for advanced settings.





Image: Front view of the remote control with the lower panel slid open, exposing a full array of advanced function buttons.

- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **ENERGY SAVING PROGRAM:** Activates energy-saving settings.
- **FAN:** Adjusts fan speed.
- **ECONOMY:** Engages economy mode for reduced power consumption.
- **SENSOR:** Activates or deactivates the temperature sensor function.
- **SWING:** Controls the louver swing direction.
- **OUTDOOR UNIT LOW NOISE:** Reduces outdoor unit noise level.
- **SET:** Used for confirming settings.
- **WEEKLY:** Accesses weekly timer settings.
- **ON/OFF (Timer):** Sets the ON/OFF timer.
- **SLEEP:** Activates sleep mode.
- **TIMER SETTING:** Enters timer setting mode.
- **SELECT (Up/Down Arrows):** Navigates through menu options.
- **NEXT:** Moves to the next setting option.
- **SEND:** Sends the current setting to the air conditioner.
- **BACK:** Returns to the previous menu or setting.
- **CLOCK ADJUST:** Adjusts the remote's internal clock.

- **°C/°F:** Toggles temperature display between Celsius and Fahrenheit.
- **RESET:** Resets the remote to default settings.

## MAINTENANCE

---

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the display becomes dim or the remote's response is sluggish. Always replace both batteries simultaneously with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote to direct sunlight, high temperatures, humidity, or strong impacts.

## TROUBLESHOOTING

---

### Remote Not Responding or Air Conditioner Not Reacting

If the remote does not seem to work or the air conditioner does not respond to commands, follow these steps:

1. **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity and are not depleted. Replace with new 1.5V AAA alkaline batteries if necessary.
2. **Line of Sight:** Ensure there is a clear line of sight between the remote's infrared emitter and the air conditioner's receiver. Obstructions can block the signal.
3. **Distance:** Make sure you are within the effective operating range of the air conditioner's receiver.
4. **Custom Code Setting (If Applicable):** Some universal replacement remotes may require setting a custom code if the default operation does not work. Refer to the instructions on the back of the remote for this process.






Image: Rear view of the remote control, showing a label with instructions for setting a custom code if the remote does not work immediately.

#### Custom Code Setting Instructions (from remote label):

If the remote doesn't work, please set the remote custom code as the following steps:

1. Aim the remote control at the signal receiver on the air conditioner. Press and hold the **Power** button for 4 seconds to show the current custom code.
2. Press the **TEMP. Up/Down** button to change the code (e.g., 01-08, initially set to 01).
3. Press the **Power** button again to confirm the code. When the air conditioner reacts, the code is set.

Please check whether the functions work well or not. If not, please repeat the above steps to try other codes. If it still won't work, you may need to order the correct remote control. Please contact us for assistance.

## SPECIFICATIONS

|              |                     |
|--------------|---------------------|
| Model Number | SENUO-8IN1-AR-REM1U |
| Brand        | ECONTROLLY          |

|                    |                                                |
|--------------------|------------------------------------------------|
| Compatible Devices | Fujitsu Air Conditioners                       |
| Power Source       | 2 x 1.5V AAA Alkaline Batteries (not included) |
| Product Dimensions | 5.91 x 1.57 x 0.59 inches                      |
| Item Weight        | 1.41 ounces                                    |
| Color              | White                                          |
| Special Feature    | Ergonomic                                      |
| Country of Origin  | China                                          |

## COMPATIBLE MODELS

This remote commander is compatible with a wide range of Fujitsu Air Conditioner models, including but not limited to:

- AR-REM1U, AR-RED1U, AR-REF1U, AR-REC1U, AR-REY1U, AR-REG1U
- AR-REF3E, AR-REM5E, AR-REM6E
- UTY-RVNUM, UTY-LNHUM, UTY-LRHUM, UTY-RNBYU, UTY-RNNUM, UTY-RSNUM
- AASU9RLS3, ASU9RLS3Y, ASU12RLS3Y, ASU15RLS3Y, ASU30RLE
- ASUG12LZAS, ASUG09LZAS, ASUG15LZAS
- ASUG09LZBS, ASUG12LZBS, ASUG15LZBS
- AOU9RLS3H, AOU12RLS3H, AOU15RLS3H, AOU30RLXEH
- AOUG09LZAS1, AOUG15LZAS1, AOUG12LZAS1

## WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ECONTROLLY Replacement Remote Commander, please contact the seller or manufacturer directly through your purchase platform. Please refer to your purchase receipt for specific warranty information.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question