

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EverBrite](#) /

› [EverBrite E007099AE LED Motion Sensor Night Light User Manual](#)

EverBrite E007099AE

EverBrite E007099AE LED Motion Sensor Night Light User Manual

Model: E007099AE | Brand: EverBrite

INTRODUCTION

Thank you for choosing the EverBrite LED Motion Sensor Night Light. This manual provides essential information for the safe and efficient use of your new night lights. Please read these instructions carefully before installation and operation, and retain them for future reference.

WHAT'S IN THE BOX

Verify that all components are present before proceeding with installation.

- 6 x RGB Motion Sensor Night Lights
- 6 x Adhesive Iron Sheets
- 6 x Lanyards
- 18 x AAA Batteries (pre-installed or included separately)




Image: All components included in the EverBrite 6-pack, neatly arranged.

SETUP: BATTERY INSTALLATION

Your EverBrite LED Motion Sensor Night Lights require 3 AAA batteries each. Batteries are included with your purchase.

- 1. Open the Battery Compartment:** Gently twist the back cover of the night light counter-clockwise to unlock and remove it.
- 2. Insert Batteries:** Insert 3 AAA batteries into the compartment, ensuring correct polarity (+/-) as indicated inside.
- 3. Close the Compartment:** Replace the back cover and twist clockwise until it locks securely into place.



Image: Visual instructions for installing AAA batteries into the night light.

OPERATING INSTRUCTIONS

Motion Sensor Activation

The night light features a sensitive motion sensor with a detection range of up to 13 feet and a 125° sensing angle. It activates when motion is detected in environments with light between 10-50 LUX (dim indoor settings) or full natural light conditions below 10 LUX. The light will automatically turn off after 15-25 seconds of no motion detected to conserve battery life.

SENSITIVE MOTION SENSOR

The light activates with motion in indoor environments between 10-50 lux, or below 10 lux in full natural light.




Image: Demonstration of the motion sensor's detection range and angle in a kitchen setting.

Dimmable & Color Options

The night light offers adjustable brightness and 16 color options (cool white and 15 RGB colors).

- **Change Color:** Tap the finger symbol on the light to cycle through cool white and 15 RGB colors.
- **Adjust Brightness (Dimming):** Hold the finger symbol to activate stepless dimming. Brightness can be adjusted up to 10 lumens, providing sufficient light for a 13-foot distance.

ADJUSTABLE LIGHT SETTINGS



Tap to switch between 16 colors (RGB & White)

Long press for stepless dimming



Image: Instructions for changing colors and dimming the night light using the touch sensor.

Product Overview Video

Your browser does not support the video tag.

Video: An official product video from EverBrite showcasing the features and functionality of the LED Motion Sensor Night Light, including its color-changing and motion-sensing capabilities.

Color Options Demonstration Video

Your browser does not support the video tag.

Video: An official product video from EverBrite demonstrating the 15 RGB color options and cool white light available with the motion sensor night lights.

INSTALLATION METHODS

The EverBrite LED Motion Sensor Night Light offers three versatile installation methods:

- 1. Magnet Adsorption:** The light has a built-in magnet, allowing it to be directly attached to any iron surface.
- 2. Stick On:** Use the provided adhesive iron sheets. Peel off the protective backing from an adhesive

sheet, stick it to your desired surface, and then attach the night light magnetically to the sheet.

3. **Hanging:** Utilize the included lanyards. Attach a lanyard to the designated loop on the night light and hang it in your preferred location.

3 INSTALLATION METHODS

Multiple installation methods provide more convenience



Image: Visual guide for the three installation methods: magnetic, adhesive, and hanging.

SPECIFICATIONS

Feature	Detail
Model Number	E007099AE
Brand	EverBrite
Light Source Type	LED
Light Color Options	15 RGB colors, Cool White
Dimmable	Yes (Stepless dimming up to 10LM)
Motion Sensor Range	Up to 13 feet
Sensing Angle	125°

Auto-off Timer	15-25 seconds (after no motion detected)
Power Source	Battery Powered (3 x AAA per light, included)
Material	Plastic
Product Dimensions	3.47"D x 3.14"W x 0.86"H
Weight	1.26 pounds (total for 6-pack)
Mounting Type	Wall Mount (Magnet, Adhesive, Hanging)
Indoor/Outdoor Usage	Indoor



Image: Detailed dimensions and key features of the EverBrite night light.

MAINTENANCE

- Cleaning:** Wipe the surface of the night light with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- Battery Replacement:** Replace all three AAA batteries when the light output diminishes or the motion sensor becomes less responsive. Ensure correct polarity during replacement.
- Storage:** If storing the night lights for an extended period, remove the batteries to prevent leakage.

and damage.

TROUBLESHOOTING

- **Light not turning on:**

- Check battery installation and ensure batteries are fresh.
- Verify the ambient light conditions. The sensor activates in dim light or darkness.
- Ensure the motion sensor is not obstructed.

- **Light stays on constantly:**

- Check for continuous motion within the sensor's range.
- Ensure the ambient light is not too low, causing the sensor to remain active.

- **Motion sensor not detecting:**

- Confirm the light is in an area with sufficient darkness for activation.
- Check the distance and angle of detection.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the packaging or contact EverBrite customer service directly. Keep your purchase receipt for warranty claims.

© 2026 EverBrite. All rights reserved.