

manuals.plus /

› [Rohent](#) /

› [Rohent Q1 Portable Hands-Free Neck Fan Instruction Manual](#)

Rohent Q1

Rohent Q1 Portable Hands-Free Neck Fan Instruction Manual

Model: Q1

1. INTRODUCTION

Thank you for choosing the Rohent Q1 Portable Hands-Free Neck Fan. This device is designed to provide personal cooling with convenience and efficiency. Featuring a 4000mAh battery, USB-C recharging, ultra-quiet operation, and 4 adjustable speeds, it is suitable for various environments including offices, outdoor activities, and travel. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image 1.1: The Rohent Q1 Portable Hands-Free Neck Fan in black, showcasing its ergonomic design and airflow vents.

2. SAFETY INFORMATION

- **Read all instructions:** Before operating the device, familiarize yourself with all instructions and warnings.
- **Keep away from water:** Do not immerse the fan in water or expose it to heavy rain.
- **Avoid foreign objects:** Do not insert fingers or any objects into the fan blades or vents. This product contains exposed fan blades; users with long hair should secure it to prevent entanglement.
- **Charging safety:** Use only the provided USB-C cable and a compatible 5V/2A adapter for charging. Do not use damaged cables or chargers.
- **Battery care:** Do not disassemble, puncture, or expose the battery to extreme temperatures.
- **Children and pets:** Keep the device out of reach of small children and pets to prevent accidental injury or damage.
- **Storage:** Store the fan in a cool, dry place when not in use.

Great Gift Choice



Image 2.1: Illustration highlighting the fan's design to prevent hair or beard entanglement.

3. PRODUCT OVERVIEW

3.1 Components

- Flexible Neckband
- Dual Fan Units with Air Vents
- Power/Speed Control Buttons (on both sides)
- USB-C Charging Ports (on both sides)
- Soft Silicone Padding

3.2 Key Features

- **4000mAh Battery:** Provides 5-16 hours of cooling, depending on the speed setting.
- **USB-C Rechargeable:** Fast and efficient charging with dual-head Type-C cable.
- **Ultra-Quiet Operation:** Operates at whisper-quiet levels, suitable for various environments.
- **4 Adjustable Speed Settings:** Customize airflow from a gentle breeze to strong wind.
- **360° Cooling Design:** Strategically placed air vents provide consistent airflow around the neck and face.
- **Soft Silicone Padding:** Ensures comfort during extended wear.
- **Lightweight & Portable:** Easy to carry and wear for hands-free cooling.



Image 3.1: Diagram illustrating the 360-degree airflow design for comprehensive cooling.



Image 3.2: Close-up of the soft silicone padding on the neckband, designed for comfort and flexibility.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your Rohent Q1 Neck Fan. The device comes with two 2000mAh batteries (total 4000mAh) and two USB-C charging ports, one on each side.

1. Locate the USB-C charging ports on both sides of the fan.
2. Connect the provided dual-head USB-C cable to both charging ports on the fan.
3. Connect the other end of the USB-C cable to a 5V/2A power adapter (not included) or a compatible USB power source.
4. The charging indicator lights will illuminate. A full charge typically takes approximately 4 hours.
5. Once fully charged, disconnect the cable.



Image 4.1: Diagram illustrating the dual 2000mAh batteries and simultaneous USB-C charging for efficient power delivery.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Fan

Gently widen the flexible neckband and place it around your neck. The soft silicone padding ensures a comfortable and secure fit. Adjust the fan units for optimal airflow towards your face and neck.

Outer Duct Aerodynamic Design

Can blow cold air evenly around the whole neck

Free your
hands



Image 5.1: A person wearing the Rohent Q1 Neck Fan, demonstrating its hands-free design and comfortable fit.

5.2 Power On/Off and Speed Adjustment

The Rohent Q1 features power/speed control buttons on both sides for convenient operation.

1. **To Power On:** Press and hold either power button for approximately 2 seconds. The fan will start at Speed 1 (Soft Wind).
2. **To Adjust Speed:** Briefly press either power button to cycle through the 4 speed settings:
 - Speed 1: Soft Wind
 - Speed 2: Cool Wind
 - Speed 3: Strong Wind
 - Speed 4: Strongest Wind
3. **To Power Off:** Press and hold either power button for approximately 2 seconds from any speed setting.



Image 5.2: Visual representation of the 4 adjustable speed settings and the synchronized dual-side control buttons for ease of use.

6. MAINTENANCE

6.1 Cleaning

- Ensure the fan is powered off and disconnected from any charging source before cleaning.
- Wipe the exterior of the fan with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Do not rinse the fan directly under water.
- Periodically check the air intake and exhaust vents for dust or debris. Use a soft brush or compressed air to gently clear any blockages.

6.2 Storage

- When not in use for an extended period, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to charge the battery to approximately 50% before long-term storage to preserve battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully using the provided USB-C cable and a 5V/2A adapter.
Weak airflow.	Fan is on a low speed setting. Vents are obstructed.	Increase the speed setting. Check and clear any obstructions from the air intake/exhaust vents.
Fan makes unusual noise.	Debris in fan blades.	Power off the fan and gently remove any visible debris from the fan blades using a soft brush.

Problem	Possible Cause	Solution
Hair gets caught in fan.	Long hair is not secured.	Secure long hair (e.g., tie it back) before wearing the fan to prevent entanglement.
Fan not charging.	Cable or adapter issue. Ports are dirty.	Ensure the USB-C cable and adapter are functioning correctly. Try a different cable/adapter. Clean charging ports gently with a dry, soft brush.

8. SPECIFICATIONS

Model Name	Q1
Brand	Rohent
Battery Capacity	4000mAh (2 x 2000mAh Lithium Ion)
Battery Life	5-16 hours (depending on speed setting)
Charging Port	USB-C (dual-head charging)
Charging Time	Approx. 4 hours (with 5V/2A adapter)
Speed Settings	4 levels
Motor Speed	Up to 8000 RPM (High-speed brushless motor)
Noise Level	20 Decibels
Wattage	10 watts
Voltage	5 Volts
Product Dimensions	9.68"D x 2.1"W x 7.9"H
Item Weight	1.06 pounds
Included Components	1* Neck Fan, 1* USB Cable, 1* User Manual

9. WARRANTY AND SUPPORT

Rohent products are manufactured with high-quality materials and undergo strict quality control. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit the official Rohent website. Please retain your proof of purchase for warranty claims.