

Lamshaw KT71

Lamshaw Magnetic Smart Watch Charger User Manual

Compatible with NONGAMX KT71, KLOGIPOW KT71, PAKRYS KT71 Smart Watches

1. INTRODUCTION

Thank you for choosing the Lamshaw Magnetic Smart Watch Charger. This charger is specifically designed to provide a safe and convenient charging solution for your NONGAMX KT71, KLOGIPOW KT71, or PAKRYS KT71 Smart Watch. This manual provides essential information on how to set up, operate, and maintain your charger, along with important safety guidelines.

Please read this manual thoroughly before using the product to ensure proper function and longevity.

2. PRODUCT OVERVIEW

The Lamshaw Magnetic Smart Watch Charger features a magnetic connection for easy and secure attachment to your compatible smartwatch. It includes built-in short-circuit protection to safeguard your device against overvoltage and overcurrent conditions.

Key Features:

- **Magnetic Connection:** Ensures a stable and reliable charge.
- **Safety Protection:** Integrated IC for short-circuit, overvoltage, and overcurrent protection.
- **Portability:** Compact and lightweight design for easy transport.
- **Compatibility:** Specifically designed for NONGAMX KT71, KLOGIPOW KT71, and PAKRYS KT71 Smart Watches.



Image: The Lamshaw magnetic smart watch charger cable, white color, showing the USB-A connector and the magnetic charging puck with two gold pins.

3. SETUP AND CHARGING INSTRUCTIONS

3.1 Connecting the Charger

1. Connect the USB-A end of the charging cable to a compatible power source, such as a computer USB port, a laptop, a power bank, or a wall charger (5V/1A recommended).
2. Ensure the power source is active.



Power bank



Wall charger



Computer





Laptop

Image: Illustration showing the charger connected to a computer, laptop, power bank, and wall charger, demonstrating various compatible power sources.

3.2 Charging Your Smart Watch

1. Align the magnetic charging puck with the charging contacts on the back of your NONGAMX KT71 series smart watch. The magnets will automatically snap into place.
2. Ensure the charging magnets attract correctly. If the magnets repel, the device will not charge. Adjust the orientation of the charging puck until a secure magnetic connection is established.
3. Once connected, your smart watch display will show a charging indicator, typically a battery icon with a charging animation or percentage.
4. Charging time may vary depending on the watch's battery level and the power source.

Magnetic Charging Interface



If the charging magnets repel, the device will not charge.



You can charge correctly if the magnets attract whilst charging,



While charging

Image: Diagram illustrating the magnetic charging interface, showing correct and incorrect magnetic alignment for charging, and the charging status display on the smartwatch.

Your browser does not support the video tag.

Video: This video demonstrates the correct method for connecting the magnetic charger to a smartwatch, showing the magnetic alignment and the charging indication on the watch screen.

4. SAFETY INFORMATION

- Do not expose the charger to water or excessive moisture.
- Avoid extreme temperatures. Do not use or store the charger in very hot or cold environments.
- Do not attempt to disassemble or modify the charger. This may cause damage and void any warranty.
- Keep out of reach of children.
- Unplug the charger from the power source when not in use or during electrical storms.
- The built-in short-circuit protection IC will automatically cut off the circuit in case of a short-circuit or if the charger is left plugged in after the device is fully charged, ensuring safety.

5. TROUBLESHOOTING

Smart Watch is Not Charging:

- **Check Magnetic Connection:** Ensure the magnetic charging puck is correctly aligned and securely attached to the smartwatch's charging contacts. If the magnets repel, reverse the orientation of the charging puck.
- **Verify Power Source:** Make sure the USB-A end of the cable is firmly plugged into a working USB port or power adapter. Try a different USB port or power adapter if available.
- **Inspect Cable:** Check the charging cable for any visible damage or kinks.
- **Clean Contacts:** Ensure the charging contacts on both the charger and the smartwatch are clean and free of dust or debris.

6. SPECIFICATIONS

Brand	Lamshaw
Compatible Devices	NONGAMX KT71, KLOGIPOW KT71, PAKRYS KT71 Smart Watches
Connector Type	USB-A to Magnetic Pogo Pin
Input Voltage	5 Volts
Output Voltage	5 Volts
Output Current	1 Amps
Special Feature	Short Circuit Protection, Overvoltage Protection, Overcurrent Protection
Cable Length	100cm (3.3 feet)
Color	White

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact your retailer. Keep your purchase receipt as proof of purchase.

If you encounter any issues not covered in this manual, please reach out to customer service for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D8BMHG45>

More documents and user manuals: **<https://manuals.plus/>**