

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Waleaf](#) /
- › [Waleaf Fireplace TV Stand with 18" Electric Fireplace User Manual](#)

## Waleaf 58TVS

# Waleaf Fireplace TV Stand User Manual

Model: 58TVS

## 1. INTRODUCTION

---

Thank you for purchasing the Waleaf Fireplace TV Stand. This product combines a modern entertainment center with an integrated 18-inch electric fireplace, offering both functional storage and ambient heating. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your TV stand.

Please read this manual thoroughly before assembly and use, and retain it for future reference.

## 2. SAFETY INFORMATION

---

**WARNING: Important Safety Instructions. Read and understand all instructions before using this appliance.**

- Always unplug the electric fireplace from the power outlet before cleaning, performing maintenance, or relocating the unit.
- Do not operate the fireplace with a damaged cord or plug, or if the heater has malfunctioned, been dropped, or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This TV stand is designed for indoor use only.
- Ensure the TV stand is placed on a level, stable surface to prevent tipping.
- Do not exceed the maximum weight capacity of 300 pounds for the top surface.
- Assembly requires two people. Follow all assembly steps carefully.

## 3. PACKAGE CONTENTS

---

Your Waleaf Fireplace TV Stand will arrive in two separate boxes. Please ensure you have received both packages before beginning assembly. Carefully unpack all components and verify against the parts list provided in the

included assembly instructions. If any parts are missing or damaged, contact customer service immediately.

- 58-inch TV Stand components (Box 1)
- 18-inch Electric Fireplace insert (Box 2)
- Remote Control for Electric Fireplace
- Assembly Hardware Kit
- Detailed Assembly Instructions Manual



**TIPS: This Cabinet Comes With 2 Boxes**



Image: The product is shipped in two separate boxes, labeled Box 1 and Box 2, indicating the need to receive both for complete assembly. The image also shows the overall dimensions of the fireplace insert.

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Waleaf Fireplace TV Stand requires careful attention to detail and is best performed by two adults. Please follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all parts are present and undamaged before starting.

**Key Assembly Features:**

- **Durable Construction:** The TV stand is constructed from MDF (Medium-Density Fiberboard) with a classic wood grain finish, designed for durability and scratch resistance.
- **Adjustable Glass Shelves:** The side compartments feature four adjustable tempered glass shelves, allowing customization of storage space for media players, game consoles, and decorative items.
- **Cable Management:** Integrated cable holes in the back panel help organize and conceal wires, maintaining a tidy appearance.



Adjustable glass shelves provide you with more free storage and display space





Image: Detail showing the adjustable glass shelves within the TV stand's side compartments, illustrating how they can be positioned at different heights.

# Premium MDF Board

## Grain Design



**Breathable**



**Easy to  
clean**



**Good load  
bearing**



**Wear  
resistant**

Image: A close-up view of the cable management hole located on the back panel of the TV stand, designed to help organize electronic device wiring.

## 5. OPERATING INSTRUCTIONS

### 5.1. TV Stand Usage

- Place your television on the top surface. This stand is suitable for TVs up to 65 inches and can support up to 300 pounds.
- Utilize the open storage compartments and adjustable glass shelves for media devices, gaming consoles, books, or decorative items.
- Route power cords and signal cables through the designated cable holes to maintain a neat and organized appearance.

### 5.2. LED Lighting System

The TV stand features built-in LED lights with 6 different color options to enhance your living space. The LED lights are typically controlled via a remote control or a switch on the unit. Refer to the specific instructions for the LED

lighting system included in your package for detailed operation.



Image: The TV stand showcasing its integrated LED lighting system, capable of displaying multiple colors, along with the remote control used to operate these lighting features.

### 5.3. Electric Fireplace Operation

The 18-inch electric fireplace provides warmth and ambiance. It can be operated with or without heat, allowing for year-round enjoyment of the flame effect. Use the included remote control or the control panel on the fireplace unit to adjust settings.

- **Power ON/OFF:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Choose between 750W (energy-saving) and 1500W (adequate heating) options. The heating area covers up to 400 square feet.
- **Timer Function:** Set the operational timer for 1 to 8 hours.
- **Flame Colors:** Select from 12 different flame colors to match your mood or decor.
- **Flame Brightness (Dimmer):** Adjust the brightness of the flame effect (5 levels).
- **Flame Speed:** Adjust the speed of the flame effect (5 levels).



Image: A detailed view of the electric fireplace's control panel, highlighting settings for heater power, timer, dimmer, flame speed, and power. Below, a visual representation of the five flame brightness levels (L1 to L5) is shown.

## 6. MAINTENANCE

### 6.1. TV Stand Care

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- For glass shelves, use a standard glass cleaner.
- Periodically check all hardware connections and tighten if necessary.
- Keep the TV stand away from direct sunlight and excessive moisture to prevent warping or discoloration.

### 6.2. Electric Fireplace Care

- Ensure the fireplace is unplugged and cool before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or spray liquids directly onto the unit.
- Keep the air intake and exhaust vents clear of dust and debris to ensure proper airflow and prevent overheating.

## 7. TROUBLESHOOTING

---

If you encounter issues with your Waleaf Fireplace TV Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord loose, circuit breaker tripped.	Check if the unit is plugged in securely. Verify the wall outlet is functional. Reset the circuit breaker if necessary.
No heat from fireplace.	Heat function not activated, thermostat setting too low, safety cut-off activated.	Ensure the heat setting (750W/1500W) is selected. Increase the thermostat setting. Unplug the unit for 5 minutes to reset the safety cut-off, then plug back in.
Flame effect not visible or flickering.	Flame brightness set too low, LED bulb issue.	Adjust the flame brightness setting using the remote or control panel. If the issue persists, contact customer support.
LED lights on TV stand not working.	Power connection loose, remote battery low, LED strip damage.	Check the power connection for the LED lights. Replace remote batteries. If still not working, contact customer support.
TV stand feels unstable.	Uneven floor, loose assembly hardware.	Ensure the stand is on a level surface. Re-tighten all assembly screws and bolts.

For issues not covered here, please refer to the detailed troubleshooting section in your separate assembly manual or contact Waleaf customer service.

## 8. SPECIFICATIONS

---

Feature	Specification
Brand	Waleaf
Model Name	W58-TV (Item model number: 58TVS)
Product Dimensions (Overall)	15.75"D x 58.07"W x 24.06"H
Material	Engineered Wood (MDF), Tempered Glass
Color	Brown
Finish Type	Polished
Installation Type	Freestanding
Item Weight	80 Pounds

Feature	Specification
Max TV Size Supported	Up to 65 inches
Max Weight Capacity (Top)	300 Pounds
Electric Fireplace Size	18 inches
Power Source	Corded Electric
Heat Settings	750W / 1500W
Heating Coverage	Up to 400 sq ft
Timer Function	1-8 hours
Flame Colors	12 options
LED Lights (TV Stand)	6 color options
Included Components	18" Electric Fireplace, 58" TV Stand, Instructions, Remote Control

## 9. WARRANTY AND SUPPORT

---

Waleaf provides a limited warranty for this product. Please refer to the warranty information included in your product packaging for specific terms and conditions. For any questions, missing parts, or assistance with assembly or operation, please contact Waleaf customer service. Your satisfaction is important to us.

For customer service inquiries, please refer to the contact information provided in your product's packaging or visit the official Waleaf website.