PoundMax 1000122641

Onn 10" Dual Screen Portable DVD Player Kit Instruction Manual

Model: 1000122641
Brand: PoundMax

Introduction

This manual provides comprehensive instructions for the Onn 10" Dual Screen Portable DVD Player Kit. This kit allows for maximized entertainment with two 1024 x 600 native resolution LCD screens, perfect for on-the-go use. It supports DVD, DVD±R/RW, CD, and CD-R/RW formats. The kit includes a remote control, audio/video cables, power adapters, earbuds, headrest straps, and a carry case.

Figure 1: Onn 10" Dual Screen Portable DVD Player Kit. The image displays both screens, one with visible controls, showing an underwater scene.

Setup

Mounting the Screens

The DVD players can be easily mounted using the adjustable headrest straps. Securely fasten the straps around the vehicle's headrests. Ensure the screens are stable and do not obstruct the driver's view.

Power Connection

Connect the primary unit to a 12V DC car adapter (cigarette lighter port) using the provided AC/DC power adapter. The secondary unit connects to the primary unit via the DC to DC connection cable to share power and video signal.

Connecting Screens

Use the 3.5mm audio/video cable to connect the primary unit to the secondary unit. This allows both screens to display the same content from the primary DVD player.

Operating Instructions

Inserting a Disc

Press the **OPEN** button on the primary unit to open the disc tray. Insert your DVD or CD with the label side facing up. Close the disc tray gently.

Playback Controls (Primary Unit)

- **Play/Pause:** Press the **Play/Pause** button to start or pause playback.
- **Source:** Use the **Source** button to switch between DVD/CD playback and external inputs (USB/SD/MMC card).
- **Volume:** Adjust the volume using the **Volume +** and **Volume -** buttons.
- **Next/Previous:** Use the arrow buttons to navigate between tracks or chapters.

Secondary Unit Controls

- **Display On/Off:** Turn the secondary screen display on or off without unplugging the unit.
- **Mute:** Mute the audio output from the secondary unit.
- **Display Setup:** Access display settings for the secondary screen.
- **Volume:** The secondary unit has independent volume controls, allowing individual adjustment for the viewer.

Headphone Use

Both units feature a 3.5mm headphone jack. Plug in the provided earbuds or your own headphones for private listening. Volume can be adjusted independently for each screen when headphones are used.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screens and exterior. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle discs by the edges. Keep them clean and free of scratches to ensure optimal playback.
- **Storage:** When not in use, store the DVD player kit in the provided carry case to protect it from dust and damage. The carry case has compartments for screens, cables, and DVDs.

Troubleshooting

No Power

- Ensure the power adapter is securely plugged into both the unit and the 12V DC car adapter.
- Check the vehicle's 12V DC outlet for power.

No Picture/Sound on Secondary Screen

- Verify the DC to DC connection cable and the 3.5mm audio/video cable are properly connected between the primary and secondary units.
- Check the "Display On/Off" setting on the secondary unit.

Disc Not Playing

- Ensure the disc is clean and free of scratches.
- Verify the disc is inserted correctly with the label side up.
- Confirm the disc format (DVD, CD) is supported. This is a DVD player, not a Blu-ray player.

Specifications

Feature	Detail
Screen Size	10 inches (Dual TFT LCD color displays)
Resolution	1024 x 600 native resolution
Aspect Ratio	16:9
Supported Media	DVD, DVD±R/RW, CD, CD-R/RW
Connectivity	USB, SD/MMC Card, 3.5mm Audio/Video In/Out, DC Power In/Out
Audio	Built-in stereo speakers, Stereo headphone jack
Power Source	AC/DC power adapter, 12V DC car adapter
Dimensions	14 x 5 x 10 inches
Weight	4.9 pounds

Warranty and Support

For customer support information, including warranty details and technical assistance, please refer to the contact information provided on the product packaging or the official Onn website. The video mentions customer support is available from 7 AM - 9 PM CST by calling 1-888-516-2630.
Protection plans are available for purchase separately to extend coverage beyond the standard warranty period. These include 2-Year and 3-Year Protection Plans, as well as a Complete Protect plan.

© 2024 PoundMax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why can't I play a DVD on my Onn 10" Dual Screen Portable DVD Player (Model 1000122641) after being prompted to select a language?

If your Onn 10" Dual Screen Portable DVD Player (Model 1000122641) is stuck on a language selection screen or will not play after selecting one, please try the following steps:Use the Remote Control: The...

Read full answer

Why do I see a loading error when trying to load a disc on my Onn 10" Dual Screen Portable DVD Player (Model 1000122641)?

If you are seeing a loading error on your Onn 10" Dual Screen Portable DVD Player (Model 1000122641), please check the following troubleshooting steps based on the manual:Check Disc Format: Ensure you are not...

Read full answer