

LIZRROT B0D8J2T1X3

LIZRROT Ergonomic Wireless Keyboard and Mouse Combo User Manual

Model: B0D8J2T1X3 | Brand: LIZRROT

INTRODUCTION

Thank you for choosing the LIZRROT Ergonomic Wireless Keyboard and Mouse Combo. This product is designed to enhance your productivity and comfort with its ergonomic design, silent operation, and convenient features like a built-in phone holder. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Please check the package contents carefully upon unboxing:

- 1 x LIZRROT Ergonomic Wireless Keyboard
- 1 x LIZRROT Wireless Mouse
- 1 x 2.4 GHz USB Receiver
- 1 x User Manual (this document)

Note: AAA batteries for the keyboard and mouse are not included and must be purchased separately.

SETUP GUIDE

1. Installing Batteries

For the Keyboard:

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert 1 AAA battery, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

For the Mouse:

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

2. Connecting the USB Receiver

The LIZRROT keyboard and mouse combo uses a single 2.4 GHz USB receiver for both devices.

1. Locate the 2.4 GHz USB receiver, typically stored in the mouse's battery compartment or packaged separately.
2. Plug the USB receiver into an available USB port on your computer (PC, laptop, Chromebook, etc.).
3. Turn on the power switch on both the keyboard and the mouse. The power switch for the keyboard is usually located near the indicator lights, and for the mouse, it's on the underside.
4. The devices should automatically connect to your computer within a few seconds. No additional software or drivers are required for installation.



Image: The LIZRROT Ergonomic Wireless Keyboard and Mouse Combo, showing the keyboard with a phone in its holder, the mouse, and the small USB receiver. This illustrates the components included and their general appearance.



SILENT AND DURABLE

Keep focus without disturbing others

Image: A close-up of the keyboard and mouse, highlighting the power switch on the keyboard and indicating battery requirements (1 AAA for keyboard, 2 AAA for mouse). This image helps users locate the power switch and understand battery installation.

OPERATING INSTRUCTIONS

Keyboard Usage

The keyboard features a full-size layout with a comfortable ergonomic design and a generous palm rest to reduce wrist strain.



ERGONOMIC MAKES LIFE BETTER

High-tech Design Palm Rest Keeps Wrists Injury-free

Image: A user's hands positioned comfortably on the LIZRROT ergonomic keyboard, demonstrating the natural hand placement facilitated by the design. This image emphasizes the ergonomic benefit.

Multimedia Shortcuts

The keyboard includes 6 independent multimedia keys and 12 F-keys with integrated media functions for quick access to common tasks:

- **F1-F12:** Standard function keys.
- **Dedicated Multimedia Keys:** Play/Pause, Previous Track, Next Track, Volume Down, Volume Up, Mute.
- **Other Shortcuts:** Internet browser, Email, My Computer, Calculator.




SMART POWER-SAVING

10 Mins Auto-Sleep (One Click to Active)

Image: A close-up of the top row of the LIZRROT keyboard, highlighting the multimedia keys and their functions. This visually explains the quick access features.

Phone/Tablet Holder

The integrated 8.7-inch phone holder allows you to conveniently place your smartphone or tablet directly on the keyboard for easy viewing of messages, videos, or other content while working.



8.7IN LARGE PHONE HOLDER

Hold Your Device To Work More Efficiently

Image: The LIZRROT keyboard with a smartphone placed in its integrated holder, demonstrating the convenience of this feature. The image also indicates the 8.7-inch size of the holder.

Mouse Usage

The wireless mouse offers silent clicks and adjustable DPI settings for precise control.

DPI Adjustment

The mouse features 3 adjustable DPI levels (800/1200/1600) to customize cursor sensitivity. Press the DPI button, usually located near the scroll wheel, to cycle through the settings.

- **800 DPI:** Slower cursor movement, ideal for precise tasks.
- **1200 DPI:** Standard cursor movement.
- **1600 DPI:** Faster cursor movement, suitable for quick navigation.

3 LEVELS DPI

There is a DPI adjustment button near the roller, you can adjust the DPI as you like.



Image: A close-up of the LIZRROT wireless mouse, illustrating the DPI adjustment button and the three available DPI settings (800, 1200, 1600). This helps users understand how to change mouse sensitivity.

POWER SAVING FEATURES

Both the keyboard and mouse are equipped with smart sleep modes to conserve battery life:

- **Keyboard Sleep:** If idle for 15 minutes, the keyboard will enter sleep mode.
- **Mouse Sleep:** If idle for 10 minutes, the mouse will enter sleep mode.

To wake up either device, simply press any button on the mouse or any key on the keyboard. For extended periods of non-use, it is recommended to turn off the power switches on both devices to maximize battery life.



23 MULTIMEDIA SHORTCUTS

Make Things Simple and Efficient

Image: A visual representation of the LIZRROT keyboard and mouse in a sleep state, with text indicating "Smart Sleep Mode" and details like "10 Mins Auto Sleep" and "Click Keys to Active." This reinforces the power-saving functionality.

MAINTENANCE

Cleaning

- Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Ensure no liquid enters the device.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the finish.

Battery Replacement

Replace batteries when performance degrades or the low battery indicator (if present) illuminates. Follow the battery installation steps outlined in the "Setup Guide" section.

Always dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Solution
Keyboard/Mouse not responding.	• Ensure batteries are correctly installed and not depleted. Replace if necessary. • Check if the power switch on both devices is turned ON. • Ensure the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port. • Move the keyboard and mouse closer to the USB receiver to ensure they are within the 33-foot (10m) wireless range. • Restart your computer.
Lag or intermittent connection.	• Reduce interference by moving other wireless devices (e.g., Wi-Fi routers, cordless phones) away from the receiver. • Ensure there are no large metal objects between the devices and the receiver. • Try plugging the USB receiver into a different USB port, preferably one on the front of your computer if using a desktop.
Mouse cursor erratic or not moving smoothly.	• Clean the optical sensor on the underside of the mouse. • Ensure you are using the mouse on a suitable surface (not highly reflective or transparent). A mouse pad is recommended. • Adjust the DPI setting using the DPI button on the mouse.
Keys are sticky or unresponsive.	• Gently clean around the affected keys with compressed air or a soft brush to remove debris. • Ensure no liquid has spilled on the keyboard.

SPECIFICATIONS

Feature	Detail
Connectivity	2.4 GHz Wireless (USB Receiver)
Wireless Range	Up to 33 feet (10 meters)
Keyboard Layout	Full-size with Numeric Keypad
Keyboard Power	1 x AAA Battery (not included)
Mouse Power	2 x AAA Batteries (not included)
Mouse DPI Levels	800 / 1200 / 1600

Feature	Detail
Compatibility	Windows XP/Vista/7/8/10/X, PCs, Laptops, Chromebooks
Special Features	Ergonomic Design, Silent Keys/Clicks, Integrated Phone Holder, Multimedia Shortcuts, Smart Sleep Mode
Color	Silver
Item Weight	1.92 pounds (approx. 0.87 kg)
Package Dimensions	17.36 x 10.87 x 1.61 inches (approx. 44.09 x 27.61 x 4.09 cm)

WARRANTY AND SUPPORT

LIZRROT is committed to providing high-quality products and excellent customer service.

- **Warranty:** This product comes with a one-year unconditional return and exchange policy.
- **After-Sales Service:** LIZRROT offers lifetime after-sales service for this product.

If you encounter any problems or have questions regarding your LIZRROT Ergonomic Wireless Keyboard and Mouse Combo, please contact our customer service team. You can typically find contact information on the product packaging or by visiting the LIZRROT store page on Amazon and clicking "Ask a question."

Your feedback is valuable and helps us improve our products and services.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question