

[manuals.plus](#) /

› [Ymiko](#) /

› **Ymiko Men's Back Hair Trimmer User Manual - Model Ymikohzngo38q1a**

Ymiko Ymikohzngo38q1a

Ymiko Men's Back Hair Trimmer User Manual

Model: Ymikohzngo38q1a

1. INTRODUCTION

Thank you for choosing the Ymiko Men's Back Hair Trimmer. This device is designed for efficient and comfortable hair removal on the back and other body parts. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.



Image 1.1: The Ymiko Men's Back Hair Trimmer, showcasing its sleek design.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Electric Back Trimmer

- 1 x Charging Base
- 1 x USB Cable
- 1 x Cleaning Brush
- 1 x Handle (Removable Curved Handle)
- 1 x User Manual (This document)



Image 2.1: All components included in the Ymiko Back Hair Trimmer package.

3. PRODUCT FEATURES

- **Extended Handle Design:** Provides a comfortable grip and enhanced control, facilitating access to hard-to-reach areas.
- **Effortless Hair Removal:** Engineered for a safe, fast, and comfortable shaving experience without pulling hairs.
- **Versatile Wet and Dry Use:** Suitable for use in the shower or in dry conditions, offering flexibility for grooming preferences.
- **Removable Curved Handle:** Ergonomically designed handle for independent grooming of the back and other body parts.
- **Built-in Lithium-ion Battery:** 500mAh capacity for cordless operation.

Removable curved handle design
Ergonomic design allows you to trim hard to reach areas of your back without help



Image 3.1: The trimmer with its removable curved handle, illustrating its ergonomic design for reaching the back.



**Wet and dry use
For use in the shower or
elsewhere in the home**

Image 3.2: The trimmer is suitable for both wet and dry use, allowing for flexible grooming environments.

4. SETUP AND CHARGING

4.1. Initial Charge

1. Connect the USB cable to the charging base.
2. Plug the other end of the USB cable into a suitable USB power adapter (not included) or a computer USB port.
3. Place the electric back trimmer onto the charging base. Ensure it is seated correctly.
4. Allow the device to charge fully before its first use. The indicator light on the trimmer will provide charging status (refer to the device for specific light indications).

4.2. Attaching the Handle

For grooming hard-to-reach areas like the back, attach the removable curved handle:

1. Align the trimmer head with the attachment point on the curved handle.
2. Gently push the trimmer onto the handle until it clicks securely into place.
3. To remove, press the release button (if present) or gently pull the trimmer away from the handle.



Image 4.1: The trimmer with the extended handle attached, ready for use on the back.





Image 4.2: Top view of the trimmer with the handle attached, showing the full length.

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off

1. To turn on the trimmer, press the power switch once. The indicator light will illuminate, signifying that the device is active.
2. To turn off the trimmer, press the power switch again. The indicator light will turn off.



Image 5.1: Close-up view of the power switch and indicator light on the trimmer.

5.2. Trimming Hair

The Ymiko Back Hair Trimmer can be used on various body parts, including the back, chest, and arms.

- **For Back Trimming:** Attach the removable curved handle as described in Section 4.2. Hold the handle firmly and guide the trimmer head across your back, moving against the direction of hair growth for optimal results.
- **For Other Body Parts:** The trimmer can be used without the extended handle for areas like the chest, arms, or face. Hold the trimmer directly and gently glide it over the desired area.
- **Wet or Dry Use:** The trimmer is designed for both wet and dry applications. For wet use, it can be used in the shower. Ensure the charging port cover is securely closed if using in wet conditions.



Image 5.2: The trimmer head, suitable for direct use on accessible body areas.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your trimmer.

1. After each use, turn off the trimmer.
2. Remove the trimming head from the main unit.
3. Use the provided cleaning brush to remove any accumulated hair from inside the trimming head and the main unit.
4. Rinse the trimming head under cold running water. Ensure no water enters the main unit if it is not designed for full immersion.
5. Allow all parts to air dry completely before reattaching the trimming head or storing the device.
6. Store the trimmer in a dry, cool place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully using the charging base and USB cable.
Trimmer pulls hair or cuts poorly.	Trimming head is clogged with hair or dull.	Clean the trimming head thoroughly as per Section 6. If the issue persists, the blade may need replacement (contact customer support for availability).

Problem	Possible Cause	Solution
Indicator light not working.	Device malfunction.	Ensure the device is charged. If the problem persists, contact customer support.

8. SPECIFICATIONS

Item Type	Men Back Trimmer
Material	ABS
Built-in Battery	Lithium-ion battery 500mAH
Model Name	Ymikohzngo38q1a
Power Source	AC/DC (via USB charging)
Special Feature	Adjustable (referring to the handle)
Recommended Uses	Indoor/Outdoor, Body Grooming
Dimensions (Package)	9.45 x 8.66 x 2.36 inches
Weight (Package)	14.46 ounces

9. SAFETY INFORMATION

- Keep the device out of reach of children.
- Do not disassemble or attempt to repair the device yourself. Contact qualified personnel for service.
- Avoid using the trimmer on irritated, damaged, or infected skin.
- Ensure the charging port is dry before connecting the USB cable.
- Do not immerse the main unit in water. Only the trimming head is designed for rinsing.
- Use only the provided charging cable and base.

10. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. For technical support or inquiries, please visit the official Ymiko website or contact their customer service department.

Manufacturer: Ymiko

Date First Available: July 1, 2024