

[Manuals.plus](#) /

› [MEDION](#) /

› MEDION E65895 Construction Site Radio User Manual

MEDION E65895

MEDION E65895 Construction Site Radio User Manual

Model: E65895 (MD 43895)

Brand: MEDION

1. INTRODUCTION

Welcome to the user manual for your new MEDION E65895 Construction Site Radio. This robust and versatile radio is designed to provide excellent sound quality in challenging environments, making it an ideal companion for construction sites, gardening, camping, and more. This manual will guide you through the setup, operation, and maintenance of your device to ensure optimal performance and longevity.



Image: The MEDION E65895 Construction Site Radio, showcasing its robust design and control panel.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the device. Keep this manual for future reference.

- **Water and Dust Protection (IP54):** The radio is splash-water resistant and protected against dust ingress (IP54 rating). This protection applies only when the device is operating on battery power. Do not submerge the device in water.
- **Battery Safety:** The device contains an integrated Li-ion battery. Do not expose the battery to excessive heat, direct sunlight, or fire. Do not attempt to replace the battery yourself.
- **Ventilation:** Ensure proper ventilation around the device. Do not block any ventilation openings.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use liquid or aerosol cleaners.
- **Operating Environment:** Avoid operating the device in extremely hot, cold, dusty, or humid environments.



Image: The MEDION E65895 radio demonstrating its IP54 splash-water and dust protection, suitable for outdoor and demanding environments.

3. PACKAGE CONTENTS

Please check the package contents upon unpacking to ensure all items are present and undamaged:

- MEDION Construction Site Radio (MD 43895)
- USB-C Charging Cable
- User Manual (this document)

4. PRODUCT FEATURES AND COMPONENTS

The MEDION E65895 is equipped with various features for a comprehensive audio experience:

- **Robust Housing:** Designed for durability in demanding conditions.
- **Integrated Carry Handle:** For easy transport.
- **Bluetooth 5.4:** Wireless music streaming from compatible devices with a range of approximately 10 meters.
- **PLL FM Radio:** With 30 preset stations for quick access to your favorite channels.
- **AUX Input:** For connecting external audio sources via a 3.5mm jack.
- **Integrated Rechargeable Battery:** 2,000 mAh Li-ion battery for portable use.
- **LCD Display:** Clear display for frequency and mode information.

Dimensions and Weight

The radio features a compact design for easy portability:

- Product Dimensions: 14.4 x 16.7 x 23 cm (L x W x H)
- Weight: Approximately 1.35 kg

Bouwplaatsradio in een compact formaat

Klein en handig voor eenvoudig transport



ca. 1,35 kg

Image: The compact dimensions of the MEDION E65895 Construction Site Radio, highlighting its portability.

Geïntegreerde PLL FM-radio

Al je favoriete zenders altijd bij de hand



Image: Close-up of the MEDION E65895 showing its integrated PLL FM radio with extendable telescopic antenna.

Draadloos muziek streamen via Bluetooth® 5.4

Gemakkelijk je favoriete nummers
afspelen vanaf je smartphone



Image: The MEDION E65895 demonstrating wireless music streaming via Bluetooth 5.4 from a smartphone.

Geïntegreerde oplaadbare batterij

Tot 10 uur muziekplezier zonder stopcontact*



*Afhankelijk van het soort gebruik

Image: The MEDION E65895 highlighting its integrated rechargeable battery, providing up to 10 hours of music playback.

5. SETUP

5.1 Charging the Battery

Before first use, fully charge the integrated Li-ion battery. Connect the supplied USB-C charging cable to the USB-C port on the radio and the other end to a suitable USB power adapter (not included) or a powered USB port.

- The charging indicator on the display will show the charging status.
- A full charge provides up to 10 hours of music playback, depending on usage conditions.

5.2 Initial Power On

To turn on the radio, press and hold the Power button (usually marked with a power symbol) located on the control panel. The LCD display will light up.

6. OPERATING INSTRUCTIONS

6.1 FM Radio Operation

1. **Switch to FM Mode:** Press the 'Mode' button (if available) or cycle through modes until 'FM' is displayed.
2. **Automatic Station Search (AMS):** Press the 'AMS' button to automatically scan and save available FM stations. The radio can store up to 30 preset stations.
3. **Manual Tuning:** Use the 'Tune' or 'Skip' buttons (often marked with arrows) to manually adjust the frequency.
4. **Selecting Presets:** Use the 'Preset' button or number buttons (if available) to cycle through your saved stations.



Image: The control panel of the MEDION E65895, highlighting the ability to store 30 favorite radio stations with a single button press.

6.2 Bluetooth Connectivity

1. **Switch to Bluetooth Mode:** Press the 'Mode' button until 'Bluetooth' or 'BT' is displayed. The radio will enter pairing

mode, indicated by a flashing Bluetooth icon or specific message.

2. **Enable Bluetooth on Your Device:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and enable Bluetooth.
3. **Pairing:** Search for available devices and select 'MEDION E65895' (or similar name) from the list. Once connected, the radio will indicate a successful pairing.
4. **Playback:** You can now play audio from your connected device through the radio.

6.3 AUX Input

To play audio from devices without Bluetooth, use the AUX input:

1. **Connect Cable:** Plug a 3.5mm audio cable (not included) into the AUX input port on the radio and the other end into the headphone jack or audio output of your external device.
2. **Switch to AUX Mode:** Press the 'Mode' button until 'AUX' is displayed.
3. **Playback:** Play audio from your external device.

6.4 Volume Control

Adjust the volume using the rotary knob or dedicated volume buttons on the control panel.

7. MAINTENANCE

Proper maintenance ensures the longevity of your MEDION E65895 radio:

- **Cleaning:** Wipe the exterior of the radio with a soft, slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents. Ensure the USB-C port and AUX input are free of dust and debris.
- **Storage:** When not in use for extended periods, store the radio in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before storage to maintain its health.
- **Battery Care:** To maximize battery life, avoid fully discharging the battery frequently. Recharge the battery regularly, even if the radio is not in constant use.

8. TROUBLESHOOTING

If you encounter issues with your MEDION E65895, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Radio does not turn on.	Battery is discharged.	Connect the USB-C charging cable and charge the battery.
No sound.	Volume is too low; Incorrect source selected; Device not properly connected (AUX/Bluetooth).	Increase volume; Select correct input mode (FM, Bluetooth, AUX); Ensure cables are securely connected or Bluetooth is paired.
Bluetooth connection fails.	Radio not in pairing mode; Device too far; Interference.	Ensure radio is in Bluetooth pairing mode; Move device closer to the radio (within 10m); Restart both devices.
Poor FM reception.	Antenna not extended; Weak signal area.	Fully extend the telescopic antenna; Try repositioning the radio for better signal.

9. SPECIFICATIONS

Feature	Specification
Brand	MEDION
Model	E65895 (MD 43895)
Output Wattage	10 Watt (RMS) / Max. 100 W
Connectivity	Bluetooth 5.4, AUX-in (3.5mm)
Radio Bands Supported	FM (PLL FM radio with 30 presets)
Battery	Integrated 2,000 mAh Li-ion battery
Battery Life	Up to 10 hours (depending on usage)
Power Source	Battery-Powered (USB-C charging)
Water/Dust Resistance	IP54 (splash-water resistant, dust protected)
Dimensions (L x W x H)	14.4 x 16.7 x 23 cm
Weight	1.35 kg
Display Type	LCD

10. WARRANTY AND SUPPORT

MEDION products are designed for reliability and performance. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official MEDION website for detailed terms and conditions. Should you require technical assistance or have questions not covered in this manual, please contact MEDION customer support. Our competent customer service team is available to assist you. For the latest support information and contact details, please visit the official MEDION support page or refer to the contact information provided in your product packaging.

© 2024 MEDION. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D8JDRXBL>

More documents and user manuals: <https://manuals.plus/>