HiPlay BFGGTXMK7

HiPlay ZD Toys Iron Man MK7 Action Figure Instruction Manual

Model: BFGGTXMK7

1. Introduction

This manual provides instructions for the assembly, operation, and care of your HiPlay ZD Toys Iron Man Mark VII (MK7) 1:10 Scale Action Figure. This collectible figure is inspired by Marvel Studios' The Avengers (2012) and features detailed armor plating and multiple points of articulation for dynamic posing.

Please read these instructions carefully before handling the figure to ensure proper use and longevity.

2. Safety Information

- **Age Recommendation:** This product is recommended for collectors aged 15 years and older. It is not intended as a children's toy due to small parts and delicate components.
- **Small Parts:** The figure includes small interchangeable parts. Keep these out of reach of young children to prevent choking hazards.
- **Handling:** Handle the figure with care. Avoid excessive force when posing or changing parts to prevent breakage.
- **Environmental Conditions:** Do not expose the figure to extreme temperatures, direct sunlight for prolonged periods, or high humidity, as this may cause damage or discoloration.
- **Chemicals:** Avoid contact with harsh chemicals, solvents, or abrasive cleaners, which can damage the paint finish or material.

3. Package Contents

Verify that all components are present in the package:

- 1x Iron Man MK7 Action Figure (Non-Luminous Version)
- 4 sets of interchangeable hands
- 4 magic effect parts

- 1x Transparent display stand



Image: Iron Man MK7 figure with its accessories.

4. Setup and Assembly

4.1 Unboxing

1. Carefully remove the figure and all accessories from the packaging.
2. Inspect all parts for any visible damage. If any parts are damaged, contact customer support.

4.2 Attaching Interchangeable Hands

1. Gently pull the existing hands off the wrist joints.
2. Select the desired pair of interchangeable hands.
3. Align the peg on the new hand with the hole in the wrist joint and carefully push until it is securely attached. Do not force.

4.3 Assembling the Display Stand

1. Connect the clear support arm to the hexagonal base.
2. Attach the figure clip to the top of the support arm.
3. Carefully secure the Iron Man figure into the clip for aerial poses.



Image: Iron Man MK7 figure displayed on its transparent stand.

5. Operating and Posing

5.1 Articulation Points

The Iron Man MK7 figure features multiple points of articulation, allowing for a wide range of dynamic poses. These include joints in the neck, shoulders, elbows, wrists, torso, hips, knees, and ankles.

- Gently manipulate each joint to achieve the desired pose.
- Avoid forcing joints beyond their natural range of motion to prevent damage.



Image: Iron Man MK7 figure demonstrating articulation with energy effects.

5.2 Attaching Magic Effect Parts

The included magic effect parts can be attached to the figure's hands and feet to simulate repulsor blasts or flight thrusters.

1. Identify the small pegs on the effect parts and the corresponding holes on the figure's hands (if using open palm hands) or feet.
2. Carefully insert the pegs into the holes until they are snug.



Image: Iron Man MK7 figure with magic effect parts attached.

6. Maintenance

6.1 Cleaning

- To clean the figure, gently wipe it with a soft, dry cloth.
- For stubborn dust or smudges, lightly dampen the cloth with water. Ensure the figure is completely dry before storing or displaying.
- Do not use cleaning sprays, solvents, or abrasive materials, as these can damage the paint and finish.

6.2 Storage

- Store the figure in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep the figure and its accessories in a dust-free environment to maintain its condition.
- If storing for extended periods, consider returning the figure to its original packaging or a protective display case.

7. Troubleshooting

7.1 Stiff Joints

If a joint feels stiff, gently warm the area with a hairdryer on a low setting for a few seconds (hold at a safe distance) to soften the plastic before attempting to move it. Do not apply excessive heat.

7.2 Loose Parts

If a part becomes loose, it may be possible to tighten it with a small amount of clear nail polish or a specialized joint-tightening fluid applied to the peg, allowing it to dry completely before reassembly. Use sparingly.

7.3 Parts Not Fitting

Ensure that you are using the correct parts for the intended connection. If a part does not fit, do not force it. Re-check the instructions or consult online resources for guidance.

8. Specifications

Product Name	HiPlay ZD Toys Iron Man MK7 Action Figure
Model Number	BFGGTXMK7
Scale	1:10
Product Height	18 cm (7 inches)
Product Dimensions	3.15 x 9.06 x 7.09 inches
Item Weight	1 pound
Material	ABS, PVC
Manufacturer	ZD Toys

9. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any inquiries regarding product defects, missing parts, or general support, please contact HiPlay customer service directly through their official channels or the retailer where the product was purchased.

You can visit the HiPlay Store on Amazon for more information and contact options.

© 2026 HiPlay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question