

- Manuals.plus /
- › LiuShan /
 - › User Manual for LiuShan 360-Degree Rotation Tablet Case (TECLAST M50 Mini / T50 Mini)

LiuShan LS00857-2

User Manual for LiuShan 360-Degree Rotation Tablet Case

Model: LS00857-2

1. INTRODUCTION

Thank you for choosing the LiuShan 360-Degree Rotation Tablet Case. This case is specifically designed to provide comprehensive protection and versatile functionality for your 8.7-inch TECLAST M50 Mini or Teclast T50 Mini tablet. Crafted from durable synthetic leather with a soft microfiber interior, it safeguards your device from daily wear and tear, including knocks, dust, damage, and scratches.

This manual provides instructions on how to properly install, use, and maintain your tablet case to ensure its longevity and optimal performance.



Figure 1.1: LiuShan 360-Degree Rotation Tablet Case (Purple)

2. SETUP

To install your tablet into the case, follow these simple steps:

1. Ensure your tablet is clean and free of debris.
2. Carefully align your 8.7-inch TECLAST M50 Mini or Teclast T50 Mini tablet with the case's internal frame.
3. Gently press the tablet into the frame, ensuring all corners and edges are securely seated. The case is designed for a snug fit to prevent accidental dislodging.
4. Once the tablet is in place, you can close the cover and secure it with the integrated elastic band to keep it protected when not in use.

Wraps around the back cover, holds tablet closed securely when not in use



Figure 2.1: Securing the case with the elastic band

3. OPERATING

The LiuShan tablet case offers several features to enhance your tablet experience:

3.1 360-Degree Rotating Stand

The unique 360-degree swivel design allows you to prop up your device both vertically and horizontally. Simply rotate the tablet within the case to switch between portrait and landscape orientations.



DUAL VIEWING MODE

The unique 360 degree swivel design allows you to prop up your device vertically or horizontally.



Figure 3.1: Dual Viewing Mode (Vertical and Horizontal)

3.2 Multiple Stand Angles

The case features three stand angles (approximately 100°, 80°, and 60°) for optimal viewing and typing experiences. Adjust the tablet's position by placing the edge into one of the three grooves on the cover.



Figure 3.2: Adjustable Stand Angles

3.3 Stylus Loop

An integrated stylus loop is provided for convenient storage of your stylus (stylus not included). This ensures your stylus is always at hand when you need it.

Stylus Loop Desing



Figure 3.3: Stylus Loop Design

4. MAINTENANCE

To keep your LiuShan tablet case in optimal condition, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior synthetic leather with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- **Interior Care:** The soft microfiber interior is designed to protect your screen from scratches. If dust or debris accumulates, gently wipe it with a dry, lint-free cloth.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Avoid Overstuffing:** Do not force oversized items into the case, as this can stretch or tear the material and compromise its protective qualities.



High Quality Material & Craftsmanship

Soft microfiber Interior
Protect the screen from scratches

High Quality Exterior
Against daily wear and tear

Figure 4.1: Case Material and Craftsmanship

5. TROUBLESHOOTING

If you encounter any issues with your tablet case, consider the following common solutions:

- **Case Does Not Fit:** Ensure your tablet is specifically the 8.7-inch TECLAST M50 Mini or Teclast T50 Mini model. This case is not compatible with other tablet models, including the TECLAST M50 Pro. Verify your tablet's model number.
- **Tablet Not Secure:** Double-check that the tablet is fully seated within the case's frame, with all corners properly aligned and snapped into place.
- **Stand Instability:** Ensure the tablet's edge is firmly placed within one of the three designated grooves on the cover. Uneven surfaces can also affect stability.

6. SPECIFICATIONS

Feature	Detail
Compatible Devices	8.7" TECLAST M50 Mini, Teclast T50 Mini Tablet
Model Number	LS00857-2
Material	Synthetic PU Leather (Exterior), Soft Microfiber (Interior)
Color	Purple
Form Factor	Cover
Shell Type	Soft
Item Weight	3.2 ounces
Package Dimensions	10 x 5 x 0.5 inches

7. WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain technical support, please refer to the product packaging or contact LiuShan customer service directly through their official website or the platform where the product was purchased. Please have your model number (LS00857-2) and purchase details ready when contacting support.

© 2024 LiuShan. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D8KPSZD3>

More documents and user manuals: **<https://manuals.plus/>**