FIOGOHUMI 10000BTU

FIOGOHUMI 10000BTU Portable Air Conditioner User Manual

Model: 10000BTU

1. Important Safety Instructions

Please read all instructions carefully before using this portable air conditioner. Keep this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- This appliance is for indoor use only.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the unit with a damaged cord or plug.
- Always unplug the unit before cleaning or servicing.
- Do not block the air inlets or outlets.
- Keep the unit on a flat, stable surface to prevent tipping.
- Do not use in wet areas like bathrooms or laundries.
- Children should be supervised to ensure they do not play with the appliance.

2. Product Overview

The FIOGOHUMI 10000BTU Portable Air Conditioner is a versatile 4-in-1 unit designed to provide cooling, dehumidification, fan operation, and a quiet sleep mode for rooms up to 350 sq. ft.

Key Features:

- **Cooling Capacity:** 10000 BTU (ASHRAE)
- **Coverage Area:** Up to 350 sq. ft.
- **Operating Modes:** Cool, Dehumidify, Fan, Sleep
- **Dehumidification:** 50 pints/day capacity with auto-evaporative system
- **Quiet Operation:** Noise level ≤45dB
- **Refrigerant:** R32 (environmentally friendly)
- **Control:** LED display and remote control

- **Convenience:** 24-hour timer, power outage reset, 360° wheels, ergonomic handles



Image: The portable air conditioner effectively cools a room up to 350 sq. ft. within 10 minutes.

Image: The unit features built-in handles and castor wheels for easy mobility.

3. Setup and Installation

Follow these steps for quick and effortless installation of your portable air conditioner.

What's in the Box:

- Portable Air Conditioner Unit
- Exhaust Hose
- Window Adapter Kit (includes single window sealing plate and connectors)
- Remote Control
- User Manual

Installation Steps:

1. **Position the Unit:** Place the air conditioner on a flat, stable surface near a window and a power outlet. Ensure there is at least 20 inches of space around the unit for proper airflow.
2. **Attach Exhaust Hose:** Connect one end of the exhaust hose to the air outlet on the back of the unit. Twist clockwise until secure.
3. **Install Window Kit:** Assemble the window sealing plate(s) to fit your window opening. The single plate is 25.5 inches, and two plates together can extend from 35 to 49 inches. Secure the window adapter to the other end of the exhaust hose.
4. **Vent the Exhaust:** Insert the window adapter into the assembled window sealing plate. Close the window to secure the plate and hose. Ensure the exhaust hose is not sharply bent or kinked, as this can reduce efficiency.
5. **Plug In:** Plug the power cord into a grounded electrical outlet.



Image: Visual guide for connecting the exhaust hose and installing the window sealing plate.

4. Operating Instructions

Your FIOGOHUMI portable air conditioner offers multiple modes for customized comfort.

Control Panel and Remote Control:

The unit can be operated using the integrated LED control panel on top of the unit or the included remote control, effective up to 16 feet away.




Image: The LED control panel and remote control allow for easy customization of settings.

Operating Modes:

- **Cool Mode:** Provides powerful cooling with a temperature range of 61°F to 88°F. Adjust the desired temperature using the up/down arrows.
- **Dehumidifier Mode:** Removes excess moisture from the air (up to 50 pints/day). The auto-evaporative system typically handles condensation, but for continuous dehumidification, connect the drain pipe.
- **Fan Mode:** Circulates air without cooling. Choose from different fan speeds (Low/High).
- **Sleep Mode:** Designed for quiet operation during sleep. The unit maintains a comfortable temperature while minimizing noise (≤45dB).




Image: Overview of the four operating modes: Cool, Sleep, Fan, and Dry (Dehumidifier).

Timer Function:

Set the 24-hour timer to automatically turn the unit on or off at a specified time.

Power Outage Reset:

The unit features a power outage reset function, allowing it to resume previous settings after a power interruption.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your air conditioner.

Filter Cleaning:

The air filter should be cleaned twice a month to maintain cooling efficiency. To clean:

1. Unplug the unit from the power outlet.
2. Remove the filter from its housing (refer to the diagram on the unit for location).
3. Wash the filter with warm, soapy water. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it into the unit.

Water Drainage:

This unit features an auto-evaporative system, which typically exhausts most condensed water with the hot air. However, in high humidity conditions or when using dehumidifier mode, excess water may accumulate. Connect the included drain pipe to the drainage port for continuous drainage.

Storage:

Before storing the unit for an extended period, ensure all water is drained, and the filter is clean and dry. Store the unit in a cool, dry place.



Image: The washable air filter is easily removable for cleaning to maintain air quality and unit efficiency.

6. Troubleshooting

If you encounter issues with your air conditioner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord unplugged; Circuit breaker tripped	Check power outlet; Plug in securely; Reset circuit breaker
Unit not cooling effectively	Air filter dirty; Exhaust hose blocked/kinked; Room too large; Doors/windows open	Clean air filter; Ensure hose is clear and straight; Close doors/windows; Verify room size is within 350 sq. ft.
Unit is noisy	Unit not on a level surface; Fan speed too high; Internal components vibrating	Place on a level surface; Reduce fan speed; Contact customer support if noise persists
Water leakage	Drain plug not properly sealed; Unit tilted; Drain pipe blocked	Ensure drain plug is secure; Place unit on a level surface; Clear any blockages in the drain pipe

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Specification
Brand	FIOGOHUMI
Model Name	10000BTU Portable Air Conditioners
Model Number	10000BTU
Cooling Power	10000 British Thermal Units (ASHRAE)
Coverage Area	Up to 350 sq. ft.
Functions	Cool, Dehumidifier, Fan, Sleep Mode (4-in-1)

Feature	Specification
Dehumidification Capacity	50 pints/day
Noise Level	≤45 dB
Refrigerant	R32
Product Dimensions (D x W x H)	14.84"D x 13.38"W x 33.86"H
Seasonal Energy Efficiency Ratio (SEER)	6.5
Wattage	2930 watts
Control Method	Remote Control, LED Display
Window Kit Compatibility	Single plate: 25.5 inches; Two plates: 35-49 inches
UPC	768771992374

8. Warranty and Support

Limited Warranty:

This FIOGOHUMI product comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

Customer Support:

For any questions, technical assistance, or warranty claims, please follow these steps:

1. Log in to your Amazon account.
2. Navigate to 'Your Orders'.
3. Find the relevant order ID for your FIOGOHUMI Portable Air Conditioner.
4. Click on 'Contact Seller' to reach our support team.



Image: FIOGOHUMI offers customer support with a 24-hour reply window, 30-day free returns, and 2 years of machine service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question