

Lepow D15

Lepow Portable Monitor D15 Series Instruction Manual

Model: D15

1. INTRODUCTION

Thank you for choosing the Lepow Portable Monitor D15. This dual-screen extender is designed to enhance your productivity and entertainment experience on the go. Featuring a 15.6-inch 1080P Full HD IPS display, 360° foldable design, and versatile connectivity, it's an ideal companion for professionals, gamers, and travelers. This manual provides essential information for setting up, operating, and maintaining your monitor.

2. WHAT'S IN THE BOX

- 15.6 inch Monitor External Screen for Laptop Portable
- Laptop Screen with 65W PD Power Adapter
- Travel Computer Monitor for Laptop with Leather Cover
- Laptop External Monitor External Display with 2x USB-C Cable
- Traveling Monitor for Laptop Phone Monitor with User Guide



Text Description: A video showing the unboxing process of the Lepow Portable Monitor D15, revealing the monitor, cables, power adapter, and user manual.

3. PRODUCT OVERVIEW

3.1. Key Features

- **High-Resolution Display:** Experience 1080p Full HD on two 15.6" IPS screens with 100% sRGB color gamut, low blue light, and HDR mode.
- **One Cable Connection Plug&Play:** Simple connectivity with a single USB-C cable, compatible with Windows, macOS, Chrome OS, Android, iOS-iPad, tablets, desktops, PCs, MacBooks, mobile phones, Switch, Linux, Xbox, PS4, and PS5.

- **Space and Time Saving:** 360° foldable design for efficient workspace use, supporting mirror mode, split-screen, and extended screen options.
- **Built-in Dual Speakers:** Integrated dual 6Ω 2W speakers for clear audio during video conferences, multimedia presentations, and entertainment.
- **Portable & Efficient Charging:** Lightweight and easily transportable, with a deformable leather stand and a 65W power adapter that can also charge connected devices.

3.2. Monitor Components

Familiarize yourself with the ports and controls on your Lepow D15 monitor.



Text Description: A close-up image of the side of the portable monitor, highlighting the various ports and control buttons. These typically include USB-C ports for power and data, a Mini HDMI port, and control buttons for menu navigation and power.

4. SETUP

4.1. Using the Leather Cover as a Stand

1. Lay the leather cover flat on a stable surface.

2. Place the monitor onto the cover, aligning it with the magnetic strips.
3. Fold the cover to create a triangular stand, adjusting the angle for optimal viewing.



Text Description: An image showing a woman adjusting the 360-degree foldable monitor, demonstrating its flexible positioning options.

Text Description: A video demonstrating how to set up the monitor using its leather cover as a stand, showing the folding process and various viewing angles.

4.2. Connecting to Your Device

The Lepow D15 monitor supports various connection methods:

- **USB-C to USB-C:** For devices with a full-featured USB-C port (supports both power and video). Connect one end of the USB-C cable to your device's USB-C port and the other end to the monitor's USB-C port.
- **Mini HDMI to HDMI + USB-C for Power:** For devices with an HDMI output. Connect the Mini HDMI end to the monitor and the HDMI end to your device. Then, connect a USB-C cable from the monitor to a power source (e.g., power adapter or laptop's USB-C port) for power.

LEPOW

1080P FULL HD 1080p FHD

100% sRGB

60Hz

250 nits

65W 65W

Double Your Vision, Double Your Success

Experience unmatched productivity with **LEPOW 15.6"** Portable Dual Screen. Your workspace, redefined.

Text Description: An image showing a man working with a laptop connected to two external monitors, demonstrating an extended desktop setup.

Text Description: A video tutorial demonstrating how to connect the portable monitor to a laptop using a USB-C cable, showing the monitor powering on and displaying content.

4.3. Powering the Monitor

If your device's USB-C port does not provide sufficient power, or if you are using an HDMI connection, you will need to connect the monitor to an external power source using the provided 65W PD power adapter and USB-C charging cable.

30Mins
power up to 55%

65W

Power-Up Fast
Keep your devices energized with 65W fast charging.

Text Description: An image illustrating the monitor being charged or powered by a 65W power adapter, with a laptop also connected.

5. OPERATING INSTRUCTIONS

5.1. Display Modes

The Lepow D15 supports various display modes to suit your needs:

- **Mirror Mode:** Duplicates your primary screen's content onto the portable monitor. Ideal for presentations or sharing content.
- **Extend Mode:** Extends your desktop across both screens, providing more workspace for multitasking. You can arrange the displays horizontally or vertically in your operating system's display settings.
- **Split-Screen Mode:** Divides the portable monitor into multiple sections, allowing you to view several applications simultaneously.



Text Description: An image showing a man using the portable monitor in a vertical orientation next to his laptop, demonstrating mirror mode for multitasking.

5.2. Adjusting Display Settings

Use the control buttons on the side of the monitor to access the On-Screen Display (OSD) menu. From here, you can adjust settings such as:

- **Brightness and Contrast:** Optimize visual clarity for different lighting conditions.
- **Color Settings:** Adjust color temperature, hue, and saturation.
- **Audio Settings:** Control volume for the built-in dual speakers.
- **HDR Mode:** Enable or disable High Dynamic Range for enhanced visual depth.
- **Low Blue Light Mode:** Reduce blue light emission for eye comfort.

5.3. Setting Portrait Mode (Windows)

1. Right-click on your desktop and select "Display settings."

2. Identify the external monitor (it might be labeled as 2 or 3).
3. Scroll down to "Display orientation" and select "Portrait."
4. Confirm the changes when prompted.

Text Description: A video demonstrating the steps to change the display orientation to portrait mode in Windows settings.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals.
- **Storage:** When not in use, store the monitor in its protective leather cover to prevent scratches and damage.
- **Handling:** Handle the monitor with care. Avoid dropping it or applying excessive pressure to the screen.

7. TROUBLESHOOTING

Issue	Possible Solution
No signal/Black screen	Ensure cables are securely connected. Verify your device's output settings. Ensure the monitor is receiving sufficient power.
Flickering screen	Check cable connections. Try a different cable. Adjust refresh rate in display settings.
No audio from speakers	Check monitor's volume settings. Ensure your device's audio output is directed to the monitor.
Display not extending/mirroring correctly	Adjust display settings in your operating system (Windows: Display Settings; macOS: System Settings > Displays).
Color inconsistency between screens	Adjust color settings via the monitor's OSD menu or your device's display calibration tools.

8. SPECIFICATIONS

Feature	Detail
Brand	Lepow
Model Number	D15
Screen Size	15.6 Inches
Resolution	FHD 1080p (1920 x 1080 Pixels)
Aspect Ratio	16:9
Refresh Rate	60 Hz
Display Type	LED IPS
Brightness	300 nits
Color Gamut	100% sRGB
Contrast Ratio	1000:1
Connectivity Technology	USB-C, Mini HDMI
Hardware Connectivity	USB
Additional Features	Built-In Speakers, HDR, Low Blue Light Mode, 360° Foldable Design
Item Dimensions (D x W x H)	6.97"D x 4.57"W x 0.83"H
Color	Black

9. WARRANTY AND SUPPORT

The Lepow Portable Monitor D15 comes with a **1 Year Manufacturer Warranty**. For warranty claims, technical support, or further assistance, please contact Lepow customer service through their official website or the contact information provided in your user guide.

You can also visit the Lepow Store on Amazon for more product information and support resources.