

[Manuals.plus](#) /

> [JVSCAM](#) /

> JVSCAM C8 FHD 1080P 48MP Digital Camera Instruction Manual

JVSCAM C8

JVSCAM C8 FHD 1080P 48MP Digital Camera Instruction Manual

Model: C8

Brand: JVSCAM

WHAT'S IN THE BOX

- JVSCAM C8 Digital Camera
- 32GB TF Card
- Type-C Charging Cable
- Card Reader
- Lanyard / Wrist Strap
- User Manual
- Storage Bag
- Lens Cleaning Cloth



Image: Contents of the JVSCAM C8 Digital Camera package.

PRODUCT OVERVIEW

The JVSCAM C8 Digital Camera is a compact and portable device designed for capturing high-quality photos and videos. It features a 48MP photo resolution and FHD 1080P video recording capabilities, making it suitable for various photography and videography needs.

- **FHD 1080P Video & 48MP Photo:** Equipped with a CMOS image sensor and anti-shake function for clear images and stable videos. Includes a built-in microphone.
- **16x Digital Zoom & Auto Focus:** Allows for detailed close-ups and ensures sharp images by automatically adjusting focus.
- **1500mAh High Capacity Battery:** Provides over 180 minutes of continuous shooting on a full charge, with an auto-off function for energy saving.
- **Multifunctional:** Can be used as a webcam, features 22 filters, smile detection, timed shooting, continuous shooting, and self-timer. Built-in LED light for low-light conditions.



Image: JVSCAM C8 Digital Camera, showcasing its compact design.



Image: Visual representation of FHD 1080P video and 48MP photo capabilities.

SETUP

Inserting the MicroSD Card

The camera comes with a 32GB MicroSD card pre-installed. If you need to remove or insert a card:

1. Locate the MicroSD card slot on the side of the camera.
2. Gently push the card until it clicks into place. Ensure the contacts face the screen side of the camera.
3. To remove, push the card again until it springs out.

Charging the Camera

The camera has a built-in 1500mAh rechargeable battery.

1. Connect the provided Type-C USB cable to the camera's charging port.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. A red indicator light will illuminate during charging and turn off when fully charged.

Video: JVSCAM Digital Camera Kids Camera. This video demonstrates the unboxing and initial setup of the camera, including inserting the memory card and connecting the charging cable.

Video: JVSCAM Autofocus Digital Camera. This video provides a brief overview of the camera's features and initial handling.

OPERATING INSTRUCTIONS

Powering On/Off

Press and hold the power button (usually located on the top or side) to turn the camera on or off.

Taking Photos

1. Ensure the camera is in photo mode (indicated by a camera icon on the screen).
2. Point the camera at your subject.
3. Half-press the shutter button to activate autofocus (focus frame changes from red to green).
4. Fully press the shutter button to capture the photo.




Image: How to use the autofocus feature by half-pressing the shutter button.

Recording Videos

1. Switch the camera to video mode (indicated by a video camera icon).
2. Press the shutter button to start recording.
3. Press the shutter button again to stop recording.

Zoom Function

Use the '+' and '-' buttons on the camera to adjust the 16x digital zoom.




Image: Demonstration of the 16x digital zoom feature.

Autofocus

The camera is equipped with an autofocus function. Half-press the shutter button to allow the camera to focus on your subject before fully pressing to capture.

Special Features

Anti-Shake

Enable the anti-shake function in the camera settings to reduce blur in photos and videos.



Image: Illustrates the effect of the anti-shake feature on image clarity.

Smile Detection

Activate smile detection in the settings to automatically capture photos when a smile is detected.




Image: Shows the camera detecting smiles for automatic photo capture.

Self-Timer

Set a delay of 2, 5, or 10 seconds before a photo is taken, ideal for group shots or selfies.



Image: Displays the self-timer settings for delayed photo capture.

Filters

Experiment with 22 built-in filter effects to add creative touches to your photos.



22 Filter Effects

A wide variety of filter styles

Image: Shows various filter effects that can be applied to photos.

Built-in LED Flash

Use the built-in LED flash to ensure clear photos even in low-light conditions.




Image: Demonstrates the effect of the flash light in dark environments.

Transferring Files

To transfer photos and videos to your computer or phone:

1. Connect the camera to your computer using the provided Type-C cable.
2. Alternatively, remove the MicroSD card and use the included card reader to connect to your device.



Image: Illustrates the process of transferring photos and videos from the camera to other devices.

MAINTENANCE

- **Cleaning:** Use the provided lens cleaning cloth to gently wipe the lens and screen. Avoid abrasive materials.
- **Storage:** Store the camera in the included storage bag to protect it from dust and scratches when not in use.
- **Battery Care:** Fully charge the battery before extended storage. Avoid extreme temperatures.

TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Blurry images:** Ensure autofocus is enabled. Half-press the shutter button to allow the camera to focus before fully pressing. Check for smudges on the lens.
- **Video recording issues (e.g., no sound):** Verify microphone settings in the menu. Ensure the camera is in a quiet environment for optimal audio capture.
- **Files not transferring:** Ensure the USB cable is securely connected. Try using the card reader directly with the MicroSD card.
- **Screen artifacts/grainy images:** Digital zoom can sometimes introduce artifacts. For best quality, avoid excessive digital zoom and crop images later if needed.

SPECIFICATIONS

Brand	JVSCAM
Model Name	C8-Beige
Effective Still Resolution	48 MP
Video Resolution	1080p
Digital Zoom	16 x
Screen Size	2.4 Inches
Memory Storage Capacity	32 GB (MicroSD)
Battery Capacity	1500mAh
Special Features	Anti-Shake, Self-Timer, Timestamp, Smile Capture, Filters, Autofocus
Connectivity Technology	Micro USB

WARRANTY AND SUPPORT

The JVSCAM C8 Digital Camera comes with a 2-year satisfactory warranty. For any issues or support inquiries, please contact JVSCAM-US directly through their store on Amazon. Our staff is available to assist you promptly.



 **2** Year
Warranty-free

 **24** H
Online

Meaningful Gifts



Image: Warranty details and customer support availability.