

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Cuisinart](#) /

> [Cuisinart AMW-90AFB Replacement Air Fryer Basket User Manual](#)

## Cuisinart AMW-90AFB


# Cuisinart AMW-90AFB Replacement Air Fryer Basket User Manual

Model: AMW-90AFB

## 1. PRODUCT OVERVIEW

---

The Cuisinart AMW-90AFB Replacement Air Fryer Basket is an essential accessory designed to restore or enhance the functionality of your Cuisinart AMW-90 Air Fryer. This OEM (Original Equipment Manufacturer) part ensures consistent crispy and flavorful results by facilitating even heat distribution and efficient air circulation. Crafted from durable, high-quality materials, this basket is built for longevity and frequent use, simplifying both cooking and cleaning processes.



**Image 1:** The Cuisinart AMW-90AFB Replacement Air Fryer Basket. This image displays the basket's design, highlighting its sturdy construction and perforated base for optimal air circulation.

## 2. PACKAGE CONTENTS

---

Upon unpacking, please ensure all items listed below are present and in good condition.

- 1 x Cuisinart AMW-90AFB Air Fryer Basket

## 3. COMPATIBILITY

---

**Important:** This replacement air fryer basket is designed **exclusively** for use with the Cuisinart AMW-90 Air Fryer model. It will not fit any other air fryer models, even if they appear similar in size or design. Using this basket with an incompatible model may result in improper fit, reduced performance, or damage to the appliance. Please verify your air fryer model number before installation.

## 4. INSTALLATION INSTRUCTIONS


---

Follow these steps to properly install the replacement air fryer basket into your Cuisinart AMW-90 Air Fryer.

1. **Safety First:** Ensure your Cuisinart AMW-90 Air Fryer is unplugged from the power outlet and has

completely cooled down before handling any internal components.

2. **Remove Old Basket (if applicable):** If you are replacing an existing basket, carefully pull the old basket assembly straight out from the air fryer unit.
3. **Insert New Basket:** Align the new AMW-90AFB replacement basket with the guides inside the air fryer's main compartment. Gently slide the basket into place until it is fully seated and secure. You should feel it click or fit snugly into position.
4. **Verify Fit:** Once installed, gently pull on the handle to ensure the basket is securely locked in place and does not wobble.



**Image 2:** Illustrative image of the air fryer basket, demonstrating its form factor for proper installation into the AMW-90 unit.

## 5. OPERATING THE AIR FRYER BASKET

---

The AMW-90AFB basket is designed to work seamlessly with your Cuisinart AMW-90 Air Fryer. Refer to your main Cuisinart AMW-90 Air Fryer instruction manual for specific cooking times, temperatures, and operational guidelines.

- **Food Placement:** Place food evenly in a single layer within the basket to ensure optimal air circulation and even cooking. Avoid overcrowding.
- **Shaking/Tossing:** For best results with certain foods (e.g., fries, chicken wings), periodically remove the basket and gently shake or toss the contents to ensure all sides are exposed to the hot air.

- **Crispy Results:** The perforated design of the basket promotes efficient air flow, which is crucial for achieving crispy textures.

## 6. CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your air fryer basket and ensure continued optimal performance.

- **After Each Use:** Allow the basket to cool completely before cleaning.
- **Hand Washing:** Wash the basket with warm, soapy water using a non-abrasive sponge or cloth. Rinse thoroughly and dry immediately to prevent water spots.
- **Dishwasher Safe:** The basket is generally dishwasher safe. Place it on the top rack for best results. Avoid using harsh detergents or abrasive cleaning tools.
- **Stubborn Residue:** For baked-on food, soak the basket in warm, soapy water for 15-20 minutes before cleaning.
- **Storage:** Store the clean, dry basket inside your air fryer or in a dry place.

## 7. TROUBLESHOOTING

If you encounter any issues with your replacement air fryer basket, please refer to the following common solutions.

Problem	Possible Cause	Solution
Basket does not fit into the air fryer.	Incorrect air fryer model.	Verify your air fryer is the Cuisinart AMW-90 model. This basket is not compatible with other models.
Food is not cooking evenly.	Basket overcrowded; food not shaken.	Ensure food is in a single layer. Shake or toss food halfway through cooking. Refer to your main air fryer manual for cooking guidelines.
Basket is difficult to clean.	Baked-on food residue.	Soak the basket in warm, soapy water for 15-20 minutes before washing. Use a non-abrasive sponge.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Cuisinart
Model Name	AMW-90AFB
Compatibility	Cuisinart AMW-90 Air Fryer ( <i>only</i> )
Part Number	AMW-90AFB
Item Weight	4.8 ounces
Product Dimensions	12 x 6 x 6 inches (approximate)
Color	Silver
Included Components	Air Fryer Basket
Material	Durable, high-quality materials (OEM standard)
UPC	086279218209

## 9. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, product support, or to purchase additional accessories, please contact Cuisinart customer service directly or visit their official website.

**Cuisinart Official Website:** [www.cuisinart.com](http://www.cuisinart.com)

Please have your product model number (AMW-90AFB) and any purchase details ready when contacting support.