

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Hakan](#) /

> [Korkmaz Hanedan A843-04 Electric Turkish Tea Maker Samovar Instruction Manual](#)

## Hakan Korkmaz Hanedan A843-04

# Korkmaz Hanedan A843-04 Electric Turkish Tea Maker Samovar Instruction Manual

Model: Korkmaz Hanedan A843-04 | Brand: Hakan

## INTRODUCTION

The Korkmaz Hanedan A843-04 Electric Turkish Tea Maker Samovar is designed for brewing and serving tea with convenience and traditional style. This stainless steel double-pot tea machine features automatic temperature adjustment to maintain freshness and flavor, along with automatic boil and keep-warm functions. It operates on a 110V US plug, eliminating the need for a converter. The samovar is equipped with dry boil protection for safe operation.

1.37 qts. \_\_\_\_\_  
(43.9 fl oz)

3.69 qts. \_\_\_\_\_  
(118.3 fl oz)

GREAT FOR FAMILY  
GATHERINGS

18/10 STAINLESS  
STEEL BODY



Image: Front view of the Korkmaz Hanedan A843-04 Electric Turkish Tea Maker Samovar, showcasing its two-pot design and rose gold accents.

## SETUP

### 1. Initial Cleaning

Before the first use, thoroughly clean both the upper and bottom pots with hot water and liquid dish soap. Rinse all components completely. Avoid using wire brushes or hard cleaning materials on any surface to prevent scratching.

### 2. Assembly

1. Place the main body (bottom pot) on a stable, flat surface.
2. Ensure the tap is securely attached and in the closed position.
3. Position the upper pot (teapot) onto the designated area on top of the bottom pot.
4. Place the lid on the upper pot.



HOLDS  
**50**  
TEA GLASSES

~~NO NEED FOR  
A PLUG CONVERTER~~



**1200 W, 110V  
US PLUG**

\*only by Hes Trade special  
for US and Canada Buyers

Image: Diagram illustrating the capacities of the upper pot (1.3L) and bottom pot (3.5L) of the samovar.

## OPERATING INSTRUCTIONS

### 1. Filling the Bottom Pot (Water Boiler)

- Remove the upper pot and its lid.
- Fill the bottom pot with fresh water, ensuring it does not exceed the maximum fill line.
- Place the upper pot back onto the bottom pot.

### 2. Adding Tea to the Upper Pot (Teapot)

- Add your desired amount of tea leaves into the upper pot. The integrated infuser will hold the tea leaves.
- Place the lid securely on the upper pot.

### 3. Powering On and Boiling Water

- Plug the 110V US plug into a suitable power outlet.
- Activate the boiling function. The samovar will automatically boil the water.
- Once the water reaches boiling point, the unit will automatically switch to the 'keep-warm' function.



## THE BEST GIFT IDEA FOR TEA LOVERS WITH ORIGINAL BOX

Image: Close-up of the samovar's base, highlighting the automatic keep-warm and boil function indicators.

### 4. Brewing and Serving Tea

- Allow the tea leaves in the upper pot to steep with a small amount of hot water from the bottom pot for a few minutes to create a strong concentrate.
- To serve, pour the concentrated tea from the upper pot into your glass.
- Use the tap on the bottom pot to add hot water to dilute the tea to your preferred strength.



AUTOMATICALLY  
KEEPS WATER  
WARM & BOILS

INCLUDES  
SAFETY  
COVER

Image: The samovar with a decorative plate positioned under the tap, designed to catch drips and enhance safety.

## MAINTENANCE

---

### Cleaning

- Always unplug the samovar and allow it to cool completely before cleaning.
- Wash the upper pot, lid, and infuser with warm water and liquid dish soap.
- Wipe the exterior of the bottom pot with a damp cloth. Do not immerse the electrical base in water.
- For stubborn stains or mineral deposits, use a descaling solution suitable for stainless steel appliances, following the product instructions.
- Dry all parts thoroughly before reassembly or storage.

**Note:** The samovar is not dishwasher safe.

## TROUBLESHOOTING

---

### 1. Samovar does not turn on

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the power switch is in the 'ON' position.

- Verify that the circuit breaker has not tripped.

## 2. Water is not boiling or staying warm

- Confirm that the boiling function is activated.
- Ensure there is sufficient water in the bottom pot. The dry boil protection feature will prevent heating if water levels are too low.
- Check for any error indicators on the unit.

## 3. Water leaks from the tap

- Ensure the tap is fully closed after use.
- Check if the tap is properly installed and tightened.

## SPECIFICATIONS

<b>Model Name</b>	Korkmaz Hanedan A843-04
<b>Brand</b>	Hakan
<b>Manufacturer</b>	Korkmaz
<b>Material</b>	Stainless Steel
<b>Color</b>	Inox - Rose Gold
<b>Upper Pot Capacity</b>	1.3 L (43.9 Fluid Ounces)
<b>Bottom Pot Capacity</b>	3.5 L (118.3 Fluid Ounces)
<b>Total Capacity</b>	5.1 Quarts (162.2 Fluid Ounces / 4800 mL)
<b>Power Plug</b>	110 V US Plug
<b>Product Dimensions</b>	13"D x 12"W x 17"H
<b>Item Weight</b>	2.4 pounds
<b>Dishwasher Safe</b>	No



PLATE  
INCLUDED  
FOR SAFETY

Image: Close-up of the samovar's power cord, showing the 110V US plug for direct use without a converter.

## WARRANTY INFORMATION

---

For specific warranty details, including coverage period and terms, please refer to the documentation included with your product or contact the manufacturer directly. Warranty information may vary based on region and purchase date.

## CUSTOMER SUPPORT

---

Should you require assistance, have questions, or encounter any issues with your Korkmaz Hanedan A843-04 Electric Turkish Tea Maker Samovar, please contact Hakan customer support. Refer to your product packaging or the manufacturer's official website for contact details.