

Yoursme YS-W10324651

Yoursme W10324651 Drive Hub Kit Instruction Manual

Model: YS-W10324651

1. INTRODUCTION

This manual provides instructions for the installation and use of the Yoursme W10324651 Drive Hub Kit. This kit is designed as a replacement drive block for the inner tub of various washing machine models.

The W10324651 Drive Hub Kit is compatible with a wide range of washing machine brands, including Whirlpool, Maytag, KitchenAid, Jenn-Air, Amana, Magic Chef, Admiral, Norge, Roper, and Kenmore. It replaces part numbers W10324651, 1877235, AH2581262, EA2581262, PS2581262, W10291415, W10291416, W10291417, W10528947, W10396887, W10528947VP, PS6012095, AP5665171, 2684908, and EAP6012095.

Proper installation of this drive hub kit can help resolve common washing machine issues such as unusual noise, water leakage, shaking and moving during operation, and problems with agitation or spinning.



W10324651

WASHER BASKET DRIVE HUB KIT

Ensure your washing machine operates smoothly and efficiently



Image 1.1: Overview of the W10324651 Washer Basket Drive Hub Kit components.

2. PACKAGE CONTENTS

The W10324651 Drive Hub Kit includes the following components:

- Basket Driven Hub
- Drive Block Retainers
- 6 Screws
- 2 Wire Harness Holders

3. SAFETY INFORMATION

Before attempting any repairs or installations on your washing machine, please observe the following safety precautions:

- **Disconnect Power:** Always unplug the washing machine from the power outlet before beginning any work to

prevent electrical shock.

- **Water Supply:** Turn off the water supply to the washing machine.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and safety glasses.
- **Consult Professional:** If you are unsure about any step or lack the necessary tools or experience, it is recommended to consult a qualified appliance repair technician.
- **Original Manual:** Refer to your washing machine's original service manual for specific disassembly and reassembly instructions for your model.

4. INSTALLATION INSTRUCTIONS


Follow these steps to install the W10324651 Drive Hub Kit. These are general guidelines; specific washer models may have variations. Always refer to your appliance's service manual for detailed instructions.

1. **Remove Old Driven Hub and Drive Block:** Carefully disassemble the washing machine to access the inner tub and the existing driven hub and drive block. Remove these old components.
2. **Install New Drive Block onto Spin Tube:** Place the new drive block component onto the spin tube of the washing machine.
3. **Install Driven Hub Using Screws:** Position the new driven hub over the drive block and secure it using the provided screws. Ensure they are tightened appropriately.
4. **Install Tub Nut and Hand Tighten:** Install the tub nut and hand tighten it to secure the assembly.
5. **Tighten Nut with Hammer and Wrench:** Use a wrench to further tighten the tub nut. Lightly tap the wrench with a hammer to ensure a secure fit.
6. **Inspect Installation:** Visually inspect all connections and components to ensure they are correctly installed and secure before reassembling the washing machine.



USER-FRIENDLY OPERATION

Come with instruction manual for easy operation



01



Remove old driven hub and drive block

02




Install new drive block onto spin tube

03



Install driven hub using screws

04



Install tub nut and hand tighten

05



Tighten nut by lightly tapping wrench with hammer

06



Inspect installation

Image 4.1: Step-by-step installation process for the drive hub kit.

5. OPERATING

After successful installation of the W10324651 Drive Hub Kit and reassembly of your washing machine, the appliance should operate as intended. The new drive hub facilitates the proper rotation and agitation of the inner tub, ensuring efficient washing and spinning cycles. Conduct a test cycle without laundry to confirm proper function and absence of leaks or unusual noises.

6. MAINTENANCE

The W10324651 Drive Hub Kit is constructed from durable aluminum and steel with a protective coating designed to resist corrosion, rust, and oxidation, ensuring a long service life. Regular maintenance of your washing machine, such as cleaning the tub and checking for any obstructions, will help prolong the life of all components, including the drive hub.

7. TROUBLESHOOTING

If you experience issues after installing the W10324651 Drive Hub Kit, consider the following:

- **Unusual Noise/Shaking:** Re-check the tightness of all fasteners, especially the tub nut. Ensure the drive hub and drive block are seated correctly. Verify that the washing machine is level.
- **Water Leakage:** Inspect all water connections and seals. Ensure the tub nut is sufficiently tightened.
- **No Agitation/Improper Spinning:** Confirm that the drive hub is fully engaged with the spin tube and that the drive block retainers are correctly installed. Ensure no foreign objects are obstructing the tub's movement.

If problems persist, it is advisable to consult a professional appliance repair technician.



DIRECTLY REPLACEMENT

Washer hub replaces for the following part numbers

W10324651	W10291415	W10528947VP
1877235	W10291416	PS6012095
AH2581262	W10291417	AP5665171
EA2581262	W10528947	2684908
PS2581262	W10396887	EAP6012095

Image 7.1: Common washing machine problems that the drive hub kit can help address.

8. SPECIFICATIONS

Manufacturer	Yoursme
--------------	---------

Part Number	YS-W10324651
Item Weight	8.3 ounces
Product Dimensions	4 x 4 x 1 inches
Included Components	1x Drive Hub Kit (Basket Driven Hub, Drive Block Retainers, 6 Screws, 2 Wire Harness Holders)





Premium Matrials

Exceed a high-quality and high-strength standard



CNC Machined

Extremely high accuracy with consistent tolerances



Long Time Service

Safe to use for many years without trouble

High Quality

Constructed from premium aluminum and steel, finished with coating
Strong, durable, rust-proof and corrosion-resistant
Hardened construction offers high strength and impact resistance
Manufactured to exceed the OEM specification and quality



Image 8.1: Product dimensions of the drive hub kit components.

9. WARRANTY AND SUPPORT

This product comes with a **1-Year Warranty** from the manufacturer, Yoursme. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the manufacturer's official website. Always ensure you have your purchase details and model number (YS-W10324651) available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question