

WLIVE ADSJ611BL

WLIVE TV Stand Instruction Manual

Model: ADSJ611BL

For 32-60 inch LCD TVs and Monitors

1. INTRODUCTION

Thank you for purchasing the WLIVE TV Stand. This manual provides essential information for the safe and efficient use of your new TV stand. Please read these instructions carefully before assembly and operation, and keep them for future reference. This stand is designed to accommodate 32 to 60-inch LCD TVs and monitors, offering mobility, adjustable viewing angles, and a stable platform for your display and accessories.





Figure 1: Front view of the WLIVE TV Stand with a mounted television.

2. PRODUCT FEATURES

- **VESA Standard Compatibility:** Supports VESA patterns from 10x10cm to 40x40cm, suitable for 32-60 inch TVs and monitors.
- **Convenient Mobility:** Equipped with smooth-rolling casters for easy movement. Front wheels feature foot-operated stoppers for secure locking without bending down.
- **Adjustable Height and Angle:** Height can be adjusted from 95cm to 165cm based on hardware mounting position. The rack's angle can be tilted up and down by 15 degrees for optimal viewing.
- **Integrated Cable Management:** Features a cable management system to neatly organize and conceal cables, maintaining a clean and tidy appearance.
- **Sturdy Construction:** Made from durable steel with an epoxy resin powder coating, ensuring stability and longevity.
- **Accessory Shelf:** Includes a shelf for placing peripheral devices such as projectors, media players, or laptops.

身長や使う場所に合わせて、高さ調節

低位置で使う テレビ会議など座る時



高位置で使う プレゼンや展示会、受付に



Figure 2: Illustration of the adjustable height feature, ranging from 95cm to 165cm.

別ルームへ移動や掃除が便利に キャスター付き



Figure 3: The stand's casters allow for easy movement and feature a locking mechanism for stability.

3. PRODUCT SPECIFICATIONS

Specification	Detail
Model Number	ADSJ611BL
Main Unit Size (W x D x H)	50 x 37 x 95-165 cm
Shelf Size	49 x 30 cm
Main Unit Weight	9.72 kg
Package Weight	11 kg
Rack Load Capacity	30 kg
Shelf Load Capacity	5 kg

Material	Steel (Epoxy Resin Powder Coating)
VESA Compatibility	10x10cm to 40x40cm
Compatible TV/Monitor Size	32-60 inches
Maximum Tilt Angle	15 degrees (up/down)



Figure 4: Comprehensive dimensions and specifications of the TV stand.

4. ASSEMBLY INSTRUCTIONS

The WLIVE TV Stand comes with a Japanese instruction manual and all necessary display mounting screws for straightforward assembly. While specific step-by-step instructions are not provided here, general assembly typically involves:

1. **Unpacking:** Carefully remove all components from the packaging and verify against the parts list in the included manual.

2. **Base Assembly:** Assemble the base components, ensuring the casters are securely attached.
3. **Column Installation:** Attach the main support column to the assembled base.
4. **Shelf Attachment:** Install the accessory shelf at the desired height on the column.
5. **TV Bracket Assembly:** Attach the VESA compatible TV mounting brackets to the top of the column.
6. **TV Mounting:** Securely attach your TV or monitor to the mounting brackets using the provided screws. Ensure the TV is centered and level.
7. **Cable Management:** Utilize the integrated cable management system to route and conceal all connecting cables for a neat setup.

Always refer to the detailed instruction manual included in your product package for precise assembly steps and safety guidelines.

5. OPERATION

5.1. Height Adjustment

The height of the TV stand can be adjusted to suit various viewing preferences and environments. Locate the height adjustment mechanism on the main column (typically a knob or lever). Loosen it, adjust the TV to the desired height between 95cm and 165cm, and then securely tighten the mechanism to lock the height in place.

5.2. Angle Adjustment

The TV mounting rack allows for a vertical tilt of up to 15 degrees (both upwards and downwards). To adjust the angle, gently tilt the TV to your preferred viewing angle. The mechanism is designed to hold the angle once set. Ensure the TV is stable after adjustment.

5.3. Mobility and Locking Casters

To move the TV stand, ensure the caster locks on the front wheels are disengaged. Gently push or pull the stand to its new location. Once positioned, engage the foot-operated stoppers on the front casters to securely lock the stand in place and prevent unintended movement.





対応サイズ	32 -60v
ラック耐荷重	40kg
棚板耐荷重	10kg
総耐荷重	50kg
VESA最大限	60×40cm
本体材質	スチール

このような梱包でお届けします。

※こちらの商品はお客様組立となります。

※日本語取り扱い説明書付き



Figure 5: Visual representation of height and angle adjustment capabilities.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight and secure. Retighten if necessary.
- **Caster Maintenance:** Keep the casters free from dust and debris to ensure smooth movement. If they become stiff, clean them and apply a small amount of silicone lubricant if needed.

- **Load Capacity:** Do not exceed the maximum load capacities for the rack (30kg) and shelf (5kg) to prevent damage or instability.

7. TROUBLESHOOTING

7.1. Stand is unstable or wobbly.

- Ensure all assembly screws are fully tightened.
- Verify that the TV is properly centered and securely mounted on the VESA brackets.
- Check that the casters are locked when the stand is stationary.
- Ensure the stand is placed on a flat, level surface.

7.2. Casters are difficult to move or lock.

- Check for any debris (e.g., hair, lint) caught in the caster wheels and remove it.
- Ensure the locking mechanism is fully disengaged when attempting to move the stand.
- If the casters are stiff, clean them and apply a small amount of silicone-based lubricant.

7.3. TV appears too high or too low.

- Adjust the height of the main column as described in Section 5.1.
- Note that if your TV is less than 45cm in height, the stand's pole may protrude from behind the TV. This is a design characteristic and not a defect.

8. WARRANTY AND SUPPORT

WLIVE offers a one-year warranty for this product. For any questions, concerns, or technical support regarding your WLIVE TV Stand, please contact the seller directly through your purchase platform. Please have your model number (ADSJ611BL) and purchase details ready when contacting support.

For more information, you may visit the official WLIVE store page: [WLIVE Store](#)

© 2024 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question