

[Manuals.plus](#) /

› [Gudsunal](#) /

› Gudsunal Induction Hob User Manual

Gudsunal IC3616F

Gudsunal Induction Hob User Manual

Model: IC3616F

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before installing, operating, or maintaining your Gudsunal Induction Hob. Keep this manual for future reference.

- Ensure the appliance is installed by a qualified technician in accordance with local regulations.
- Do not operate the hob if the glass surface is cracked or broken. Disconnect from power immediately.
- Use only induction-compatible cookware.
- Keep children away from the appliance during operation and cooling.
- Do not place metallic objects like knives, forks, spoons, or lids on the hob surface as they can become hot.
- Clean the hob regularly to prevent grease buildup, which can be a fire hazard.
- Ensure adequate ventilation around the appliance.
- The appliance is designed for domestic use only.

2. PRODUCT OVERVIEW

The Gudsunal Induction Hob (Model IC3616F) is a 2-plate installation unit featuring flexible cooking zones, a total power output of 3600 W, and various convenient functions for efficient cooking.




Figure 2.1: Front view of the Gudsunal Induction Hob, Model IC3616F. This image displays the two induction cooking zones, the central 'FLEX ZONE' indicator, and the touch control panel at the bottom, including power level indicators, timer controls, and power buttons.

Key Features:

- **Flex Zones:** Allows combining two cooking zones into one large zone for larger cookware.

- **3600 W Total Power:** High power output for rapid heating.
- **Booster Function:** Provides extra power for quick boiling or searing.
- **9 Power Levels:** Precise control over cooking temperature.
- **Timer Function:** Set cooking durations for individual zones.
- **Automatic Shut-Off:** Enhances safety by turning off the hob after a period of inactivity or if overheating occurs.
- **Continuous Low Power Heating:** Maintains consistent low temperatures for simmering.

3. SETUP AND INSTALLATION

The Gudsunal Induction Hob is designed for drop-in installation. Professional installation is recommended.

3.1 Unpacking and Inspection

Carefully remove the hob from its packaging. Inspect for any damage during transit. Retain packaging materials for potential future transport or returns.



Figure 3.1: Packaging box displaying the model number IC3616F, rated voltage 220-240V~, 50/60Hz, and total power 3600W. The box also shows handling symbols like 'fragile' and 'keep dry'.




Figure 3.2: The bottom side of the product packaging, indicating the correct orientation for storage and handling. Symbols include 'do not step on' and 'do not stack'.

3.2 Installation Requirements

- **Cut-out Dimensions:** Refer to the included cut-out size board for precise measurements. The product dimensions are 52 x 29 x 5.8 cm.
- **Electrical Connection:** The hob requires a 240 Volts (AC) power supply. Total wattage is 3600 watts. Ensure the electrical circuit can support this load. The power cable is approximately 80 cm long.
- **Ventilation:** Ensure sufficient clearance around the hob for proper ventilation to prevent overheating.
- **Included Components:** The package includes the hob, a cut-out size board, sealing tape, and installation kits. A user manual is also provided.

3.3 Installation Steps

1. Prepare the countertop opening according to the provided cut-out size board.
2. Apply the sealing tape around the edges of the hob to prevent liquid ingress.
3. Carefully lower the hob into the prepared opening.
4. Connect the hob to the electrical supply, ensuring all connections are secure and comply with local electrical codes.
5. Test the hob's functionality before permanent use.

4. OPERATING INSTRUCTIONS

The Gudsunal Induction Hob features intuitive touch controls for ease of use.

4.1 Basic Operation

- **Power On/Off:** Touch the power symbol () to turn the hob on or off.
- **Zone Selection:** Select the desired cooking zone by touching its corresponding control.
- **Power Level Adjustment:** Use the '+' and '-' buttons to adjust the power level from 1 to 9.
- **Booster Function:** Touch the 'B' button for a quick power boost. This function provides maximum power for rapid heating and will automatically reduce to a lower power level after a set time.

4.2 Flex Zone Function

The Flex Zone allows you to combine two individual cooking zones into one large zone, ideal for oversized pots, griddle pans, or multiple smaller pots.

- To activate the Flex Zone, place your large cookware across both designated flexible zones.
- Select one of the flexible zones and then touch the 'FLEX ZONE' button (if available on the control panel, otherwise the hob will automatically detect). The two zones will now operate as a single unit with a unified power setting.
- Adjust the power level as usual for the combined zone.

4.3 Timer Function

The timer can be set for individual cooking zones to automatically turn them off after a specified duration.

- Select the cooking zone for which you want to set the timer.
- Touch the timer button (often represented by a clock symbol).
- Use the '+' and '-' buttons to set the desired cooking time.
- The zone will automatically switch off when the timer expires.

4.4 Automatic Shut-Off

For safety, the hob will automatically shut off if a cooking zone is left on for an extended period without adjustment, or if it detects overheating.

5. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction hob.

- Always ensure the hob is cool and disconnected from the power supply before cleaning.
- For light spills and daily cleaning, wipe the glass surface with a soft cloth and a mild detergent.
- For stubborn stains or burnt-on food, use a ceramic hob scraper, holding it at a shallow angle.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the glass surface.
- The hob surface has a slightly granular texture, which may require thorough cleaning to avoid leaving traces.
- Clean the control panel with a damp cloth; avoid excessive moisture.

6. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; power cord not connected; circuit breaker tripped.	Check power connection; reset circuit breaker; ensure power is available.
Cooking zone not heating.	Non-induction compatible cookware; cookware not centered; small cookware.	Use induction-compatible pots/pans; center cookware; use appropriate size cookware.
Display shows an error code.	Specific malfunction.	Refer to the detailed error code list in the included user manual for specific actions. If the issue persists, contact customer support.
Unusual noise during operation.	Normal fan noise; cookware vibration.	A slight fan noise is normal for induction hobs. Some cookware may vibrate slightly, which is not a fault.

7. TECHNICAL SPECIFICATIONS

Detailed specifications for the Gudsunal Induction Hob, Model IC3616F.

Specification	Value
Brand Name	Gudsunal
Model Info	IC3616F
Product Dimensions	52 x 29 x 5.8 cm
Item Weight	4.3 kg
Installation Type	Drop-In
Burner Type	Induction
Heating Elements	2
Voltage	240 Volts (AC)
Wattage	3600 watts

Specification	Value
Fuel Type	Electric
Material Type	Metal
Special Features	Timer, Continuous Low Power Heating, Booster, Flex Zones, Automatic Shut-Off
Included Components	Cut-out size board, User Manual, Sealing tape, hob, Installation kits

8. WARRANTY AND SUPPORT

For warranty information and technical support, please contact the manufacturer or authorized service centers.

8.1 Manufacturer Information

- **Manufacturer:** Foshan Cavi Trading Co., Ltd.
- **Address:** Room 702, Building 4, No.10, Tongxing road, Chancheng, 528000 Foshan, Guangdong, China.



Figure 8.1: Side of the product packaging displaying manufacturer and importer contact details in both Chinese and English.

8.2 Customer Service

- **General Service Contact:** service@gudsunalkitchen.com
- **UK Representative (SEASAA LIMITED):**
 - **Address:** 5 South Charlotte Street, EH2 4AN, EH3 6RE, United Kingdom
 - **Telephone:** +44 (0)2039255748
 - **Email:** seasaa289@outlook.com



Figure 8.2: Side of the product packaging displaying the UK representative's contact information, including address, telephone, and email.

For detailed warranty terms and conditions, please refer to the warranty card included with your product or contact customer service.

© 2024 Gudsunal. All rights reserved.

This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D8QQ637C>

More documents and user manuals: <https://manuals.plus/>