Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOSHIRO KT-4DG-B

BOSHIRO 4-Drawer Black Dresser Instruction Manual

Model: KT-4DG-B

1. Introduction

Thank you for choosing the BOSHIRO 4-Drawer Black Dresser. This modern storage cabinet is designed to provide ample storage and complement various home styles, including modern minimalist and industrial aesthetics. This manual contains important information regarding the safe assembly, proper use, and maintenance of your new dresser. Please read it thoroughly before assembly and retain it for future reference.



Image 1.1: The BOSHIRO 4-Drawer Black Dresser, a modern storage solution for various rooms.

2. Safety Information

WARNING: Furniture Tip-Over Hazard

- Serious or fatal crushing injuries can occur from furniture tip-overs.
- To help prevent tip-over, this furniture must be permanently attached to the wall using the wall attachment device(s) provided.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Place heaviest items in the lowest drawers.
- Do not place heavy objects on top of the dresser unless it is securely anchored.

Always follow these safety guidelines to ensure the well-being of your household.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Expected Components:

- Dresser Top Panel
- Side Panels (2)
- Back Panel
- Drawer Fronts (4)
- Drawer Side Panels (8)
- Drawer Back Panels (4)
- Drawer Bottom Panels (4)
- Drawer Glides (8 pairs)
- Vintage Metal Knobs (4)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Kit (wall anchor, strap, screws)
- Instruction Manual



Image 3.1: Illustration of key features including vintage metal knobs, solid construction, and deep drawers, indicative of components.

4. Setup and Assembly Instructions

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate assembly guide included in your package. Ensure you have all necessary tools (typically a screwdriver and hammer) before starting.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Verify against the parts list.
2. **Assemble the Frame:** Attach the side panels to the base and top panels using the provided hardware. Ensure all connections are secure.
3. **Install Drawer Glides:** Secure the drawer glides to the inner sides of the dresser frame according to the instructions.
4. **Assemble Drawers:** Construct each of the four drawers by attaching the front, back, and side panels, then inserting the bottom panel. Install the remaining drawer glides onto the assembled drawers.
5. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame.
6. **Attach Knobs:** Secure the vintage metal knobs to the front of each drawer.
7. **Install Anti-Tip Kit:** This is a critical safety step. Attach the anti-tip device to the back of the dresser and securely anchor it to a wall stud using the provided hardware. Refer to the anti-tip kit instructions for detailed steps.



Image 4.1: Visual representation of the dresser's dimensions and the spacious interior of its four drawers, indicating ease of access and storage capacity.

5. Operating Instructions

The BOSHIRO 4-Drawer Black Dresser is designed for convenient storage in various rooms. To ensure optimal functionality and longevity:

- **Drawer Usage:** Open and close drawers smoothly using the knobs. Avoid forcing drawers open or shut, as this can damage the glides.
- **Weight Distribution:** Distribute weight evenly within the drawers. Place heavier items in lower drawers to enhance stability and prevent tip-over.
- **Placement:** Position the dresser on a level surface to prevent wobbling and ensure proper drawer alignment.

6. Maintenance

Proper care will help maintain the appearance and structural integrity of your dresser.

- **Cleaning:** Wipe the surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Environmental Conditions:** Avoid placing the dresser in direct sunlight or near heat sources, as this can cause warping or fading. Maintain a stable room temperature and humidity.



Image 6.1: Visual representation of the dresser's key attributes: easy cleaning, stable structure, and waterproof properties, highlighting its durability and low maintenance.

7. Troubleshooting

Common Issues and Solutions:

- **Drawers are difficult to open/close:**
  - Check if the drawer glides are properly aligned and installed.
  - Ensure no items are obstructing the drawer's path.
  - Verify that the dresser is on a level surface.
- **Dresser wobbles:**
  - Ensure all assembly hardware is securely tightened.
  - Place the dresser on a flat, even floor. Use furniture pads or shims if necessary to level it.

- **Missing parts or damaged components:**
  - Do not proceed with assembly. Contact BOSHIRO customer support immediately for replacement parts.

8. Specifications

Brand	BOSHIRO
Model Name	KT-4DG-B
Product Dimensions	15.75"D x 31.5"W x 35.4"H
Color	Black
Number of Drawers	4
Item Weight	80.3 pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Damp Cloth

9. Warranty and Support

For any questions, concerns, or assistance with your BOSHIRO dresser, please contact BOSHIRO customer support. While specific warranty details are not provided in this manual, BOSHIRO is committed to customer satisfaction.
You can visit the official BOSHIRO store for more information or to contact support:

Visit the BOSHIRO Store

© 2024 BOSHIRO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8S7T7LB

More documents and user manuals: **https://manuals.plus/**