



[Manuals.plus](#) /

> [Wanish](#) /

> Wanish Electric Warming Tray FWT-800 (XXL 32"x18") Instruction Manual

Wanish FWT-800

Wanish Electric Warming Tray FWT-800 (XXL 32"x18") Instruction Manual

Model: FWT-800 | Brand: Wanish

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Wanish Electric Warming Tray. Please read these instructions thoroughly before first use and retain for future reference.



Image 1: The Wanish Electric Warming Tray (XXL 32"x18") keeping multiple dishes warm.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent injury or damage, observe the following precautions:

- Always place the warming tray on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the power cord is not damaged or frayed. Do not operate if the cord or plug is damaged.
- Keep children and pets away from the warming tray during operation. The main heating surface becomes hot.
- The anti-scald edges and handles remain cool to the touch, but exercise caution when handling hot dishes.
- Do not place plastic containers or items that may melt directly on the heating surface. Use heat-resistant cookware made of tempered glass, ceramic, or metal.
- Unplug the appliance when not in use and before cleaning. Allow it to cool completely before handling or storing.
- The built-in thermostat prevents overheating, ensuring safe, long-term operation.

3. PRODUCT FEATURES

- **Large Capacity:** XXL 32"x18" tempered glass surface accommodates 6-8 dishes simultaneously.
- **Full Surface Heating:** Utilizes heating wire and heating film with PTC technology for even heat distribution across the entire surface.
- **Adjustable Temperature:** Two temperature modes: Low (104°F) and High (284°F).
- **Safety Features:** Built-in thermostat for stable temperature control and overheat protection. Anti-scald aluminum handles and edges remain cool. Raised rubber feet ensure air circulation and protect tabletops.
- **Durable Construction:** Heat-resistant tempered glass with premium rose gold stainless steel edges.
- **Extended Power Cord:** 78-inch non-removable power cord for flexible placement.

WANISH WARMING TRAY




Image 2: Key features and dimensions of the Wanish Electric Warming Tray.

4. SETUP

1. Unpack the warming tray and remove all packaging materials.
2. Place the warming tray on a flat, stable, and heat-resistant surface. Ensure adequate clearance around the unit for proper ventilation.

3. Plug the 78-inch power cord into a standard 110V electrical outlet.
4. The appliance is ready for use without any assembly required.

5. OPERATING INSTRUCTIONS

The Wanish Electric Warming Tray features a simple mechanical button operation for temperature control.

1. **Power On:** Locate the power switch, typically on the side or front edge of the tray. Flip the switch to the 'Low' or 'High' position to turn on the unit.
2. **Select Temperature:** Choose between 'Low' (104°F) for maintaining warmth or 'High' (284°F) for heating colder items or faster warming.
3. **Preheat:** Allow the tray to preheat for a few minutes to reach the desired temperature. The warm indicator light will illuminate when the tray is active.
4. **Place Dishes:** Place cooked, hot dishes directly onto the tempered glass surface. Ensure dishes are made of heat-resistant materials such as glass, ceramic, or metal.
5. **Monitor:** The built-in thermostat will maintain the set temperature, preventing overheating and ensuring food remains warm for extended periods.
6. **Power Off:** When finished, flip the power switch to the 'Off' position and unplug the unit from the electrical outlet.

Temperature Adjustable, Easy To Operate

OURS



- ✓ 2 Temperature Modes
- ✓ High 284°F/ Low 158°F
- ✓ 2 temperature settings are sufficient for most uses.
- ✓ Button operation is simple and easy for the elderly.
- ✓ Side button design avoids dishes, avoid accidental touch. Doesn't block the sight of temperature adjustment.
- ✓ Mechanical buttons with long service life.

OTHERS



- ✗ Easy to lose touch sensitivity
- ✗ Easy to accidentally touch and cause functional changes during use
- ✗ Large temperature control panel occupies heating area
- ✗ Difficult to control with wet hands
- ✗ Easy to forget to unlock the child lock mode
- ✗ Complex modes are not user-friendly for the elderly
- ✗ Easy to hide under dishes, difficult to operate

Image 3: Simple mechanical temperature control for ease of use.

6. MULTI-FUNCTIONAL USES

Beyond keeping food warm for parties and buffets, your Wanish Electric Warming Tray offers versatile applications:

- **Defrosting:** Gently defrost frozen foods.
- **Dough Fermentation:** Provide a warm environment for dough to rise.
- **Drying:** Use for gentle drying of various items.
- **Warming Beverages:** Keep milk, wine, or tea warm.
- **Face Mask Warming:** Warm face masks for a spa-like experience.

4-IN-1 FUNCTION



Keep Warm



Thawing



Dough
Fermentation



Drying



Image 4: The warming tray's versatile 4-in-1 functionality.

7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your warming tray:

- Always ensure the appliance is unplugged and completely cool before cleaning.
- The tempered glass surface is explosion-proof, waterproof, and oil-proof, making it easy to clean.
- Wipe the glass surface with a soft, damp cloth and mild detergent. For stubborn stains, a glass cleaner can be used.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Wipe the handles and edges with a damp cloth.
- Ensure all parts are thoroughly dry before storing or next use.
- Store the warming tray in a dry place. Its slim body design allows for flat or vertical storage.

8. TROUBLESHOOTING

If you encounter issues with your warming tray, refer to the following common solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working electrical outlet and the power switch is in the 'Low' or 'High' position.
- **Food not warming sufficiently:** Verify that the correct temperature setting ('High' for faster warming) is selected. Ensure dishes are heat-resistant and placed directly on the heating surface.
- **Uneven heating:** The full surface heating technology is designed for even distribution. Ensure dishes are not excessively large or covering the entire surface in a way that impedes heat transfer.
- **Overheating:** The built-in thermostat prevents overheating. If the unit feels excessively hot, it may automatically reduce power or shut off as a safety measure. Allow it to cool before resuming use.

For further assistance, please contact customer support as detailed in the Warranty and Support section.

9. SPECIFICATIONS

Specification	Detail
Model Number	FWT-800
Product Dimensions	32"L x 18"W x 1.18"H
Item Weight	13 Pounds
Material	Heat-resistant Tempered Glass, Premium Rose Gold Stainless Steel Edges and Handles
Color	Black
Voltage	110 Volts
Wattage	350 watts
Maximum Temperature	284 Degrees Fahrenheit
Power Source	Corded Electric

10. WARRANTY AND SUPPORT

Wanish offers a one-year guarantee for this Electric Warming Tray. For any questions or support needs, please follow these steps:

1. Go to the product page on Amazon.
2. Click on "Sold by Wanish".
3. Select "Ask a question".
4. Send your question to seller customer support for an effective response.