

[Manuals.plus](#) /

› [Vesgantti](#) /

› Vesgantti 68" Loveseat Sofa Instruction Manual

## Vesgantti 68" Loveseat Sofa

# Vesgantti 68" Loveseat Sofa Instruction Manual

Model: 68" Loveseat Sofa

## 1. SAFETY INFORMATION

---

Always use this product indoors and ensure it is assembled correctly to avoid injury. Do not exceed the maximum weight capacity of 772 lbs. Be cautious when handling the non-slip protective backing on the legs during assembly.

## 2. SETUP AND ASSEMBLY

---

The Vesgantti 68" Loveseat Sofa is designed for tool-less assembly. It arrives in one package, and assembly is recommended for two people, typically taking about 10 minutes.

### 2.1 Unpacking

- Carefully open the packaging to avoid scratching the sofa components.
- Remove all components and protective materials.

### 2.2 Assembly Steps

Follow the included visual instructions for connecting the sofa sections and attaching the legs. Ensure all connections are secure before use.



Image: Fully assembled Vesganti 68" Loveseat Sofa.

### 2.3 Initial Cushion Recovery

Due to compressed packaging, cushions require time to fully recover their shape and fluffiness. This process typically takes 24-48 hours.

- Place the sofa in a ventilated, dry, and warm area.
- Gently pat the cushions with your hands or a soft tool (like a wooden stick) to help them regain elasticity and fluffiness faster.



Image: Internal structure of the sofa, highlighting foam cushions, springs, and solid wood frame.

## 3. OPERATION AND USAGE

### 3.1 General Use

The loveseat sofa features an FSC Certified solid wood frame, ensuring sturdiness and durability. Non-slip protective backing on the legs provides stability and protects flooring.



Image: Detail of the FSC Certified solid wood frame.

### 3.2 Weight Capacity

The maximum weight capacity for this loveseat sofa is 772 lbs.

### 3.3 Ergonomic Design

The sofa includes ergonomic armrests designed to provide comfortable support. The deep seat cushion (21.3 inches) offers ample space for relaxation and helps maintain good posture.

## 4. CARE AND MAINTENANCE

### 4.1 Fabric Care (Corduroy)

The corduroy fabric is thick and wear-resistant. For general cleaning:

- Regularly vacuum the fabric using a soft brush attachment to remove dust and debris.

- For spills, blot immediately with a clean, dry cloth. Avoid rubbing, which can spread the stain.
- For deeper cleaning, consult a professional upholstery cleaner or use a mild fabric cleaner suitable for corduroy, testing on an inconspicuous area first.



Image: Detail of the corduroy fabric texture.

#### 4.2 Cushion Care

Both seat and back cushions are removable. The seat cushions also have removable covers.

- Rotate and fluff cushions regularly to maintain their shape and even out wear.
- If covers are removable, follow care instructions on the label for cleaning. Typically, gentle machine wash or hand wash with cold water and air dry is recommended.

#### 4.3 Wood Frame Care

Wipe the wood frame and legs with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.

### 5. TROUBLESHOOTING

#### 5.1 Cushion Fluffiness Issues

If cushions do not fully recover their shape after unpacking:

- **To restore fluffiness:** After carefully opening the package, place the sofa in a ventilated, dry, and warm place and wait for at least 48 hours for it to naturally recover.
- **To speed up recovery:** Gently tap the foam sofa with a tool such as a wooden stick, or slap the sofa with your hand. This can help it regain elasticity more quickly.
- **If shape is still not restored:** Use a hairdryer to heat the sofa at a safe distance, gently stretching and reshaping the foam until it is back to flat.

## 6. PRODUCT SPECIFICATIONS




Image: Key dimensions and weight capacity of the loveseat sofa.

Feature	Detail
Brand	Vesgantti
Type	Loveseat
Product Dimensions (D x W x H)	30"D x 68"W x 35"H

Feature	Detail
Item Weight	75.6 Pounds
Weight Limit	772 Pounds
Seating Capacity	2
Seat Depth	21.3 inches
Seat Height	5.5 Inches
Seat Back Interior Height	17.7 Inches
Minimum Required Door Width	68 Inches
Upholstery Fabric Type	Corduroy
Frame Material Type	Wood (FSC Certified Solid Wood)
Fill Material	Springs, Foam
Suspension Type	Spring
Item Firmness Description	Medium
Assembly Required	Yes (Tool-less)
Indoor Outdoor Usage	Indoor
Has Removable Seat Cushion Cover	true
Back Cushion Removability	Removable
Seat Cushion Removability	Removable

## 7. WARRANTY AND CUSTOMER SUPPORT

### 7.1 Product Warranty

This Vesgantti Loveseat Sofa comes with a Limited Warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase or contact customer support.

### 7.2 Return Policy

The product is eligible for a 30-day return policy, allowing for refunds or replacements. Please refer to the retailer's return policy for full terms and conditions.

### 7.3 Customer Support

For any questions, concerns, or assistance with your Vesgantti Loveseat Sofa, please contact Vesgantti customer support. Contact information can typically be found on the product packaging or the official Vesgantti website.

