

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lorus](#) /
- › [Lorus R2383PX9 Digital Quartz Watch User Manual](#)

Lorus R2383PX9

Lorus R2383PX9 Digital Quartz Watch User Manual

Model: R2383PX9

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Lorus R2383PX9 Digital Quartz Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece. Keep this manual for future reference.

PRODUCT OVERVIEW

The Lorus R2383PX9 is a digital quartz watch designed for reliability and functionality. It features a clear digital display, a durable silicone strap, and multiple functions including time, date, and chronograph. The watch is water-resistant up to 100 meters.

Watch Components and Controls






Figure 1: Front View of Lorus R2383PX9 Watch

This image displays the watch face with its digital display showing time and date. Visible buttons are labeled 'LIGHT' (top left), 'MODE' (bottom left), 'ST/STP' (top right), and 'SET/RST' (bottom right).



Figure 2: Side View of Lorus R2383PX9 Watch

This image shows the watch from a side angle, providing a clearer view of the watch case thickness and the ergonomic design of the buttons.





Figure 3: Back View of Lorus R2383PX9 Watch with Strap

This image illustrates the rear of the watch, focusing on the comfortable silicone strap and the classic buckle closure mechanism.

- **LIGHT Button (Top Left):** Activates the backlight for visibility in low-light conditions.
- **MODE Button (Bottom Left):** Cycles through different display modes (Time, Chronograph).
- **ST/STP Button (Top Right):** Used to start and stop the chronograph function.
- **SET/RST Button (Bottom Right):** Used to reset the chronograph or adjust settings in time-setting mode.

SETUP

Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the seconds begin to flash. This indicates you are in time-setting mode.
2. Press the **SET/RST** button to cycle through the settings: seconds, hours, minutes, month, date, day of the week. The currently adjustable value will flash.
3. Use the **ST/STP** button to increase the flashing value. Hold the button to advance rapidly.
4. Once all settings are correct, press the **MODE** button to exit the time-setting mode and return to the normal time display.

OPERATING

Using the Chronograph (Stopwatch)

1. From the normal time display, press the **MODE** button once to enter chronograph mode. The display will show '00:00:00'.
2. Press the **ST/STP** button to start the stopwatch.
3. Press the **ST/STP** button again to stop the stopwatch.
4. While the stopwatch is stopped, press the **SET/RST** button to reset it to '00:00:00'.
5. Press the **MODE** button to return to the normal time display.

Activating the Backlight

Press the **LIGHT** button (top left) to illuminate the display for a few seconds. This feature is useful in dark environments.

Water Resistance

Your Lorus R2383PX9 watch is water-resistant up to 100 meters (10 BAR). This means it is suitable for swimming, snorkeling, and showering. However, it is not recommended for scuba diving. Do not operate buttons while the watch is submerged in water, as this can compromise the water seal.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and strap regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid using harsh chemicals or abrasive cleaners, as these can damage the watch's finish or strap material.

Battery Replacement

The Lorus R2383PX9 watch is powered by a battery. When the display becomes dim or the watch stops functioning, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance is maintained and to prevent damage to the internal components.

TROUBLESHOOTING

- **Display is blank or dim:** The battery may be low or depleted. Refer to the "Battery Replacement" section.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not a feature of this model). If the issue persists, a battery replacement or professional inspection may be required.
- **Time is inaccurate:** Re-set the time according to the "Setting Time and Date" instructions. If inaccuracy continues, the watch may require servicing.
- **Condensation under the crystal:** This indicates a breach in the watch's water resistance. Stop using the watch immediately and seek professional repair to prevent further damage.






SPECIFICATIONS




- **Model Number:** R2383PX9
- **Display Type:** Digital
- **Movement:** Quartz
- **Case Dimensions:** Approximately 36 mm x 13 mm
- **Weight:** Approximately 40 grams
- **Strap Material:** Silicone
- **Water Resistance:** 100 meters (10 BAR)
- **Special Features:** Chronograph, Backlight
- **Power Source:** Battery powered (Battery included)
- **Manufacturer:** Seiko (Brand: Lorus)

WARRANTY AND SUPPORT

Your Lorus R2383PX9 watch is covered by a manufacturer's warranty. For specific warranty terms, duration, and to register your product, please refer to the warranty card included with your purchase or visit the official Lorus website. For technical support or service inquiries, please contact Lorus customer service through their official channels.

Related Documents - R2383PX9

<div><div><p>LORUS A Watch You Can Trust</p></div><div><p>INSTRUCTION MANUAL FOR WATCH CALIBRE VD57</p></div></div> <div><div><p>WARNING</p></div><div><p>THIS PRODUCT CONTAINS A BUTTON BATTERY If swallowed or placed inside any part of the body, this battery can cause serious or fatal injury without delay or notice. Before swallowing please check whether there is a risk. If you find the battery the have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26. New Zealand 0800 553 767 / 0800 553 767.</p></div></div>	<p>Lorus VD57 Watch Instruction Manual - Time, Date, Stopwatch Guide</p> <p>Comprehensive instruction manual for the Lorus VD57 watch, covering time and date setting, stopwatch operation, battery replacement, and care instructions. Learn how to use all features of your Lorus VD57 timepiece.</p>
<div><div><p>LORUS A Watch You Can Trust</p></div><div><p>INSTRUCTION MANUAL FOR WATCH CALIBRE VJ22</p></div></div> <div><div><p>WARNING</p></div><div><p>THIS PRODUCT CONTAINS A BUTTON BATTERY If swallowed or placed inside any part of the body, this battery can cause serious or fatal injury without delay or notice. Before swallowing please check whether there is a risk. If you find the battery the have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26. New Zealand 0800 553 767 / 0800 553 767.</p></div></div>	<p>Lorus VJ22 Analogue Quartz Watch Instruction Manual</p> <p>Official instruction manual for the Lorus VJ22 analogue quartz watch. Learn how to set the time, day, and date, understand Lumibrite features, battery care, water resistance, and adjust the band length.</p>
<div><div><p>Instruction Manual LORUS CAL. VD75</p></div><div><p>■ CHARACTERISTICS</p><ol style="list-style-type: none">1. Stop: Indicated by the hour, minute and second hands.2. Date: Indicated by the date hand.3. Day of the week: Indicated by the day hand.<p>■ DISPLAY AND CROWN / BUTTONS</p><p>Hour hand Minute hand Day hand Date hand</p><p>1. Crown 2. Pusher 3. Pusher</p><p>■ HOW TO SET THE TIME AND DAY</p><p>Day hand Date hand</p><p>■ RECOMMENDATIONS</p><ol style="list-style-type: none">1. Pull out the crown to the second click when the small second hand is pointing at the 12 o'clock position.2. Turn the crown clockwise to advance the date to the desired day of the week.3. Push the crown to set the time.4. Push the crown to set the day.<p>NOTES</p><ul style="list-style-type: none">• Do not use the day hand to set the day. The day hand is only for display.• The day hand is only for display. Do not use the day hand to set the day.• The day hand is only for display. Do not use the day hand to set the day.<p>■ HOW TO SET THE DATE</p><p>Day hand Date hand</p><p>■ RECOMMENDATIONS</p><ol style="list-style-type: none">1. Pull out the crown to the first click.2. Turn the crown clockwise to set the date to the desired day.3. Push the crown to set the time.<p>NOTES</p><ul style="list-style-type: none">• Do not use the date hand to set the date. The date hand is only for display.• The date hand is only for display. Do not use the date hand to set the date.• The date hand is only for display. Do not use the date hand to set the date.</div></div>	<p>Lorus CAL. VD75 Instruction Manual: Setting Time, Date, Day, and Care Guide</p> <p>Official instruction manual for the Lorus CAL. VD75 watch. Covers setting time, date, and day, LUMIBRITE features, battery replacement, water resistance, and essential watch care instructions.</p>

	<p>Lorus CAL. Z010 (R23 Series) Digital Watch Instruction Manual</p> <p>Detailed instruction manual for the Lorus CAL. Z010 (R23 Series) digital watch, covering time and calendar settings, stopwatch, countdown timer, alarms, second time zone, EL backlight, battery replacement, and care instructions.</p>
	<p>Lorus Watch Calibre Z009 Instruction Manual</p> <p>Comprehensive instruction manual for the Lorus Watch Calibre Z009, detailing features, operation, settings, care, and safety information for this timepiece.</p>
	<p>Lorus Watch Calibre Z021 Instruction Manual</p> <p>Official instruction manual for the Lorus Watch Calibre Z021, covering features, operation, settings, stopwatch, alarm, EL backlight, battery replacement, and care instructions.</p>