

[Manuals.plus](#) /

› [GYMAX](#) /

› GYMAX Outdoor Rattan Buffet Cabinet MB27793-94FR Instruction Manual

GYMAX MB27793-94FR

GYMAX Outdoor Rattan Buffet Cabinet

Model: MB27793-94FR

INTRODUCTION

Thank you for choosing the GYMAX Outdoor Rattan Buffet Cabinet. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new cabinet. Please read these instructions thoroughly before beginning assembly or use, and retain this manual for future reference.



Image: The GYMAX Outdoor Rattan Buffet Cabinet, featuring a black rattan weave and a light wood top, is shown in a contemporary indoor environment. The cabinet has an open shelf and two lower doors, providing versatile storage.

SAFETY INFORMATION

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the cabinet. Refer to the 'Specifications' section for weight capacities.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- While the PE rattan is sun and fade-resistant, avoid prolonged exposure to heavy rain to extend the product's lifespan.
- Place the cabinet on a level surface to ensure stability and prevent tipping. Use the adjustable foot pads to compensate for uneven ground.

SETUP AND ASSEMBLY

Your GYMAX Outdoor Rattan Buffet Cabinet requires assembly. Please follow the step-by-step instructions provided in the separate assembly manual included with your package. Ensure all components are present before starting assembly.

Key Assembly Tips:

- Identify all parts: Lay out all components and compare them with the parts list in the assembly manual.
- Use the correct tools: Ensure you have the necessary tools as specified in the assembly manual.
- Adjustable Foot Pads: Once assembled, adjust the foot pads at the base of the cabinet to ensure it stands level and stable on any surface. This is crucial for preventing wobbling and ensuring safety.



Image: A detailed diagram illustrates the dimensions of the buffet cabinet, including its overall height of 86cm, width of 90cm, and depth of 53cm. Internal measurements for the open shelf and closed cabinet are also provided, along with weight capacities for the top (75kg) and internal shelf (30kg).



Image: Close-up views highlight the cabinet's elegant metal handles, the elevated design of the feet to keep the base dry, and the adjustable foot pads that allow for leveling on uneven surfaces.

OPERATING AND USAGE

The GYMAX Outdoor Rattan Buffet Cabinet is designed for versatile storage and display in various outdoor and indoor settings.

Storage Features:

- **Wide Top Surface:** The acacia wood top provides ample space for displaying potted plants, serving dishes, or holding beverages. It has a weight capacity of up to 45 kg.
- **Open Storage Shelf:** An easily accessible open shelf is ideal for frequently used items, condiments, or decorative pieces.
- **Double-Door Cabinet:** The lower cabinet features two doors and two internal tiers, offering concealed storage for larger items, kitchenware, or gardening tools. The internal shelf has a weight capacity of 30 kg.

Recommended Applications:

This cabinet is a perfect addition to balconies, patios, gardens, poolside areas, or even as an auxiliary storage unit in outdoor kitchens or barbecue zones. Its elegant design also allows for use in indoor spaces like dining rooms or living areas.

Plateau de Table en Bois d'Acacia à Lattes



Durété
Élevée



Grain
Distinctif



Résistance
à l'Usure



Image: The buffet cabinet is shown on a balcony, demonstrating its practical storage capabilities. The open shelf holds smaller items, while the double-door cabinet below provides ample space for larger kitchen or outdoor essentials.

MAINTENANCE

Proper care will ensure the longevity and appearance of your GYMAX Outdoor Rattan Buffet Cabinet.

Cleaning:

- **PE Rattan:** Wipe the rattan surfaces with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Acacia Wood Top:** The acacia wood top is painted for protection. Clean with a soft, damp cloth. Avoid leaving

standing water on the surface. Periodically, you may wish to re-apply a wood sealant or oil to maintain its finish and weather resistance, especially if used outdoors.

- **Metal Frame:** Wipe the metal frame with a damp cloth. Dry immediately to prevent rust.

Protection:

- While the PE rattan is sun and fade-resistant, it is recommended to cover the cabinet or move it to a sheltered location during periods of heavy rain or extreme weather conditions to prevent water accumulation and extend its lifespan.
- During winter months or extended periods of non-use, storing the cabinet indoors or under a protective cover is advisable.

Rotin PE Noir




Anti-décoloration



Résistant au Soleil



Respirant



Magnifique Rotin Tissé à la Main



Rotin Tissé Lâchement à la Machine

Image: A close-up shot of the cabinet's slatted acacia wood top, emphasizing its natural wood grain and durable construction, which is resistant to wear.



Détails Impressionnants



Poignée Métallique Élégante



Pieds Surélevés pour Garder le Fond au Sec



Coussinets de Pied Réglables

Image: A magnified view of the hand-woven PE rattan, illustrating its tight weave and texture, which contributes to its durability and resistance to outdoor elements.

TROUBLESHOOTING

This section addresses common issues you might encounter with your buffet cabinet.

Wobbling or Instability:

- **Check Foot Pads:** Ensure all adjustable foot pads are properly extended and making firm contact with the ground. Adjust them individually until the cabinet is stable.
- **Tighten Fasteners:** Over time, screws and bolts may loosen. Re-tighten all assembly fasteners to ensure structural integrity.
- **Level Surface:** Verify that the cabinet is placed on a flat, even surface.

Doors Not Closing Properly:

- **Check Alignment:** Ensure the cabinet is level. An unlevel cabinet can cause doors to sag or not align correctly.
- **Inspect Hinges:** Check if hinges are securely fastened and not bent or damaged.
- **Magnetic Latches:** Verify that the magnetic latches are properly aligned and functioning.

Surface Stains or Discoloration:

- **Rattan:** For minor stains, use a mild soap and water solution. For deeper discoloration, consult a professional cleaning service for rattan furniture.
- **Acacia Wood:** Clean spills immediately. For persistent stains, light sanding and re-sealing may be necessary, but this should be done carefully to match the original finish.

SPECIFICATIONS

Feature	Detail
Brand	GYMAX
Model Number	MB27793-94FR
Color	Black
Materials	PE Rattan, Acacia Wood, Metal Frame
Overall Dimensions (L x W x H)	90 x 53 x 86 cm (35.4 x 20.9 x 33.9 inches)
Top Surface Weight Capacity	45 kg (99 lbs)
Internal Shelf Weight Capacity	30 kg (66 lbs)
Total Item Weight	17 kg (37.5 lbs)
Number of Shelves	2 (1 open, 1 inside cabinet)
Number of Doors	2
Special Features	Adjustable Foot Pads, Hand-woven Rattan, Painted Acacia Wood Top
Assembly Required	Yes
Country of Origin	Vietnam

Spécifications :

Couleur du Rotin : Noir /Mélange Marron /Mélange Gris	Capacité de Charge du Compartiment Ouvert : 15 kg
Matériau : Rotin PE, bois d'acacia, métal	Capacité de Charge de l'Étagère : 15 kg
Dimensions Totales : 90 x 53 x 66 cm (L x l x H)	Poids Net : 17 kg
Capacité de Charge de l'Armoire Supérieure : 45 kg	Paquet Comprend : 1 x Armoire de Rangement en Rotin 1 x Guide de l'Utilisateur



Image: A visual representation of the product specifications, detailing material composition, dimensions, and load capacities for different sections of the cabinet.

WARRANTY AND SUPPORT

Specific warranty information for the GYMAX Outdoor Rattan Buffet Cabinet (Model MB27793-94FR) is typically provided at the point of purchase or within the product packaging. Please refer to your purchase receipt or the documentation included with your product for details regarding warranty coverage and terms.

For technical support, missing parts, or any inquiries not covered in this manual, please contact GYMAX customer service through the retailer where you purchased the product or visit the official GYMAX website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D8V6F7VQ>

More documents and user manuals: <https://manuals.plus/>