

[Manuals.plus](#) /

› [CLP](#) /

› CLP Vangale Dining Chair Instruction Manual (Walnut/Black Faux Leather)

CLP Vangale (Model: 2610f0a0-5462-4e4e-a358-b17e1cbc1116)

CLP Vangale Dining Chair Instruction Manual

Model: Vangale (2610f0a0-5462-4e4e-a358-b17e1cbc1116)

INTRODUCTION

Thank you for choosing the CLP Vangale Dining Chair. This manual provides essential information for the safe assembly, proper use, and maintenance of your new chair. Please read these instructions carefully before assembly and retain them for future reference.

This specific model features a walnut-finished curved wood frame and black faux leather upholstery, designed for comfort and modern aesthetics.





Image: The CLP Vangale Dining Chair (Walnut/Black Faux Leather) in a contemporary dining environment.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely. Periodically check and re-tighten all fasteners to ensure stability.
- Do not stand on the chair. Use it only for seating purposes.
- The maximum recommended load capacity for this chair is **110 kg (242 lbs)**. Do not exceed this weight limit.
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.



Image: Icon indicating the maximum load capacity of 110 kg.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- 1x Seat Shell with Upholstery (Faux Leather, Black)
- 1x Four-legged Wooden Base (Walnut Finish)
- Assembly Hardware (screws, washers, Allen key)
- Assembly Instructions



Image: Main components of the CLP Vangale Dining Chair.

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the included assembly instructions carefully. A general overview of the process is provided below:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to avoid damage.
2. **Attach Base to Seat:** Align the four-legged wooden base with the pre-drilled holes on the underside of the seat shell.
3. **Secure Fasteners:** Insert the provided screws and washers into the holes. Hand-tighten all screws initially.
4. **Final Tightening:** Once all screws are in place, use the Allen key to fully tighten them. Ensure the chair is stable and all connections are secure. Do not overtighten.
5. **Check Stability:** Gently rock the chair to ensure it is stable and does not wobble. Adjust screws if necessary.



Image: Illustration of the four-legged wooden frame, indicating assembly points.

OPERATING (USAGE)

The CLP Vangale Dining Chair is designed for indoor use as a seating solution in dining rooms, kitchens, or similar areas. Its ergonomic design provides comfortable support.

- Always sit centrally on the chair to distribute weight evenly.
- Avoid sudden movements or excessive force that could compromise the chair's stability.
- The chair is equipped with floor protectors under the wooden legs to prevent scratches on delicate floor surfaces.



Image: Two CLP Vangale dining chairs positioned around a dining table.



Image: Diagram illustrating the floor protection feature on the chair legs.

MAINTENANCE

Regular maintenance will help preserve the appearance and longevity of your CLP Vangale Dining Chair.

- **Cleaning Faux Leather Upholstery:** For light dirt, wipe the faux leather surface with a soft, damp cotton cloth. Use a mild soap solution if necessary, then wipe with a clean, damp cloth and dry thoroughly. Avoid abrasive cleaners or solvents.
- **Cleaning Wooden Frame:** Wipe the wooden frame with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- **Periodic Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the upholstery and wood finish to fade or crack. Position the chair away from direct sunlight when possible.
- **Avoid Moisture:** Protect the chair from excessive moisture and humidity.






Image: Close-up view of the chair's curved wood frame and faux leather upholstery detail.



Image: Illustration depicting general care instructions for furniture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles after assembly.	Screws are not fully tightened or unevenly tightened.	Place the chair on a flat surface. Loosen all screws slightly, then sit on the chair to settle the components. Re-tighten all screws evenly and firmly.
Squeaking noises.	Loose connections or friction between parts.	Check and tighten all screws. If squeaking persists, disassemble and reassemble, ensuring all parts are correctly aligned.
Upholstery appears dull or stained.	Accumulation of dirt or improper cleaning.	Clean the faux leather upholstery as per the "Maintenance" section using a mild soap solution and a damp cloth.

SPECIFICATIONS

Feature	Detail
Brand	CLP
Model Name	Vangale
Item Model Number	2610f0a0-5462-4e4e-a358-b17e1cbc1116
ASIN	B0D8VFYMZ1
Color	Walnut/Black
Product Dimensions (D x W x H)	54 cm x 52 cm x 86 cm (21.3 in x 20.5 in x 33.9 in)
Seat Depth	40 cm (15.7 in)
Backrest Width	32 cm (12.6 in)

Feature	Detail
Item Weight	6 kg (13.2 lbs)
Recommended Maximum Load	110 kg (242 lbs)
Frame Material	Bentwood (Walnut finish)
Upholstery Material	Synthetic Leather (100% Polyurethane)
Filling Material	Polyester
Style	Modern
Assembly Required	Yes
Recommended Use	Indoor, Dining Room, Kitchen



Image: Detailed dimensions of the CLP Vangale Dining Chair.

WARRANTY INFORMATION

CLP products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact CLP customer support. Generally, warranties cover manufacturing defects under normal use conditions.

SUPPORT AND CONTACT

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact CLP customer support:

- **Manufacturer:** CLP
- **Seller:** CLP Home & Living
- For support, please visit the seller's page on Amazon or refer to the contact information provided in your product packaging.



Image: CLP Brand Logo.

© 2024 CLP. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

