Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit AC/DC Power Adapter

Kircuit AC/DC Power Adapter User Manual

For Gold's Gym Crosstrainer 480 Elliptical Exerciser GGEL639080

1. Introduction

This manual provides essential instructions for the safe and effective use of your Kircuit AC/DC Power Adapter. This adapter is specifically designed to provide power to the Gold's Gym Crosstrainer 480 Elliptical Exerciser, model GGEL639080. Please read this manual thoroughly before use to ensure proper operation and to prevent damage to your equipment.

2. Safety Information

- **Important:** Before connecting the power adapter, ensure that any batteries currently installed in the Gold's Gym Crosstrainer 480 console are removed. Operating the elliptical with both batteries and the power adapter simultaneously can cause damage.
- Use only with the specified Gold's Gym Crosstrainer 480 Elliptical Exerciser (Model GGEL639080).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not attempt to open or modify the adapter. There are no user-serviceable parts inside.
- Keep the adapter and cord away from heat sources, sharp edges, and moving parts.
- Ensure the power outlet is easily accessible and properly grounded.
- Unplug the adapter from the wall outlet when not in use for extended periods.

3. Setup Instructions

1. **Remove Batteries:** Locate the battery compartment on your Gold's Gym Crosstrainer 480 console and remove all batteries. This is a critical step to prevent potential damage.
2. **Identify Power Port:** Locate the DC power input port on your Gold's Gym Crosstrainer 480 Elliptical Exerciser. This is typically a small, round port.
3. **Connect Adapter to Elliptical:** Insert the barrel connector of the Kircuit AC/DC Power Adapter firmly into the DC power input port on the elliptical.
4. **Connect to Power Outlet:** Plug the AC plug of the adapter into a standard 100V-240V AC wall outlet.



Figure 3.1: The Kircuit AC/DC Power Adapter. This image shows the main unit with its attached power cord and barrel connector, ready for connection.



Figure 3.2: Kircuit AC/DC Power Adapter highlighting its 6.5 ft cord length. This view helps in planning placement relative to a power outlet.

4. Operating Instructions

Once the Kircuit AC/DC Power Adapter is correctly connected to both the Gold's Gym Crosstrainer 480 Elliptical Exerciser and a live wall outlet, the elliptical should receive power. The console of your elliptical should illuminate, indicating that it is ready for use. Refer to your Gold's Gym Crosstrainer 480 user manual for specific instructions on operating the elliptical itself.

5. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the elliptical before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cord to prevent damage.

- **Inspection:** Periodically inspect the adapter and cord for any signs of damage, such as frayed wires, cracks, or bent pins. If any damage is observed, discontinue use immediately and replace the adapter.

6. Troubleshooting

- **No Power to Elliptical:**
  - Ensure the adapter is securely plugged into both the elliptical and the wall outlet.
  - Verify that the wall outlet is functional by testing it with another device.
  - Confirm that all batteries have been removed from the elliptical's console.
  - Check the adapter cord for any visible damage.
- **Adapter Overheating:** If the adapter feels excessively hot to the touch, immediately unplug it from the wall and the elliptical. Discontinue use and contact the manufacturer or seller for assistance.

7. Specifications

Brand	Kircuit
Input Voltage	100V-240V AC
Output Voltage/Current	DC 6V, 2A
Connector Type	Barrel Connector
Compatible Device	Gold's Gym Crosstrainer 480 Elliptical Exerciser (Model GGEL639080)
Special Features	Built-in Dynamic IC, Charger IC & Power fuse for rapid charging and overcharge protection.
Cord Length	Approximately 6.5 ft (2 meters)

8. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the seller directly. Kircuit products are designed for reliability, and support is available for any issues encountered during normal use.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8VGLPCD

More documents and user manuals: **https://manuals.plus/**