

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOOBRO](#) /

› [HOOBRO 4-Tier Shoe Rack with 2 Drawers, Rustic Brown EBF77XJ01 - Instruction Manual](#)

HOOBRO EBF77XJ01

HOOBRO 4-Tier Shoe Rack with 2 Drawers

MODEL: EBF77XJ01 - INSTRUCTION MANUAL

Introduction

Thank you for choosing the HOOBRO 4-Tier Shoe Rack with 2 Drawers. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe organizer. Please read these instructions carefully before beginning assembly and keep them for future reference.

The HOOBRO 4-Tier Shoe Rack, Model EBF77XJ01, features two non-woven fabric drawers and a sturdy wooden top, offering a practical and stylish storage solution for your footwear and small essentials. Its lightweight design allows for versatile placement in various rooms, enhancing your home's organization and decor.

Safety Information

- **Anti-Tipping Device:** Always secure the product to the wall using the provided anti-tipping kit before use to prevent accidental tipping.
- **Children's Safety:** Do not allow infants or children to climb or play on the product. This is crucial for their safety and to prevent damage to the unit.
- **Weight Capacity:** Ensure the product is properly supported and not overloaded beyond its specified weight limits. Overloading can compromise stability and cause damage.
- **Drawer Care:** The non-woven fabric drawers are not washable. Clean them with a damp cloth as needed.

Package Contents

Please verify that all components are present before assembly. If any parts are missing or damaged, please contact customer support.

- 1 x HOOBRO 4-Tier Shoe Rack
- 1 x Anti-Tipping Kit
- 1 x Accessory Kit (includes all necessary tools and hardware)
- 1 x Instruction Manual

Setup and Assembly

Assembly of this shoe rack is designed to be straightforward. Follow the step-by-step instructions provided in the manual, using the numbered parts and included tools.

1. Unpack all components and lay them out on a clean, flat surface. Verify against the parts list in the included manual.
2. Follow the detailed, step-by-step instructions to connect the metal frame components.
3. Install the Oxford fabric shelves onto the designated tiers.
4. Assemble the non-woven fabric drawers as shown in the instructions and insert them into the top compartment.
5. Attach the anti-tipping device to the top of the unit and secure it to a wall stud using appropriate hardware.
6. Adjust the leveling feet at the bottom of the rack to ensure stability on uneven floors.

Note: One user reported a minor discrepancy in the printed instructions, showing part 6 instead of part 7 in a specific step. Please carefully verify part numbers during assembly to ensure correct installation.



Easy to Assemble



Anti-Tilting Device



2 Fabric Drawers



Adjustable Feet

Image: Detailed view of assembly steps, including the anti-tipping device, fabric drawers, and adjustable feet for stability.

Operating and Usage

This HOOBRO shoe rack is designed for versatile storage and organization in various home environments.

- **Shoe Storage:** The four tiers provide ample space for organizing 12-15 pairs of shoes, depending on their size and style. The open design allows for easy visibility and access to your footwear.
- **Removable Shelves:** The middle Oxford fabric shelf can be easily removed to create additional vertical space, accommodating taller items such as boots.
- **Drawer Storage:** Utilize the two non-woven fabric drawers for discreet storage of smaller items like keys, sunglasses, socks, gloves, or pet leashes.
- **Multi-purpose Use:** Beyond shoes, this unit serves as a versatile storage companion for entryways, hallways, living rooms, bedrooms, offices, or conservatories. It can organize CDs, books, albums, accessories, and decorative items.

Independent Shoe Display

Clear view, effortless access.



Image: The shoe rack with various shoes neatly displayed on its tiers, demonstrating easy access.

Removable Shelves

Creating Space for High Boots




Image: Illustration demonstrating the removable shelf feature, allowing storage for taller boots.

Ingenious Drawer Design

Non-woven drawers, your daily essentials organized.



Image: A close-up of the top section, highlighting the two non-woven fabric drawers for storing daily essentials.

Maintenance

Proper care will ensure the longevity and appearance of your HOOBRO shoe rack.

- **Cleaning the Frame and Top:** Wipe the metal frame and wooden top with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as they may damage the finish.
- **Cleaning Fabric Shelves and Drawers:** The Oxford fabric shelves and non-woven fabric drawers should be spot cleaned with a damp cloth. Do not machine wash or submerge them in water. Allow them to air dry completely.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause the wooden top to fade or warp.

Troubleshooting

If you encounter any issues with your shoe rack, please refer to the following common solutions:

- **Wobbling Unit:** Ensure all screws are tightened. Adjust the leveling feet at the bottom of the rack to stabilize it on uneven surfaces. Confirm the anti-tipping device is securely installed.
- **Difficulty Assembling:** Double-check that you are using the correct parts for each step, referring to the numbered diagrams in the instruction manual. If a part seems incorrect, re-examine the manual for potential minor errors (e.g., part number discrepancies as noted in the Setup section).
- **Drawers Not Sliding Smoothly:** Ensure the drawers are assembled correctly and are not overloaded. Check for any obstructions in the drawer slots.

If problems persist, please contact HOOBRO customer support for further assistance.

Specifications

Feature	Detail
Brand	HOOBRO
Model Number	EBF77XJ01
Color	Rustic Brown
Product Dimensions (L x W x H)	75 x 28 x 75 cm (29.5"L x 11"W x 29.5"H)
Maximum Weight Capacity (Top)	22 lbs (10 kg)
Maximum Weight Capacity (Each Drawer)	11 lbs (5 kg)
Maximum Weight Capacity (Each Oxford Fabric Shelf)	11 lbs (5 kg)
Material	Metal, Particleboard, Oxford Fabric, Non-woven Fabric
Special Features	Easy Assembly, Adjustable Feet, Anti-Tipping Device
Item Weight	6.8 kg
Number of Shelves	4
Style	Rustic Country



Image: Product dimensions overview.

Warranty and Support

HOOBRO products are manufactured with quality and customer satisfaction in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For product support, missing parts, or any questions regarding your HOOBRO 4-Tier Shoe Rack, please contact HOOBRO customer service through the retailer where you purchased the product or visit the official HOOBRO store page on Amazon: [HOOBRO Store](#).

