



Manuals.plus /

- › AMZASA /
- › AMZASA Farmhouse Chandelier Model AS9027-5WH Instruction Manual

## AMZASA AS9027-5WH

# AMZASA Farmhouse Chandelier (Model AS9027-5WH) Instruction Manual

## 1. INTRODUCTION

---

This manual provides detailed instructions for the safe installation, operation, and maintenance of your AMZASA Farmhouse Chandelier, Model AS9027-5WH. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Figure 1: AMZASA Farmhouse Chandelier (Model AS9027-5WH)

## 2. SAFETY INFORMATION

---

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker before installation.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass and metal components with care to prevent damage or injury.
- Ensure the mounting surface can support the weight of the fixture.
- This fixture is designed for indoor use only.

## 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged before proceeding with installation.

- Chandelier fixture (pre-assembled robotic arm structure)
- White Fabric Shades (5 pieces)
- Mounting hardware kit (canopy, chain, screws, wire nuts)

## 4. SPECIFICATIONS

<b>Brand</b>	AMZASA
<b>Model Number</b>	AS9027-5WH
<b>Color</b>	Gold (Fixture), White (Shades)
<b>Material</b>	Fabric shade, Iron, Metal
<b>Fixture Dimensions (Dia x H)</b>	25" x 19.3" (63.5 cm x 49 cm)
<b>Overall Height (Max)</b>	79.7" (202.4 cm) - Adjustable
<b>Canopy Diameter</b>	4.72" (12 cm)
<b>Chain Length</b>	69" (175 cm) - Adjustable
<b>Number of Lights</b>	5
<b>Bulb Base</b>	E12 Candelabra
<b>Max Wattage per Bulb</b>	40 Watts
<b>Voltage</b>	110 Volts
<b>Special Features</b>	Adjustable Height, Dimmable (with compatible bulbs/dimmer), Foldable Arms
<b>Installation Type</b>	Ceiling Mount
<b>Item Weight</b>	2.8 Pounds (1.27 kg)



Figure 2: Chandelier Dimensions

## 5. SETUP AND INSTALLATION

Professional installation is recommended. If you are performing the installation yourself, ensure you have the necessary tools, including a screwdriver, wire strippers, and potentially small wrenches for tightening components.

### 5.1 Pre-Installation

1. Turn off power at the main circuit breaker.
2. Unpack all components and inspect for any damage.
3. Review the fixture dimensions (Figure 2) to ensure it fits your intended space.
4. Determine the desired hanging height. The chain is 69 inches long and can be shortened by removing links.

### 5.2 Mounting the Fixture

1. Attach the mounting bracket to the junction box in the ceiling. Ensure it is securely fastened.
2. Connect the chandelier's chain to the canopy and the main rod. The design supports sloped, flat, and vaulted ceilings.
3. Feed the electrical wires through the chain and canopy.

### 5.3 Electrical Connections

- Connect the fixture's live (black or red) wire to the house's live (black) wire using a wire nut.
- Connect the fixture's neutral (white) wire to the house's neutral (white) wire using a wire nut.
- Connect the fixture's ground wire (bare copper or green) to the house's ground wire and the mounting bracket's ground screw.
- If installing with a dimmer switch, the fixture's live wire (L) typically connects to the dimmer's red wire, and the fixture's neutral wire (N) connects to the dimmer's white (neutral) wire. Consult your dimmer's instructions for specific wiring.
- Carefully tuck all wires into the junction box.

### 5.4 Final Assembly

1. Secure the canopy to the mounting bracket, ensuring it sits flush against the ceiling.
2. The golden metal robotic arms are pre-assembled. Gently twist and adjust each arm to your preferred orientation, ensuring they are evenly spaced and level.
3. Install the five white fabric shades onto the bulb holders.
4. Insert E12 candelabra base bulbs (not included) into each socket. Do not exceed 40 watts per bulb. LED bulbs are recommended for energy efficiency.




Figure 3: Key Installation Details

## 6. OPERATING INSTRUCTIONS

---

Once installation is complete and verified, restore power at the circuit breaker.

- **Turning On/Off:** Operate the chandelier using your wall switch.
- **Dimmable Feature:** If you have installed dimmable E12 bulbs and a compatible dimmer switch, you can adjust the light intensity by operating the dimmer control.



Figure 4: Chandelier ON/OFF State

## 7. MAINTENANCE

---

Regular maintenance ensures the longevity and appearance of your chandelier.

- **Cleaning:** Ensure power is off before cleaning. Use a soft, dry cloth to wipe the metal frame. For the fabric shades, gently dust with a soft brush or a lint roller. Avoid using abrasive cleaners or solvents, as these can damage the finish or fabric.
- **Bulb Replacement:** Always turn off power before replacing bulbs. Allow bulbs to cool completely before handling. Replace with E12 base bulbs, not exceeding 40 watts.

## 8. TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	<ol style="list-style-type: none"><li>1. Power off at circuit breaker.</li><li>2. Loose wiring connection.</li><li>3. Faulty bulb.</li></ol>	<ol style="list-style-type: none"><li>1. Check circuit breaker and wall switch.</li><li>2. Turn off power, check all wire connections.</li><li>3. Replace bulb with a known working one.</li></ol>
Chandelier arms appear crooked	Arms not evenly adjusted.	Gently adjust each robotic arm to ensure even spacing and level alignment. The arms are designed to be adjustable.
Loose components after installation	Insufficient tightening during assembly.	Turn off power. Carefully inspect and tighten any loose nuts or screws. Small wrenches may be required for some connections.

## 9. WARRANTY AND SUPPORT

The AMZASA Farmhouse Chandelier (Model AS9027-5WH) comes with a **3-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or warranty inquiries, please contact AMZASA customer service through the retailer where the product was purchased or visit the official AMZASA website.