

## XP-Pen Artist Pro 19 Gen2

# XPPen Artist Pro 19 Gen2 4K UHD Drawing Tablet User Manual

Model: Artist Pro 19 Gen2

## 1. INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your XPPen Artist Pro 19 Gen2 4K UHD Drawing Tablet. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

## 2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- **H11 Pen Case:** Includes X3 Pro Roller Stylus (1), X3 Pro Slim Stylus (1), Bluetooth Receiver for Wireless Shortcut Remote (1), Replaceable Button Cap for Slim Stylus (1), Standard Nib for Slim Stylus (4), Standard Nib for Roller Stylus (2), Felt Nib for Roller Stylus (2), Nib Extractor (1).
- 3-in-1 Cable (1)
- USB-C to USB-C Cable (2)
- USB-C to USB-A Cable (1)
- PD Power Adapter (1)
- Wireless Shortcut Remote ACK05 (1)
- Drawing Glove (1)
- Cleaning Cloth (1)
- **Pen Nibs Bag:** Includes Standard Nib for Slim Stylus (5), Standard Nib for Roller Stylus (5), Felt Nib for Roller Stylus (5).




Image: All components included in the XPPen Artist Pro 19 Gen2 package, including the tablet, two styluses, pen case, cables, power adapter, wireless shortcut remote, drawing glove, cleaning cloth, and extra nibs.

### 3. SETUP GUIDE

#### 3.1 Physical Installation

Place the drawing tablet on a stable surface. The integrated wing-shaped stand allows for adjustable angles. For alternative mounting, the tablet supports a standard VESA adapter (75x75mm).



Image: The XPPen Artist Pro 19 Gen2 drawing tablet shown with its integrated adjustable stand, demonstrating its stable placement and ergonomic design.

## 3.2 Connecting to Your Computer

The XPPen Artist Pro 19 Gen2 is not a standalone tablet and requires connection to a computer (desktop or laptop) to function. Ensure your computer meets the minimum system requirements for optimal performance.

### USB-C Connection (Full-featured USB-C Port)

If your computer has a full-featured USB-C port that supports video output (DP Alt Mode) and power delivery, you can connect the drawing display using a single USB-C to USB-C cable. If the display does not power on, connect the PD Power Adapter to the drawing display via another USB-C to USB-C cable.

## Dual Styli, Double Smooth



Image: A diagram illustrating two methods for connecting the drawing display to a PC using USB-C cables. One method uses a single USB-C cable for data, video, and power, while the other adds a separate USB-C cable for power via a PD adapter if needed.

### 3-in-1 Cable Connection

For computers without a full-featured USB-C port, use the provided 3-in-1 cable. Connect the HDMI and USB-A ends of the 3-in-1 cable to your computer. Then, connect the USB-C end of the 3-in-1 cable to the drawing display. Ensure the PD Power Adapter is connected to the drawing display via a USB-C to USB-C cable for power.




Image: A diagram illustrating two methods for connecting the drawing display to a PC using a 3-in-1 cable. This setup typically involves HDMI and USB-A connections to the PC, with a separate USB-C power connection to the display.

### 3.3 Driver Installation

Before installing new drivers, it is recommended to uninstall any existing tablet drivers from your computer to prevent conflicts. Download the latest driver for the Artist Pro 19 Gen2 from the official XP-Pen website. Follow the on-screen instructions to complete the installation. After installation, restart your computer.

## 4. OPERATING INSTRUCTIONS

### 4.1 Display Features

- **4K UHD Resolution:** The 18.4-inch display offers a 3840x2160 resolution for detailed visuals.
- **Color Accuracy:** Calman Verified with a  $\Delta E < 1.5$ , covering 99.8% sRGB, 96% Adobe RGB, and 98% Display P3



color gamuts. Supports 1.07 billion colors for smooth gradients.

- **Anti-Glare Etched Glass:** Reduces reflections and provides a paper-like texture for a natural drawing experience.
- **TÜV SÜD Certified:** Minimizes blue light exposure to reduce eye fatigue during extended use.
- **Full-Laminated Display:** Eliminates parallax for precise cursor placement.



18.4 inch

4K

4K UHD (3840x2160 px)



TÜV SÜD Certified  
(Low Blue Light)



Calman Verified  
Drawing Display



Delta E<1.5

1.07 Billion Colors



Image: An infographic highlighting key display features of the XPPen Artist Pro 19 Gen2, including its 18.4-inch size, 4K UHD resolution, TÜV SÜD certification for low blue light, Calman verification, Delta E < 1.5 color accuracy, and support for 1.07 billion colors.

## 4.2 Stylus Operation

The tablet comes with two X3 Pro styluses: the X3 Pro Roller Stylus and the X3 Pro Slim Stylus. Both feature 16,384 pen pressure levels, 3g initial active force, and 60° tilt function.

- **X3 Pro Roller Stylus:** Features a scroll wheel and customizable shortcut keys.
- **X3 Pro Slim Stylus:** Lightweight design with removable buttons to prevent accidental activation.
- **Customization:** Pen tilt can be disabled in the driver settings.

# X3 Pro Smart Chip Automatic ID Recognition




Image: A detailed view of the X3 Pro Slim Stylus and X3 Pro Roller Stylus, illustrating their buttons, scroll wheel (on the roller stylus), and highlighting the 16,384 pressure levels and X3 Pro Smart Chip technology.

## 4.3 ACK05 Wireless Shortcut Keyboard

The ACK05 remote features a physical dial and ten customizable keys. It connects via Bluetooth 5.0 or a Bluetooth dongle, enhancing workflow efficiency. Customize key functions through the tablet driver software.

# Delta E<1.5\* Elevate Art with High Color Accuracy

The high color accuracy meets the high standards of creative professionals.



\*For the sRGB only

Image: The ACK05 Wireless Shortcut Keyboard shown next to the drawing tablet, highlighting its compact design, physical dial, and customizable keys for improved workflow.

## 4.4 System and Software Compatibility

The Artist Pro 19 Gen2 is compatible with a wide range of operating systems and creative software:

- **Operating Systems:** Windows 7 (or later), macOS 10.13 (or later), ChromeOS 88 (or later), Android (USB3.1 DP1.2), Linux.
- **Software:** Adobe Photoshop, Illustrator, SAI, CorelDRAW, GIMP, Krita, MediBang, FireAlpaca, Toon Boom, Maya, Blender 3D, and more.



# ACK05 Bluetooth Keyboard

## Smoother Creation, Faster Pace

127.55 x 70.49 x 10mm

Wired, Bluetooth dongle, Bluetooth 5.0



Image: An illustration displaying the XPPen Artist Pro 19 Gen2's compatibility with major operating systems (Windows, macOS, Android, ChromeOS, Linux) and popular creative software applications (e.g., Photoshop, Illustrator, Krita, Blender 3D).

## 5. MAINTENANCE

### 5.1 Cleaning the Display

Use the provided cleaning cloth to gently wipe the display surface. Avoid using harsh chemicals or abrasive materials that could damage the screen.

### 5.2 Replacing Stylus Nibs

When the stylus nib wears down, use the nib extractor tool (located in the pen case) to carefully pull out the old nib. Insert a new nib firmly into the stylus. A variety of replacement nibs (standard and felt) are included in the pen case and nibs bag.

## 6. TROUBLESHOOTING



- **Display Not Lighting Up:** Ensure all cables are securely connected. If using USB-C, confirm your computer's USB-C port supports video output and power delivery, or connect the PD Power Adapter.
- **Stylus Not Responding:** Check if the stylus is charged. Verify that the drivers are correctly installed and updated. Ensure no other tablet drivers are causing conflicts.
- **Driver Conflicts:** Uninstall all previous tablet drivers before installing the XPPen driver.
- **Color Inaccuracy:** Ensure your display settings are correctly calibrated and that the tablet driver is configured for the desired color profile (sRGB, Adobe RGB, Display P3).

For further assistance, please refer to the support section.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	19 x 14 x 0.1 inches
Item Weight	9.58 pounds
Model Number	Artist Pro 19 Gen2
Display Resolution	4K UHD (3840x2160)
Screen Size	18.4 inches (diagonal)
Color Gamut	99.8% sRGB, 96% Adobe RGB, 98% Display P3
Color Depth	1.07 Billion Colors (10-bit)
Stylus Pressure Levels	16,384
Stylus Tilt Support	60°
Connectivity	3-in-1 Cable, USB-C to USB-C Cable
Operating System Compatibility	Windows 7+, macOS 10.13+, ChromeOS 88+, Android (USB3.1 DP1.2), Linux
Special Features	AG etched glass, TÜV SÜD certified, Calman Verified, Dual Stylus, ACK05 Wireless Shortcut Keyboard

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

All XPPen products come with a 1-Year Protection Plan. Please refer to the terms and conditions for support, returns, and refunds.



Image: The XP-Pen brand logo, representing the manufacturer of the drawing tablet.







## 8.2 Customer Support



For any questions or assistance regarding your product, you can contact XPPen customer service via Amazon Message. XPPen also offers lifetime service for its products.



© 2023 XP-Pen. All rights reserved.

### Related Documents - Artist Pro 19 Gen2

  	<p><a href="#">XP-PEN Graphics Tablet Driver User Manual - Setup and Features</a></p> <p>A comprehensive user manual for XP-PEN graphics tablet drivers, detailing installation, configuration of work area, pen settings, express keys, roller/touch functions, and display adjustments. Supports various XP-PEN models including Star, Deco, Innovator, and Artist series.</p>
  	<p><a href="#">XP-Pen Magic Drawing Pad Quick Guide - Model 9494 G</a></p> <p>This quick guide provides essential information for the XP-Pen Magic Drawing Pad (Model 9494 G), including product overview, specifications, package contents, stylus operation, charging, Micro SD card usage, safety precautions, and FCC compliance details.</p>
	<p><a href="#">XP-PEN Artist 15.6 Graphic Pen Display User Manual</a></p> <p>This user manual provides comprehensive instructions for the XP-PEN Artist 15.6 Graphic Pen Display, covering safety precautions, product overview, setup, driver installation and uninstallation for Windows and macOS, driver settings customization, and frequently asked questions.</p>
	<p><a href="#">XPPen Artist 3rd Series Graphics Display User Manual</a></p> <p>Comprehensive user manual for the XPPen Artist 3rd Series Graphics Display, covering setup, driver installation, stylus usage, settings, and troubleshooting.</p>

<p><b>Contents</b></p> <ul style="list-style-type: none"><li>001 Quick start</li><li>002 Power, sleep, and reset</li><li>003 OS, firmware</li><li>004 Features and feature settings</li><li>005 Basic use</li><li>006 Troubleshooting and warranty</li></ul>	<p><a href="#">XPPen Magic Drawing Pad User Manual</a></p> <p>User manual for the XPPen Magic Drawing Pad, covering home screen navigation, power operations, file transfer (wired and Bluetooth), charging, stylus usage, preventing finger false touch, and redeeming an ibis Paint X membership. Detailed steps and notes are provided for each feature.</p>
<p>How to make express keys on Windows?</p> <p>The drawing pen used in this guide is the XP-PEN Pro PenTablet. Settings shown are for Windows 10.</p>  <p>It is recommended that you check the settings of your XP-PEN Pro PenTablet. Settings for the XP-PEN Pro PenTablet are shown in the screenshot. The settings are as follows:</p>  <p>There is also a PenTablet Settings app on Windows.</p>	<p><a href="#">How to Set Up XP-PEN PenTablet Express Keys and Install Drivers</a></p> <p>A comprehensive guide to configuring express keys for XP-PEN graphics tablets on Windows and installing XP-PEN drivers on macOS Catalina (10.15), covering PenTablet settings and essential system preferences.</p>