Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOSHIRO Night Stand

BOSHIRO Farmhouse Nightstand with Charging Station User Manual

Brand: BOSHIRO
Model: Night Stand

1. Introduction and Overview

This manual provides essential information for the assembly, operation, and maintenance of your BOSHIRO Farmhouse Nightstand with Charging Station. Designed with a rustic antique white finish, carved pilasters, and two spacious drawers, this nightstand offers both aesthetic appeal and practical functionality, including an integrated charging station for your electronic devices. It is suitable for use in bedrooms, living rooms, or other areas requiring convenient storage and power access.



Figure 1.1: BOSHIRO Farmhouse Nightstand with Charging Station.

2. Safety Information

Please read and understand all safety instructions before assembling or using the nightstand. Failure to follow these instructions may result in injury or damage to the product.

- **Proper Assembly:** Ensure proper assembly to avoid tipping. All fasteners must be securely tightened.
- **Weight Distribution:** Keep heavy items away from the edge of the nightstand to maintain stability. Distribute weight evenly within drawers and on the top surface.
- **Electrical Safety:** The integrated charging station is designed for standard electronic devices. Do not overload the outlets. Avoid using damaged cords or plugs. Keep liquids away from the charging station.
- **Placement:** Place the nightstand on a flat, stable, and level surface.
- **Children and Pets:** Keep small parts and assembly tools out of reach of children and pets. Do not allow children to climb on or play with the nightstand.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact BOSHIRO customer service.

- Nightstand Frame Components
- Drawer Components (2 sets)
- Integrated Charging Station Unit
- Hardware Pack (screws, dowels, cam locks, etc.)
- Assembly Guide

4. Setup and Assembly

Assembly of the BOSHIRO Nightstand is designed to be straightforward with the included Assembly Guide. Please follow the clear step-by-step illustrations and ensure all screws and pieces are correctly labeled and used.

Tools Required:

- Hammer
- Screwdriver (Phillips head recommended)

Assembly Steps (General Overview):

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the main frame of the nightstand according to the diagrams in the Assembly Guide.
3. Construct the two drawers, ensuring the drawer slides are correctly oriented.
4. Install the integrated charging station into its designated slot on the top surface.
5. Insert the assembled drawers into the nightstand frame.
6. Attach any remaining decorative elements or hardware.
7. Ensure all connections are secure and the nightstand is stable before use.



Figure 4.1: Nightstand Dimensions and Drawer Components.



Figure 4.2: Detail of Wood Carved Pilasters and Sturdy Base.

5. Operating Instructions (Charging Station)

The BOSHIRO Nightstand features a convenient integrated charging station to power your electronic devices.

Features:

- 2 Standard AC Outlets (125V/12A)
- 2 USB Ports (5V/2.1A)
- 2.3-inch Round Hole for Cord Organization (located at the back)
- 4.9-Foot Power Cord

Usage:

1. Plug the nightstand's power cord into a standard wall outlet.
2. Connect your devices (e.g., smartphones, tablets, lamps) to the AC outlets or USB ports on the charging station.
3. Utilize the cord organization hole at the back to neatly route cables and reduce clutter.



Figure 5.1: Charging Station in Use.

6. Maintenance and Care

Proper care will help maintain the appearance and longevity of your nightstand.

- **Cleaning:** Wipe the nightstand with a dry cloth to remove dust and dirt. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or damage to the wood.
- **Sunlight and Heat:** Avoid placing the nightstand in direct sunlight or near heat sources, which can cause fading, warping, or cracking of the wood.
- **Drawer Maintenance:** Periodically check drawer slides for smooth operation. If drawers become stiff, a small amount of silicone lubricant can be applied to the slides.

7. Troubleshooting

This section addresses common issues you might encounter with your nightstand.

Problem	Possible Cause	Solution
Nightstand is wobbly or unstable.	Loose fasteners; uneven floor; improper assembly.	Check all screws and bolts and tighten them. Ensure the nightstand is on a level surface. Review the assembly guide to confirm all steps were followed correctly.
Drawers do not slide smoothly or get stuck.	Misaligned drawer slides; debris in tracks; overloaded drawer.	Ensure drawers are correctly inserted into the slides. Clear any debris from the tracks. Do not overload drawers beyond their capacity. Apply a small amount of silicone lubricant to the slides if needed.
Charging station is not providing power.	Nightstand not plugged in; wall outlet not working; device cable issue; charging station malfunction.	Verify the nightstand's power cord is securely plugged into a functional wall outlet. Test the wall outlet with another device. Try a different charging cable or device. If the issue persists, contact customer service.
Missing or damaged parts upon delivery.	Shipping damage; packaging error.	Do not attempt to assemble. Contact BOSHIRO customer service immediately with your purchase details and a description of the missing/damaged parts.

8. Specifications

Detailed specifications for the BOSHIRO Farmhouse Nightstand.

Brand	BOSHIRO
Model Name	Night Stand
Product Dimensions (D x W x H)	15.8"D x 19.7"W x 23.6"H
Color	Antique White
Item Weight	43 Pounds
Material Type	Engineered Wood
Number of Drawers	2
Table Design	Nightstand / End Table
Style Name	Modern Farmhouse
Included Components	Assembly Guide
Tools Recommended For Assembly	Hammer, Screw Driver
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2.1A), 4.9-Foot Power Cord



Figure 8.1: Nightstand used as a Side Table in a Living Room.

9. Warranty and Support

While specific warranty details are not provided in this manual, BOSHIRO is committed to product quality and customer satisfaction. If you encounter any issues, have questions about assembly, or require replacement parts, please contact BOSHIRO customer service.

For assistance, please refer to the contact information provided with your purchase or visit the official BOSHIRO website. Our support team is available to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8W7NC63

More documents and user manuals: **https://manuals.plus/**